

Description of Device Parameters

Proline Promag 800

Electromagnetic flowmeter




Table of contents

1	About this document	4	6	"System" menu	74
1.1	Document function	4	6.1	"Device management" submenu	74
1.2	Target group	4	6.2	"User management" submenu	77
1.3	Using this document	4	6.2.1	"Define access code" wizard	78
1.3.1	Symbols for certain types of information	4	6.3	"Connectivity" submenu	79
1.3.2	Information on the document structure	4	6.3.1	"Bluetooth configuration" submenu ...	79
1.3.3	Structure of a parameter description ..	5	6.4	"Date/time" submenu	80
1.4	Documentation	5	6.5	"Geolocation" submenu	82
1.4.1	Operating Instructions	5	6.6	"Power management" submenu	83
1.4.2	Special Documentation	5	6.7	"Information" submenu	85
			6.7.1	"Device" submenu	85
			6.7.2	"Electronic module" submenu	88
			6.7.3	"Display module" submenu	89
2	"Guidance" menu	6	6.8	"Display" submenu	90
2.1	"Commissioning" wizard	6	6.9	"Software configuration" submenu	93
2.2	"Import / Export" submenu	19			
3	"Device information" menu	20	Index		95
4	"Diagnostics" menu	21			
4.1	"Active diagnostics" submenu	21			
4.2	"Diagnostic list" submenu	23			
4.3	"Simulation" submenu	25			
4.4	"Heartbeat" submenu	28			
4.5	"Diagnostic settings" submenu	28			
4.5.1	"Properties" submenu	28			
4.5.2	"Diagnostic configuration" submenu ..	29			
4.6	"Tracking pointer" submenu	38			
4.6.1	"Reset minimum/maximum values" submenu	38			
4.6.2	"Electronics temperature" submenu ...	38			
5	"Application" menu	40			
5.1	"Measured values" submenu	40			
5.1.1	"Totalizer" submenu	42			
5.2	"Units" submenu	43			
5.3	"Totalizers" submenu	46			
5.3.1	"Totalizer handling" submenu	46			
5.3.2	"Totalizer 1 to n" submenu	47			
5.4	"Sensor" submenu	50			
5.4.1	"Process parameters" submenu	50			
5.4.2	"Low flow cut off" submenu	52			
5.4.3	"Empty pipe detection" submenu	53			
5.4.4	"Sensor adjustment" submenu	56			
5.4.5	"Calibration" submenu	59			
5.4.6	"Supervision" submenu	60			
5.4.7	"Properties" submenu	61			
5.5	"Status input" submenu	61			
5.6	"Pulse/switch output 1 to n" submenu	62			
5.7	"Custody transfer" submenu	69			
5.8	"Data logging" submenu	69			
5.9	"Measured value supervision" submenu	70			

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the operating menus.

It is used to perform tasks that require detailed knowledge of the function of the device:








- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases

1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.





1.3 Using this document

1.3.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
 A0028662	Operation via local display
 A0028663	Operation via operating tool
 A0028665	Write-protected parameter




1.3.2 Information on the document structure

The parameters of all the operating menus and the commissioning wizard are described in this document.

- **Guidance** menu with the **Commissioning** wizard (→  6), which guides the user automatically through all the device parameters that are required for commissioning
- **Application** menu (→  40)
- **Diagnostics** menu (→  21)
- **System** menu (→  74)

1.3.3 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the operating tool  The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Selection	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Input range for the parameter
User interface	Display value/data for the parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function

1.4 Documentation

The Description of Device Parameters is part of the following documentation:

1.4.1 Operating Instructions

Measuring device	Documentation code
Proline 800	BA02081D



1.4.2 Special Documentation

Contents	Documentation code
Heartbeat Technology	SD01746D
Display with Bluetooth interface	SD02655D
Using Open Source Software Licenses	SD02658D
Information on Custody Transfer Measurement	SD02038D

2 "Guidance" menu

Main functions for use – from fast and safe commissioning to guided support during operation.

Navigation  Guidance

Guidance	
▶ Commissioning	→  6
▶ Import / Export	→  19

2.1 "Commissioning" wizard

Complete this wizard to commission the device.













For each parameter, enter the appropriate value or select the appropriate option.





















NOTE

If you exit the wizard before completing all required parameters, the changes you made will be saved. For this reason, the device may be in an undefined state!

In this case, a reset to the default settings is recommended.

Navigation  Guidance → Commissioning

▶ Commissioning	
Device tag	→  7
Serial number	→  8
Firmware version	→  8
Device name	→  8
Volume flow unit	→  8
Volume unit	→  9
Temperature unit	→  10
Pressure unit	→  10
Assign process variable	→  10
Unit totalizer 1 to n	→  11
Totalizer operation mode	→  11
Failure mode	→  12

Low flow cut off	→  12
On value low flow cutoff	→  13
Off value low flow cutoff	→  13
Empty pipe detection	→  13
Operating mode	→  13
Assign pulse output 1 to n	→  14
Pulse width	→  14
Value per pulse	→  15
Switch output function	→  15
Assign diagnostic behavior	→  16
Assign limit	→  16
Switch-on value	→  16
Switch-off value	→  17
Assign status	→  17
Failure mode	→  17
Value 1 display	→  18
Value 2 display	→  18
Value 3 display	→  18
Value 4 display	→  19
Display damping	→  12

Device tag

Navigation


 Guidance → Commissioning → Device tag

Description

Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (#32)

Serial number

Navigation  Guidance → Commissioning → Serial number

Description Displays the serial number of the measuring device. The serial number can be used to identify the measuring device and to retrieve further information on the measuring device, such as the related documentation, via the Device Viewer or Operations app.

Additional information:

The serial number can also be found on the nameplate of the sensor and transmitter.

User interface Character string comprising numbers, letters and special characters (#11)

Firmware version

Navigation  Guidance → Commissioning → Firmware version

Description Displays the device firmware version installed.

User interface Character string comprising numbers, letters and special characters (#8)

Device name

Navigation  Guidance → Commissioning → Device name

Description Displays the name of the transmitter.

Additional information:

The name can also be found on the transmitter's nameplate.

User interface Character string comprising numbers, letters and special characters (#16)

Volume flow unit

Navigation  Guidance → Commissioning → Volume flow unit

Description Select volume flow unit.

Selection*SI units*

- cm³/s
- cm³/min
- cm³/h
- cm³/d
- dm³/s
- dm³/min
- dm³/h
- dm³/d
- m³/s
- m³/min
- m³/h
- m³/d
- ml/s
- ml/min
- ml/h
- ml/d
- l/s
- l/min
- l/h
- l/d
- hl/s
- hl/min
- hl/h
- hl/d
- Ml/s
- Ml/min
- Ml/h
- Ml/d

US units

- af/s
- af/min
- af/h
- af/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- MMft³/s
- MMft³/min
- MMft³/h
- Mft³/d
- fl oz/s (us)
- fl oz/min (us)
- fl oz/h (us)
- fl oz/d (us)
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- Mgal/s (us)
- Mgal/min (us)
- Mgal/h (us)
- Mgal/d (us)
- bbl/s (us;liq.)
- bbl/min (us;liq.)
- bbl/h (us;liq.)
- bbl/d (us;liq.)
- bbl/s (us;beer)
- bbl/min (us;beer)
- bbl/h (us;beer)
- bbl/d (us;beer)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- bbl/s (us;tank)
- bbl/min (us;tank)
- bbl/h (us;tank)
- bbl/d (us;tank)
- kgal/s (us)
- kgal/min (us)
- kgal/h (us)
- kgal/d (us)

Imperial units

- gal/s (imp)
- gal/min (imp)
- gal/h (imp)
- gal/d (imp)
- Mgal/s (imp)
- Mgal/min (imp)
- Mgal/h (imp)
- Mgal/d (imp)
- bbl/s (imp;beer)
- bbl/min (imp;beer)
- bbl/h (imp;beer)
- bbl/d (imp;beer)
- bbl/s (imp;oil)
- bbl/min (imp;oil)
- bbl/h (imp;oil)
- bbl/d (imp;oil)

Volume unit**Navigation**

Guidance → Commissioning → Volume unit

Description

Select volume unit.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	<ul style="list-style-type: none"> ■ cm³ ■ dm³ ■ m³ ■ ml ■ l ■ hl ■ Ml Mega 	<ul style="list-style-type: none"> ■ af ■ ft³ ■ Mft³ ■ fl oz (us) ■ gal (us) ■ kgal (us) ■ Mgal (us) ■ bbl (us;oil) ■ bbl (us;liq.) ■ bbl (us;beer) ■ bbl (us;tank) 	<ul style="list-style-type: none"> ■ gal (imp) ■ Mgal (imp) ■ bbl (imp;beer) ■ bbl (imp;oil)

Temperature unit



Navigation Guidance → Commissioning → Temperature unit

Description Select temperature unit.

Selection	<i>SI units</i>	<i>US units</i>
	<ul style="list-style-type: none"> ■ °C ■ K 	<ul style="list-style-type: none"> ■ °F ■ °R

Pressure unit



Navigation Guidance → Commissioning → Pressure unit

Description Select process pressure unit.

Selection	<i>SI units</i>	<i>US units</i>
	<ul style="list-style-type: none"> ■ MPa a ■ MPa g ■ kPa a ■ kPa g ■ Pa a ■ Pa g ■ bar ■ bar g 	<ul style="list-style-type: none"> ■ psi a ■ psi g

Assign process variable



Navigation Guidance → Commissioning → Assign variable

Description Select process variable for totalizer.
 Additional information:
 If the option selected is changed, the device resets the totalizer to "0".

- Selection**
- Off
 - Volume flow

Unit totalizer



Navigation Guidance → Commissioning → Unit totalizer 1 to n

Description Select process variable totalizer unit.

- Selection**
- | | | |
|--|---|---|
| <p><i>SI units</i></p> <ul style="list-style-type: none"> ■ cm³ * ■ dm³ * ■ m³ * ■ ml * ■ l * ■ hl * ■ Ml Mega * | <p><i>US units</i></p> <ul style="list-style-type: none"> ■ af * ■ ft³ * ■ Mft³ * ■ fl oz (us) * ■ gal (us) * ■ kgal (us) * ■ Mgal (us) * ■ bbl (us;liq.) * ■ bbl (us;beer) * ■ bbl (us;oil) * ■ bbl (us;tank) * | <p><i>Imperial units</i></p> <ul style="list-style-type: none"> ■ gal (imp) * ■ Mgal (imp) * ■ bbl (imp;beer) * ■ bbl (imp;oil) * |
|--|---|---|

* Visibility depends on order options or device settings

or

Other units
None *

* Visibility depends on order options or device settings

Totalizer operation mode



Navigation Guidance → Commissioning → Operation mode


Description Select totalizer calculation mode.


- Selection**
- Net flow total
 - Forward flow total
 - Reverse flow total


Additional information *Selection*

- **Net flow total** option
The flow values in the forward and reverse flow directions are totalized and netted against each other. Net flow is recorded in the flow direction.
- **Forward flow total** option
Only the flow in the forward flow direction is totalized.
- **Reverse flow total** option
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).


Failure mode 

Navigation	 Guidance → Commissioning → Failure mode
Description	Specify how the totalizer should behave in the event of a device alarm. Additional information: The failsafe mode that applies to any other totalizers or outputs is specified separately in other parameters and is not impacted by this setting.
Selection	<ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value
Additional information	<i>Selection</i> <ul style="list-style-type: none"> ■ Stop option The totalizer is stopped in the event of a device alarm. ■ Actual value option The totalizer continues to totalize based on the current value measured; the device alarm is ignored. ■ Last valid value option The totalizer continues to totalize based on the last valid value measured before the device alarm occurred.

Display damping 


Navigation	 Guidance → Commissioning → Display damping
Description	Enter time constant (PT1 element) to set reaction time of the display to fluctuations in the measured value. Additional information: - The smaller the time constant the faster the display reacts to fluctuations in the measured value. - If the time constant is set to 0, damping is deactivated.
User entry	0.0 to 999.9 s

Low flow cut off 

Navigation	 Guidance → Commissioning → Low flow cut off
Description	Select process variable for low flow cut off to activate low flow cut off.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow

On value low flow cutoff




Navigation  Guidance → Commissioning → On value

Description Enter on value to switch on low flow cut off.
Value = 0: No low flow cut off
Value > 0: Low flow cut off is activated

User entry Positive floating-point number

Off value low flow cutoff



Navigation  Guidance → Commissioning → Off value

Description Enter off value to switch off low flow cut off. The off value is entered as a positive hysteresis with respect to the on value.

User entry 0 to 100.0 %

Empty pipe detection



Navigation  Guidance → Commissioning → Empty pipe det.

Description Switch empty pipe detection on or off. Switch on empty pipe detection to detect a partially filled or empty measuring tube.

Selection

- Off
- On

Operating mode







Navigation  Guidance → Commissioning → Operating mode

Description Set the output mode to pulse or switch.

Selection

- Pulse
- Switch

Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Pulse option Quantitatively proportional pulse with pulse width to be configured. Whenever a specific volume has been reached (pulse value), a pulse is emitted, the duration of which is set within the "Pulse width" parameter. ▪ Switch option Indicates when the state of the device changes, e.g. when a specified limit value is reached. Additional information: <ul style="list-style-type: none"> - The switch output can be in one of two states: either it is conductive or it is non-conductive. - When the function assigned to the switch output is triggered, the switch output will depending on the output configuration either be continuously conductive or continuously non-conductive or, in case of battery-operated devices, it will emit a pulse, i.e. the switch output will be closed and conductive for the duration of the pulse. - The switch output is used to display diagnostic information at the system level, e. g. by connecting a lamp that lights up when the function assigned is triggered.
<hr/>	
Assign pulse output 	
Navigation	 Guidance → Commissioning → Assign pulse 1 to n
Description	Select process variable for pulse output.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow
<hr/>	
Pulse width 	
Navigation	 Guidance → Commissioning → Pulse width
Description	<p>Specify the duration of the output pulse.</p> <p>Additional information: The maximum pulse rate is defined by $f_{max} = 1 / (2 \times \text{pulse width})$. The interval between two pulses (P) is at least as long as the specified pulse width (B). The maximum flow is defined by $Q_{max} = f_{max} \times \text{pulse value}$. If the flow exceeds these limit values, the measuring device displays the diagnostic message "443 Pulse output faulty".</p> <p>Example: - Pulse value: 0.1 g - Pulse width: 0.1 ms - $f_{max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$ - $Q_{max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$</p>
User entry	0.1 to 500 ms

Value per pulse
**Navigation**

Guidance → Commissioning → Value per pulse

Description

Enter the measured value to which a pulse corresponds.

Additional information:

Weighting of the pulse output with a quantity.

The lower the pulse value, the

– better the resolution.

– higher the frequency of the pulse response.

User entry

Signed floating-point number

Switch output function
**Navigation**

Guidance → Commissioning → Switch out funct

Description

Assign a function to the switch output.

Additional information:

- The state of the switch output (on or off) when the assigned function is triggered can be inverted in the "Invert output signal" parameter

- The "Invert output signal" parameter is not available for all devices.

Selection

- Off
- On
- Diagnostic behavior
- Limit
- Flow direction check
- Status

Additional information

Selection

- **Off** option

The switch output is permanently switched off (open, non-conductive).

- **On** option

The switch output is permanently switched on (closed, conductive).

- **Diagnostic behavior** option

Emits a pulse if there is a pending diagnostic event of the assigned behavioral category.

- **Limit** option



Emits a pulse if a limit value specified for the process variable has been reached.



- **Flow direction check** option


Emits a pulse when the flow direction changes.


- **Status** option

Emits a pulse to indicate the device status for empty pipe detection or low flow cut off, whichever option is assigned to the switch output.

Assign diagnostic behavior		
Navigation		Guidance → Commissioning → Assign diag. beh
Description	Select the diagnostic behavior for which the switch output should emit a pulse.	
Selection	<ul style="list-style-type: none"> ■ Alarm ■ Alarm or warning ■ Warning 	
Additional information	<i>Selection</i> <ul style="list-style-type: none"> ■ Alarm option The switch output only emits a pulse for diagnostic events of the "Alarm" category. ■ Alarm or warning option The switch output emits a pulse for diagnostic events of the "Alarm" or "Warning" category. ■ Warning option The switch output only emits a pulse for diagnostic events of the "Warning" category. 	

Assign limit		
Navigation		Guidance → Commissioning → Assign limit
Description	Select the process variable to monitor in case the specified limit value is exceeded. If a limit value for the selected process variable is exceeded, the output emits a pulse.	
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Flow velocity ■ Conductivity* ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Pressure* ■ Battery state of charge 	

Switch-on value		
------------------------	--	---

Navigation		Guidance → Commissioning → Switch-on value
Description	Enter limit value for the switch-on point (process variable > switch-on value = closed, conductive). Additional information: To use a hysteresis: Switch-on point > Switch-off point.	
User entry	Signed floating-point number	

* Visibility depends on order options or device settings

Switch-off value

**Navigation**

Guidance → Commissioning → Switch-off value

Description

Enter limit value for the switch-off point (process variable < switch-off value = open, non-conductive).

Additional information:

To use a hysteresis: Switch-on point > Switch-off point.

User entry

Signed floating-point number

Assign status

**Navigation**

Guidance → Commissioning → Assign status

Description

Select the device status to display for the switch output.

Additional information:

If the switch on point for empty pipe detection / low flow cut off is reached, the output is conductive. Otherwise, the switch output is non-conductive.

Selection

- Empty pipe detection
 - Low flow cut off
-

Failure mode

**Navigation**

Guidance → Commissioning → Failure mode

Description

Specify how the output should behave in the event of a device alarm.

Additional information:

For safety reasons, it is recommended that the behavior of the output in the event of a device alarm be predefined.

Selection

- Actual status
- Open
- Closed

Additional information

Selection


- **Actual status** option

In the event of a device alarm, the issue is ignored and the switch output adopts the behavior currently specified for the "Switch output function" parameter.

- **Open** option

In the event of a device alarm, the switch output's transistor is set to "non-conductive".

Value 1 display 


Navigation  Guidance → Commissioning → Value 1 display

Description Select the measured value that is displayed first on the local display.
 Additional information:
 The applicable unit of measure is specified in the "System units" submenu.

Selection

- Volume flow
- Conductivity *
- Pressure *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Value 2 display 


Navigation  Guidance → Commissioning → Value 2 display

Description Select the measured value that is shown second on the local display.
 Additional information:
 The applicable unit of measure is specified in the "System units" submenu.

Selection

- None
- Volume flow
- Conductivity *
- Pressure *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Value 3 display 

Navigation  Guidance → Commissioning → Value 3 display

Description Select the measured value that is shown third on the local display.
 Additional information:
 The applicable unit of measure is specified in the "System units" submenu.

Selection

- None
- Volume flow
- Conductivity *
- Pressure *
- Totalizer 1
- Totalizer 2
- Totalizer 3

* Visibility depends on order options or device settings

Value 4 display

**Navigation**

 Guidance → Commissioning → Value 4 display

Description

Select the measured value that is shown fourth on the local display.

Additional information:

The applicable unit of measure is specified in the "System units" submenu.

Selection

- None
- Volume flow
- Conductivity *
- Pressure *
- Totalizer 1
- Totalizer 2
- Totalizer 3

2.2 "Import / Export" submenu


Use the Import/Export functionality to import or export data, e.g. to generate a report.


Navigation  Guidance → Import / Export

▶ Import / Export

* Visibility depends on order options or device settings

3 "Device information" menu

Navigation  Device info



Status signal

Navigation  Device info → Status signal

User interface

- OK
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- ---
- Not categorized

Volume flow

Navigation  [Application](#) → [Measured values](#) → [Volume flow](#)





Description Displays the volume flow currently measured.
 Additional information:
 The applicable unit of measure is specified in the "System units" submenu.

User interface Signed floating-point number

4 "Diagnostics" menu







Troubleshooting and preventive maintenance – settings for device behavior during process and device events as well as assistance and measures for diagnostic purposes.

Navigation  Diagnostics


Diagnostics	
▶ Active diagnostics	→  21
▶ Diagnostic list	→  23
▶ Simulation	→  25
▶ Diagnostic settings	→  28

4.1 "Active diagnostics" submenu

Navigation  Diagnostics → Active diagnos.

▶ Active diagnostics	
Actual diagnostics	→  21
Timestamp	→  22
Previous diagnostics	→  22
Timestamp	→  22
Operating time from restart	→  22
Operating time	→  22


Actual diagnostics

Navigation  Diagnostics → Active diagnos. → Actual diagnos.


Description Displays the currently active diagnostic message.
 If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed.

User interface Positive integer


Timestamp

Navigation	 Diagnostics → Active diagnos. → Timestamp
Description	Displays the timestamp for the currently active diagnostic message.
User interface	Days (d), hours (h), minutes (m), seconds (s)


Previous diagnostics

Navigation	 Diagnostics → Active diagnos. → Prev.diagnostics
Description	Displays the diagnostic message for the last diagnostic event that has ended.
User interface	Positive integer


Timestamp

Navigation	 Diagnostics → Active diagnos. → Timestamp
Description	Displays the timestamp of the diagnostic message generated for the last diagnostic event that has ended.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time from restart

Navigation	 Diagnostics → Active diagnos. → Time fr. restart
Description	Indicates how long the device has been in operation since the last time the device was restarted.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time











Navigation	 Diagnostics → Active diagnos. → Operating time
Description	Indicates how long the device has been in operation.

User interface Days (d), hours (h), minutes (m), seconds (s)

4.2 "Diagnostic list" submenu

Navigation  Diagnostics → Diagnostic list → Diagnostics 1

▶ Diagnostic list

Diagnostics 1	→  23
Timestamp	→  23
Diagnostics 2	→  24
Timestamp	→  24
Diagnostics 3	→  24
Timestamp	→  24
Diagnostics 4	→  24
Timestamp	→  25
Diagnostics 5	→  25
Timestamp	→  25

Diagnostics 1

Navigation  Diagnostics → Diagnostic list → Diagnostics 1

Description Displays the currently active diagnostic message with the highest priority.

User interface Positive integer


Timestamp

Navigation  Diagnostics → Diagnostic list → Timestamp

Description Displays the timestamp for the diagnostic message with the highest priority.

User interface Days (d), hours (h), minutes (m), seconds (s)


Diagnostics 2

Navigation  Diagnostics → Diagnostic list → Diagnostics 2

Description Displays the currently active diagnostic message with the second highest priority.

User interface Positive integer

Timestamp

Navigation  Diagnostics → Diagnostic list → Timestamp

Description Displays the timestamp for the diagnostic message with the second highest priority.

User interface Days (d), hours (h), minutes (m), seconds (s)


Diagnostics 3

Navigation  Diagnostics → Diagnostic list → Diagnostics 3

Description Displays the currently active diagnostic message with the third highest priority.

User interface Positive integer

Timestamp

Navigation  Diagnostics → Diagnostic list → Timestamp

Description Displays the timestamp for the diagnostic message with the third highest priority.

User interface Days (d), hours (h), minutes (m), seconds (s)


Diagnostics 4

Navigation  Diagnostics → Diagnostic list → Diagnostics 4

Description Displays the currently active diagnostic message with the fourth highest priority.

User interface Positive integer


Timestamp

Navigation  Diagnostics → Diagnostic list → Timestamp

Description Displays the timestamp for the diagnostic message with the fourth highest priority.

User interface Days (d), hours (h), minutes (m), seconds (s)

Diagnostics 5

Navigation  Diagnostics → Diagnostic list → Diagnostics 5

Description Displays the currently active diagnostic message with the fifth-highest priority.

User interface Positive integer

Timestamp





Navigation  Diagnostics → Diagnostic list → Timestamp



Description Displays the timestamp for the diagnostic message with the fifth highest priority.

User interface Days (d), hours (h), minutes (m), seconds (s)


4.3 "Simulation" submenu

Navigation  Diagnostics → Simulation


▶ Simulation	
Assign simulation process variable	→  26
Process variable value	→  26
Pulse output simulation 1 to n	→  26
Pulse value 1 to n	→  27

Device alarm simulation	→  27
Diagnostic event simulation	→  28


Assign simulation process variable

Navigation	 Diagnostics → Simulation → Assign proc.var.
Description	Select a process variable for the simulation, thereby activating it.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Flow velocity* ■ Conductivity* ■ Temperature * ■ Pressure

Process variable value

Navigation	 Diagnostics → Simulation → Proc. var. value
Description	<p>Enter the simulation value for the selected process variable. Processing of measured values downstream as well as the signal output follow this value. In this way, it is possible to verify whether the measuring device has been configured correctly.</p> <p>Additional information: The applicable unit of measure is specified in the "System units" submenu.</p>
User entry	Signed floating-point number

Pulse output simulation 1 to n

Navigation	 Diagnostics → Simulation → Puls.outp.sim. 1 to n
Description	Switch simulation of the pulse output on or off.
Selection	<ul style="list-style-type: none"> ■ Off ■ Fixed value ■ Down-counting value

* Visibility depends on order options or device settings

Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off option Simulation of the pulse output is switched off. The device is in standard operation mode or another process variable is being simulated. ▪ Fixed value option Pulses are emitted continuously with the pulse width specified in the "Pulse width" parameter. ▪ Down-counting value option The number of pulses specified in the "Pulse value " parameter are emitted.
-------------------------------	---

Pulse value 1 to n


Navigation	Diagnostics → Simulation → Pulse value 1 to n
Description	Enter the number of pulses to simulate the pulse output. In this manner, it is possible to verify the pulse output is configured correctly and downstream processing units are functioning properly.
User entry	0 to 65 535

Diagnostic event category


Navigation	Diagnostics → Simulation → Event category
Description	Select the category of diagnostic events that should be available for selection in the "Diagnostic event simulation" parameter.
Selection	<ul style="list-style-type: none"> ▪ Sensor ▪ Electronics ▪ Configuration ▪ Process

Device alarm simulation


Navigation	Diagnostics → Simulation → Dev. alarm sim.
Description	<p>Switch the device alarm simulation on or off.</p> <p>While simulation is in progress, the display alternates between the measured value and a diagnostic message of the Function Check (C) category.</p>
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On

Diagnostic event simulation



Navigation	Diagnostics → Simulation → Diag. event sim.
Description	Select the diagnostic event to simulate.
Selection	Off

4.4 "Heartbeat" submenu

For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** application package, refer to the Special Documentation for the device → 5

4.5 "Diagnostic settings" submenu

Navigation Diagnostics → Diag. settings

▶ Diagnostic settings

▶ Properties

→ 28

4.5.1 "Properties" submenu

Navigation Diagnostics → Diag. settings → Properties

▶ Properties

Alarm delay


→ 28


















Alarm delay



Navigation	Diagnostics → Diag. settings → Properties → Alarm delay
Description	Enter a duration for the alarm delay. When a diagnostic event of the "Alarm" category occurs, the diagnostic message is not generated until the delay has elapsed.
User entry	0 to 60 s


4.5.2 "Diagnostic configuration" submenu

Navigation  Diagnostics → Diag. settings → Configuration

► Diagnostic configuration	
► Electronics	→  29
Assign behavior of diagnostic no. 376	→  30
► Configuration	→  30
Assign behavior of diagnostic no. 443	→  30
► Process	→  31
Assign behavior of diagnostic no. 832	→  32
Assign behavior of diagnostic no. 833	→  32
Assign behavior of diagnostic no. 842	→  33
Assign behavior of diagnostic no. 938	→  33
Assign behavior of diagnostic no. 955	→  34
Assign behavior of diagnostic no. 956	→  35
Assign behavior of diagnostic no. 957	→  36
Assign behavior of diagnostic no. 958	→  36
Assign behavior of diagnostic no. 959	→  37
Assign behavior of diagnostic no. 960	→  37
Assign behavior of diagnostic no. 961	→  34
Assign behavior of diagnostic no. 962	→  35

"Electronics" submenu

Navigation  Diagnostics → Diag. settings → Diag. config. → Electronics

► Electronics	
Assign behavior of diagnostic no. 376	→  30

Assign behavior of diagnostic no. 376



Navigation Diagnostics → Diag. settings → Diag. config. → Electronics → Diagnostic no. 376

Description Select behavior for diagnostic event "376 Main electronics faulty".


- Selection**
- Off
 - Alarm
 - Warning
 - Logbook entry only

Additional information *Selection*

- **Off** option
The diagnostic event is ignored and no diagnostic message is generated or logged.
- **Alarm** option
The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated.
- **Warning** option
The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated.
- **Logbook entry only** option
The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

"Configuration" submenu

Navigation Diagnostics → Diag. settings → Diag. config. → Configuration



Assign behavior of diagnostic no. 443



Navigation Diagnostics → Diag. settings → Diag. config. → Configuration → Diagnostic no. 443

Description Select behavior for diagnostic event "443 Pulse output faulty".

- Selection**
- Off
 - Alarm
 - Warning
 - Logbook entry only

Additional information

Selection

- **Off** option
The diagnostic event is ignored and no diagnostic message is generated or logged.
- **Alarm** option
The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated.
- **Warning** option
The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated.
- **Logbook entry only** option
The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

"Process" submenu

Navigation



Diagnostics → Diag. settings → Diag. config. → Process

▶ Process

Assign behavior of diagnostic no. 832	→ 32
Assign behavior of diagnostic no. 833	→ 32
Assign behavior of diagnostic no. 842	→ 33
Assign behavior of diagnostic no. 938	→ 33
Assign behavior of diagnostic no. 955	→ 34
Assign behavior of diagnostic no. 956	→ 35
Assign behavior of diagnostic no. 957	→ 36
Assign behavior of diagnostic no. 958	→ 36
Assign behavior of diagnostic no. 959	→ 37
Assign behavior of diagnostic no. 960	→ 37
Assign behavior of diagnostic no. 961	→ 34
Assign behavior of diagnostic no. 962	→ 35

Assign behavior of diagnostic no. 832


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 832
Description	Select behavior for diagnostic event "832 Electronics temperature too high".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 833


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 833
Description	Select behavior for diagnostic event "833 Electronics temperature too low".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 842


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 842
Description	Select behavior for diagnostic event "842 Process value above limit".
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ▪ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ▪ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ▪ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 938


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 938
Description	Select behavior for diagnostic event "938 EMC interference".
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ▪ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ▪ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ▪ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 955


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 955
Description	Select behavior for diagnostic event "955 Flow limit exceeded".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 961


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 961
Description	Select behavior for diagnostic event "961 Electrode potential out of specification".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 962


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 962
Description	Select behavior for diagnostic event "962 Pipe empty".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 956


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 956
Description	Select behavior for diagnostic event "956 Pressure limit exceeded".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 957


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 957
Description	Select behavior for diagnostic event "957 Time-dependent flow limit exceeded".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 958


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 958
Description	Select behavior for diagnostic event "958 Time-dependent pressure limit exceeded".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

Assign behavior of diagnostic no. 959


Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 959
Description	Select behavior for diagnostic event "959 Event at status input detected"..
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.


Assign behavior of diagnostic no. 960



Navigation	Diagnostics → Diag. settings → Diag. config. → Process → Diagnostic no. 960
Description	Select behavior for diagnostic event "960 Battery lifetime is less than 180 days".
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off option The diagnostic event is ignored and no diagnostic message is generated or logged. ■ Alarm option The device stops measuring. The signal outputs and totalizers assume the specified alarm condition. A diagnostic message is generated. ■ Warning option The device continues measuring. The signal outputs and totalizers are not affected. A diagnostic message is generated. ■ Logbook entry only option The device continues measuring. The diagnostic message is only displayed in the "Event logbook" submenu and does not alternate with the standard operational information displayed.

4.6 "Tracking pointer" submenu


Navigation  Diagnostics → Tracking pointer

▶ Tracking pointer


▶ Reset minimum/maximum values →  38

▶ Electronics temperature →  38


4.6.1 "Reset minimum/maximum values" submenu

Navigation  Diagnostics → Tracking pointer → Reset values

▶ Reset minimum/maximum values

Reset min/max values →  38


Reset min/max values

Navigation  Diagnostics → Tracking pointer → Reset values → Reset min/max


Description Select the measured variable for which the minimum value and maximum value are to be reset.


Selection Cancel

4.6.2 "Electronics temperature" submenu


Navigation  Diagnostics → Tracking pointer → Electronics temp

▶ Electronics temperature


Minimum value →  39

Maximum value →  39

Minimum value

Navigation	 Diagnostics → Tracking pointer → Electronics temp → Minimum value
Description	Displays the lowest electronics temperature measured so far. Additional information: The unit of measure is specified in the "Temperature unit" parameter.
User interface	Signed floating-point number









Maximum value

Navigation	 Diagnostics → Tracking pointer → Electronics temp → Maximum value
Description	Displays the highest electronics temperature measured so far. Additional information: The unit of measure is specified in the "Temperature unit" parameter.
User interface	Signed floating-point number

5 "Application" menu






Targeted optimization to the application – comprehensive device settings from sensor technology to system integration for optimum application adaptation.

Navigation  Application


Application	
▶ Measured values	→  40
▶ System units	→  43
▶ Totalizers	→  46
▶ Sensor	→  50
▶ Status input	→  61
▶ Pulse/switch output 1 to n	→  62
▶ Data logging	→  69
▶ Measured value supervision	→  70

5.1 "Measured values" submenu


Navigation  Application → Measured values

▶ Measured values	
Volume flow	→  41
Conductivity	→  41
Flow velocity	→  41
Pressure	→  41
▶ Totalizer	→  42


Volume flow

Navigation	 Application → Measured values → Volume flow
Description	Displays the volume flow currently measured. Additional information: The applicable unit of measure is specified in the "System units" submenu.
User interface	Signed floating-point number


Conductivity

Navigation	 Application → Measured values → Conductivity
Description	Displays the conductivity currently measured. Additional information: The applicable unit of measure is specified in the "System units" submenu.
User interface	Positive floating-point number

Flow velocity


Navigation	 Application → Measured values → Flow velocity
Description	Displays the flow velocity currently measured. Additional information: The applicable unit of measure is specified in the "System units" submenu.
User interface	Signed floating-point number

Pressure


Navigation	 Application → Measured values → Pressure
Description	Displays the pressure currently measured. Additional information: The applicable unit of measure is specified in the "System units" submenu.
User interface	Signed floating-point number

5.1.1 "Totalizer" submenu

Navigation  Application → Measured values → Totalizer



Totalizer value 1 to n

Navigation  Application → Measured values → Totalizer → Totalizer val. 1 to n

Description Displays the current totalizer counter.
 Additional information:
 Since the operating tool cannot display figures with more than 7 digits, the current counter above this range equals the sum of the totalizer counter plus the overflow displayed for the "Totalizer overflow" parameter.


Example for how to calculate the current totalizer counter when the value exceeds the 7 digit display range limit of the operating tool:

- Value of "Totalizer value" parameter: 1,968,457 m³
- Value of "Totalizer overflow" parameter: 1 × 10⁷ m³ = 10,000,000 m³
- Current totalizer reading: 11,968,457 m³

In the event of an error, the totalizer behaves as specified in the "Failure mode" parameter.

User interface Signed floating-point number

Totalizer overflow 1 to n

Navigation  Application → Measured values → Totalizer → Tot. overflow 1 to n

Description Displays the current totalizer overflow.
 Additional information:
 If the current totalizer counter exceeds the operating tool's maximum numerical display range of 7 digits, the amount above this range is expressed as an overflow. The current totalizer counter therefore equals the sum of the overflow and the totalizer value displayed in the "Totalizer value" parameter.






Example of how to calculate the current totalizer counter when the value exceeds the 7 digit display limit of the operating tool:

- Value of "Totalizer value" parameter: 1,968,457 m³
- Value of "Totalizer overflow" parameter: 1 × 10⁷ m³ = 10,000,000 m³
- Current totalizer reading: 11,968,457 m³

User interface -32 000.0 to 32 000.0

5.2 "Units" submenu

Navigation  Application → Units

▶ System units	
Volume flow unit	→  43
Volume unit	→  44
Conductivity unit	→  45
Temperature unit	→  45
Pressure unit	→  45

Volume flow unit



Navigation  Application → System units → Volume flow unit

Description Select volume flow unit.

Selection

SI units

- cm³/s
- cm³/min
- cm³/h
- cm³/d
- dm³/s
- dm³/min
- dm³/h
- dm³/d
- m³/s
- m³/min
- m³/h
- m³/d
- ml/s
- ml/min
- ml/h
- ml/d
- l/s
- l/min
- l/h
- l/d
- hl/s
- hl/min
- hl/h
- hl/d
- Ml/s
- Ml/min
- Ml/h
- Ml/d

US units

- af/s
- af/min
- af/h
- af/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- MMft³/s
- MMft³/min
- MMft³/h
- Mft³/d
- fl oz/s (us)
- fl oz/min (us)
- fl oz/h (us)
- fl oz/d (us)
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- Mgal/s (us)
- Mgal/min (us)
- Mgal/h (us)
- Mgal/d (us)
- bbl/s (us;liq.)
- bbl/min (us;liq.)
- bbl/h (us;liq.)
- bbl/d (us;liq.)
- bbl/s (us;beer)
- bbl/min (us;beer)
- bbl/h (us;beer)
- bbl/d (us;beer)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- bbl/s (us;tank)
- bbl/min (us;tank)
- bbl/h (us;tank)
- bbl/d (us;tank)
- kgal/s (us)
- kgal/min (us)
- kgal/h (us)
- kgal/d (us)

Imperial units

- gal/s (imp)
- gal/min (imp)
- gal/h (imp)
- gal/d (imp)
- Mgal/s (imp)
- Mgal/min (imp)
- Mgal/h (imp)
- Mgal/d (imp)
- bbl/s (imp;beer)
- bbl/min (imp;beer)
- bbl/h (imp;beer)
- bbl/d (imp;beer)
- bbl/s (imp;oil)
- bbl/min (imp;oil)
- bbl/h (imp;oil)
- bbl/d (imp;oil)

Volume unit



Navigation

Application → System units → Volume unit

Description

Select volume unit.

Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ cm³ ■ dm³ ■ m³ ■ ml ■ l ■ hl ■ Ml Mega 	<i>US units</i> <ul style="list-style-type: none"> ■ af ■ ft³ ■ Mft³ ■ fl oz (us) ■ gal (us) ■ kgal (us) ■ Mgal (us) ■ bbl (us;oil) ■ bbl (us;liq.) ■ bbl (us;beer) ■ bbl (us;tank) 	<i>Imperial units</i> <ul style="list-style-type: none"> ■ gal (imp) ■ Mgal (imp) ■ bbl (imp;beer) ■ bbl (imp;oil)
------------------	---	--	--

Conductivity unit

Navigation Application → System units → Conductiv. unit

Description Select conductivity unit.

Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ nS/cm ■ μS/cm ■ μS/m ■ μS/mm ■ mS/m ■ mS/cm ■ S/cm ■ S/m ■ kS/m ■ MS/m
------------------	---

Temperature unit

Navigation Application → System units → Temperature unit

Description Select temperature unit.

Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ °C ■ K 	<i>US units</i> <ul style="list-style-type: none"> ■ °F ■ °R
------------------	---	--

Pressure unit

Navigation Application → System units → Pressure unit

Description Select process pressure unit.

Selection

SI units

- MPa a
- MPa g
- kPa a
- kPa g
- Pa a
- Pa g
- bar
- bar g

US units

- psi a
- psi g

5.3 "Totalizers" submenu

Navigation



Application → Totalizers

▶ Totalizers

▶ Totalizer handling → 46

▶ Totalizer 1 to n → 47

5.3.1 "Totalizer handling" submenu

Navigation



Application → Totalizers → Totalizer

▶ Totalizer handling

Reset all totalizers → 46

Reset all totalizers

Navigation



Application → Totalizers → Totalizer → Reset all tot.


Description







Reset all totalizers to "0" and restart the totaling process. All flow quantities thus far totalized are thereby deleted.

Selection

- Cancel
- Reset + totalize


5.3.2 "Totalizer 1 to n" submenu

Navigation  Application → Totalizers → Totalizer 1 to n

► Totalizer 1 to n	
Assign process variable	→  47
Unit totalizer 1 to n	→  47
Totalizer operation mode	→  48
Control Totalizer 1 to n	→  48
Preset value 1 to n	→  49
Failure mode	→  49

Assign process variable

Navigation

 Application → Totalizers → Totalizer 1 to n → Assign variable

Description

Select process variable for totalizer.

Additional information:

If the option selected is changed, the device resets the totalizer to "0".

Selection

- Off
- Volume flow

Unit totalizer 1 to n

Navigation

 Application → Totalizers → Totalizer 1 to n → Unit totalizer 1 to n

Description

Select process variable totalizer unit.

Selection

SI units

- cm³*
- dm³*
- m³*
- ml*
- l*
- hl*
- Ml Mega*

US units

- af*
- ft³*
- Mft³*
- fl oz (us)*
- gal (us)*
- kgal (us)*
- Mgal (us)*
- bbl (us;liq.)*
- bbl (us;beer)*
- bbl (us;oil)*
- bbl (us;tank)*

Imperial units

- gal (imp)*
- Mgal (imp)*
- bbl (imp;beer)*
- bbl (imp;oil)*

* Visibility depends on order options or device settings

or

Other units

None*

* Visibility depends on order options or device settings

Totalizer operation mode



Navigation

Application → Totalizers → Totalizer 1 to n → Operation mode

Description

Select totalizer calculation mode.

Selection

- Net flow total
- Forward flow total
- Reverse flow total

Additional information

Selection

- **Net flow total** option
The flow values in the forward and reverse flow directions are totalized and netted against each other. Net flow is recorded in the flow direction.
- **Forward flow total** option
Only the flow in the forward flow direction is totalized.
- **Reverse flow total** option
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Control Totalizer 1 to n

Navigation


Application → Totalizers → Totalizer 1 to n → Control Tot. 1 to n

Description


Operate the totalizer.

Selection	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Hold
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Totalize option The totalizer is started or continues running. ■ Reset + hold option The totaling process is stopped and the totalizer is reset to "0". ■ Preset + hold option The totaling process is stopped and the totalizer is set to the start value specified in the "Preset value" parameter. ■ Reset + totalize option The totalizer is reset to "0" and the totaling process is restarted. ■ Hold option Totalizing is stopped.

Preset value 1 to n

Navigation	 Application → Totalizers → Totalizer 1 to n → Preset value 1 to n
Description	Specify start value for totalizer.
User entry	Signed floating-point number

Failure mode

Navigation	 Application → Totalizers → Totalizer 1 to n → Failure mode
Description	<p>Specify how the totalizer should behave in the event of a device alarm.</p> <p>Additional information: The failsafe mode that applies to any other totalizers or outputs is specified separately in other parameters and is not impacted by this setting.</p>
Selection	<ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value






Additional information

Selection

- **Stop** option
The totalizer is stopped in the event of a device alarm.
- **Actual value** option
The totalizer continues to totalize based on the current value measured; the device alarm is ignored.
- **Last valid value** option
The totalizer continues to totalize based on the last valid value measured before the device alarm occurred.






5.4 "Sensor" submenu

Navigation  Application → Sensor

▶ Sensor		
▶ Process parameters		→  50
▶ Low flow cut off		→  52
▶ Empty pipe detection		→  53
▶ Sensor adjustment		→  56
▶ Calibration		→  59

5.4.1 "Process parameters" submenu

Navigation  Application → Sensor → Process param.

▶ Process parameters		
Flow damping		→  51
Flow damping time		→  51
Flow override		→  51
Conductivity measurement		→  52
Conductivity damping time		→  52

Flow damping
**Navigation**

Application → Sensor → Process param. → Flow damping

Description

Enter value for damping of the flow measured value in order to reduce the variability of the flow measured value when exposed to interference.

Additional information:

The depth of the flow filter is determined by this setting. As the filter depth increases, so does the reaction time of the device.

- Value = 0: No damping. Damping of 0 is not recommended, as the measuring signal is then so noisy that it is almost impossible to perform a measurement.

- Value > 0: Damping increases

Optimal damping depends on the measuring period.

Damping impacts the following measuring device variables:

- Outputs
- Low flow cut off
- Totalizers

User entry

0 to 15

Flow damping time
**Navigation**

Application → Sensor → Process param. → FlowDampingTime

Description

Enter time constant for flow damping (PT1 element).

- Value = 0: No damping

- Value > 0: Damping increases

Additional information:

Damping is implemented by means of a proportional transmission behavior with first order delay (PT1 element).

User entry

0 to 99.9 s

Flow override
**Navigation**

Application → Sensor → Process param. → Flow override

Description


Stops the measuring process. Can be used for example when cleaning the pipeline.


Selection

- Off
- On

Additional information *Selection*


"On" option
 Activates flow override. The diagnostic message "453 Flow override active" is generated.
 Additional information:
 Output values:
 - Temperature: Measurement continues
 - Totalizers 1 to 3: No longer totalize


Conductivity measurement 

Navigation  Application → Sensor → Process param. → Conduct. measur.

Description Switch conductivity measurement on or off.
 Additional information:
 To be able to measure conductivity, the medium must have a minimum conductivity of 5 µS/cm.

Selection ■ Off
 ■ On

Conductivity damping time 

Navigation  Application → Sensor → Process param. → ConductDampTime


Description Enter time constant for conductivity damping (PT1 element):
 - Value = 0: No damping
 - Value > 0: Damping increases
 Additional information:
 Damping is implemented by means of a proportional transmission behavior with first order delay (PT1 element).

User entry 0 to 999.9 s

5.4.2 "Low flow cut off" submenu

Navigation  Application → Sensor → Low flow cut off

▶ Low flow cut off

Low flow cut off
→  53

On value low flow cutoff	→ 53
Off value low flow cutoff	→ 53

Low flow cut off



- Navigation** Application → Sensor → Low flow cut off → Low flow cut off
- Description** Select process variable for low flow cut off to activate low flow cut off.
- Selection**
- Off
 - Volume flow

On value low flow cutoff



- Navigation** Application → Sensor → Low flow cut off → On value
- Description** Enter on value to switch on low flow cut off.
Value = 0: No low flow cut off
Value > 0: Low flow cut off is activated
- User entry** Positive floating-point number

Off value low flow cutoff



- Navigation** Application → Sensor → Low flow cut off → Off value
- Description** Enter off value to switch off low flow cut off. The off value is entered as a positive hysteresis with respect to the on value.
- User entry** 0 to 100.0 %

5.4.3 "Empty pipe detection" submenu

Navigation Application → Sensor → Empty pipe det.

▶ Empty pipe detection	
Empty pipe detection	→ 54

Switch point empty pipe detection	→ 54
New adjustment	→ 54
Progress	→ 55
Empty pipe adjust value	→ 55
Full pipe adjust value	→ 55
Measured value EPD	→ 55

Empty pipe detection

Navigation	Application → Sensor → Empty pipe det. → Empty pipe det.
Description	Switch empty pipe detection on or off. Switch on empty pipe detection to detect a partially filled or empty measuring tube.
Selection	<ul style="list-style-type: none"> ■ Off ■ On


Switch point empty pipe detection

Navigation	Application → Sensor → Empty pipe det. → Switch point EPD
Description	Enter hysteresis in % below which the measuring tube will be detected as empty.
User entry	0 to 100 %

New adjustment


Navigation	Application → Sensor → Empty pipe det. → New adjustment
Description	<p>Select empty pipe or full pipe adjustment to perform a new adjustment. To adjust empty pipe detection, perform the empty pipe adjustment first and then the full pipe adjustment.</p> <p>Additional information: The measuring device is pre-adjusted at production using water (approx. 300 µS/cm). For liquids that deviate from this conductivity, a new empty pipe and full pipe adjustment must be performed on site.</p>
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Empty pipe adjust ■ Full pipe adjust

Progress


Navigation	 Application → Sensor → Empty pipe det. → Progress
Description	Shows the progress of the process.
User interface	<ul style="list-style-type: none"> ■ Ok ■ Busy ■ Not ok


Empty pipe adjust value




Navigation	 Application → Sensor → Empty pipe det. → Empty pipe value
Description	<p>Displays adjustment value when the measuring tube is empty.</p> <p>NOTE Users logged on in the Service role have write access!</p>
User interface	Positive floating-point number

Full pipe adjust value











Navigation	 Application → Sensor → Empty pipe det. → Full pipe value
Description	<p>Displays adjustment value when the measuring tube is full.</p> <p>NOTE Users logged on in the Service role have write access!</p>
User interface	Positive floating-point number

Measured value EPD


Navigation	 Application → Sensor → Empty pipe det. → Meas. value EPD
Description	Displays the value currently measured for empty pipe detection.
User interface	Positive floating-point number

5.4.4 "Sensor adjustment" submenu

Navigation  Application → Sensor → Sensor adjustm.

► Sensor adjustment	
Installation direction	→  56
Integration time	→  56
Measuring period	→  57
Measuring interval mode	→  57
Current measuring interval	→  57
Measuring interval value	→  58
Energy budget intelligent adaption	→  58
Factor pressure measuring interval	→  58


Installation direction

Navigation  Application → Sensor → Sensor adjustm. → Install. direct.

Description Select sign of flow direction




- Selection
- Forward flow
 - Reverse flow

Integration time

Navigation  Application → Sensor → Sensor adjustm. → Integration time

Description Displays the duration of an integration cycle.
NOTE
Users logged on in the Service role have write access!

User interface 1 to 65 ms

Measuring period	
Navigation	 Application → Sensor → Sensor adjustm. → Measuring period
Description	<p>Displays the duration of a full measuring period.</p> <p>Additional information: The measuring period is the time span during which the excitation of the magnetic field takes place and a measuring point is created.</p> <p>NOTE Users logged on in the Service role have write access!</p>
User interface	0 to 1 000 ms
Measuring interval mode	
Navigation	 Application → Sensor → Sensor adjustm. → MeasurIntervMod
Description	Select measuring interval mode. The measuring interval is the time span between two measuring periods.
Selection	<ul style="list-style-type: none"> ■ Fixed value ■ Intelligent adaptation
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Fixed value option The measuring interval is specified in the "Measuring interval value" parameter. This option is recommended to optimize battery lifetime. ■ Intelligent adaptation option Under normal process conditions, the measuring device measures according to the measuring interval specified in the "Measuring interval value" parameter. If the process conditions change, the measuring device measures in shorter intervals according to the usage rate specified in the "Energy budget intelligent adaption" parameter. This option is recommended to optimize the measuring result.
Current measuring interval	
Navigation	 Application → Sensor → Sensor adjustm. → Cur.meas.interv.
Description	Shows the measuring interval currently used.
User interface	Positive floating-point number

Measuring interval value**Navigation**

 Application → Sensor → Sensor adjustm. → Meas.interv.val.

Description

Enter the value for the measuring interval.

Additional information:

To increase battery life, set as long an interval as possible. To optimize the measuring result, set as short an interval as possible.

User entry

0 to 60 s

Energy budget intelligent adaption**Navigation**

 Application → Sensor → Sensor adjustm. → Energy budget

Description

Set the energy budget.

Additional information:

- Value = 100%: Energy budget usage is maximized. The measuring device adapts the measuring interval to flow changes frequently.

- Value = 50%: Mean energy budget usage. The measuring device adapts the measuring interval to flow changes at a frequency that requires half as much energy as when usage of the energy budget is maximized.

- Value = 1%: Low energy budget usage. The measuring device does not frequently adapt the measuring interval to flow changes.

NOTE

The higher the energy budget usage, the shorter the battery life span!

User entry

1 to 100 %

Factor pressure measuring interval**Navigation**

 Application → Sensor → Sensor adjustm. → FactMeasurInterv

Description

Enter factor for pressure measuring interval as a multiple of the measuring interval. To increase battery life, enter as large of a factor as possible.

Example:

"Measuring interval value" parameter value = 15 s

"Factor pressure measuring interval" parameter value = 10





Pressure measuring interval = 150 s

User entry


0 to 65 535

5.4.5 "Calibration" submenu


Navigation  Application → Sensor → Calibration

▶ Calibration	
Nominal diameter	→  59
Calibration factor	→  59
Zero point	→  59
Conductivity calibration factor	→  60


Nominal diameter

Navigation	 Application → Sensor → Calibration → Nominal diameter
Description	Shows the nominal diameter of the sensor.
User interface	Character string comprising numbers, letters and special characters (#20)

Calibration factor

Navigation	 Application → Sensor → Calibration → Cal. factor
Description	Displays the current calibration factor for the flow rate measuring sensor. Additional information: The factory setting for the calibration factor can be found on the sensor's nameplate.
User interface	Positive floating-point number

Zero point

Navigation	 Application → Sensor → Calibration → Zero point
Description	Displays the zero point correction value for the sensor. NOTE Users logged on in the Service role have write access!
User interface	Signed floating-point number


Conductivity calibration factor



Navigation	☰ Application → Sensor → Calibration → Cond. cal. fact.
Description	Displays calibration factor for conductivity measurement. NOTE Users logged on in the Service role have write access!
User interface	0.01 to 10 000

5.4.6 "Supervision" submenu

Navigation ☰ Application → Sensor → Supervision



Conductivity


Navigation	☰ Application → Sensor → Supervision → Conductivity
Description	Displays the conductivity currently measured. Additional information: The applicable unit of measure is specified in the "System units" submenu.
User interface	Positive floating-point number

Process pressure

Navigation	☰ Application → Sensor → Supervision → Process pressure
Description	Displays the currently measured process pressure.
User interface	Signed floating-point number

5.4.7 "Properties" submenu

Navigation  Application → Sensor → Properties



EPD electrode existing

Navigation  Application → Sensor → Properties → EPD electrode


Description Shows whether the empty pipe detection electrode exists.

User interface

- No
- Yes

5.5 "Status input" submenu

Navigation  Application → Status input



Assign status input

Navigation  Application → Status input → Assign stat.inp.

Description Assign a function to the status input.
 Additional information:
 Ensure the "Off" option is selected, before enabling the measuring device for custody transfer.

Selection

- Off
- Reset totalizer 1
- Reset totalizer 2

- Reset totalizer 3
- Reset all totalizers
- Generate logbook entry

Additional information

Selection

"Generate logbook entry" option

If the condition of the status input changes, a logbook entry is created.

Value status input

Navigation

☰ Application → Status input → Val.stat.inp.

Description

Indicates the current input signal level.

Additional information:

When a voltage is applied to the status input, the signal level indicates "High". Otherwise it indicates "Low".

User interface

- High
- Low

Response time status input



Navigation

☰ Application → Status input → Response time

Description

Specify the minimum amount of time the input signal level must be present before the selected function is triggered.

User entry

50 to 200 ms

5.6 "Pulse/switch output 1 to n" submenu













Configuring the pulse/frequency/switch output

Navigation

☰ Application → Pulse/switch 1 to n

▶ Pulse/switch output 1 to n

Operating mode	→ ☰ 63
Assign pulse output 1 to n	→ ☰ 64
Measuring mode	→ ☰ 64

Switch output function	→  65
Assign diagnostic behavior	→  65
Assign limit	→  66
Assign status	→  66
Value per pulse	→  66
Pulse width	→  67
Failure mode	→  67
Switch-on value	→  68
Switch-off value	→  68
Failure mode	→  68
Assign flow direction check	→  69
Switch state 1 to n	→  69

Operating mode

Navigation

 Application → Pulse/switch 1 to n → Operating mode

Description


Set the output mode to pulse or switch.

Selection


- Pulse
- Switch

Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Pulse option Quantitatively proportional pulse with pulse width to be configured. Whenever a specific volume has been reached (pulse value), a pulse is emitted, the duration of which is set within the "Pulse width" parameter. ▪ Switch option Indicates when the state of the device changes, e.g. when a specified limit value is reached. Additional information: <ul style="list-style-type: none"> - The switch output can be in one of two states: either it is conductive or it is non-conductive. - When the function assigned to the switch output is triggered, the switch output will depending on the output configuration either be continuously conductive or continuously non-conductive or, in case of battery-operated devices, it will emit a pulse, i.e. the switch output will be closed and conductive for the duration of the pulse. - The switch output is used to display diagnostic information at the system level, e. g. by connecting a lamp that lights up when the function assigned is triggered.
-------------------------------	--

Assign pulse output 1 to n

Navigation	 Application → Pulse/switch 1 to n → Assign pulse 1 to n
Description	Select process variable for pulse output.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow

Measuring mode

Navigation	 Application → Pulse/switch 1 to n → Measuring mode
Description	Select measuring mode for pulse output.
Selection	<ul style="list-style-type: none"> ▪ Forward flow ▪ Forward/Reverse flow ▪ Reverse flow
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Forward flow option For positive flow a pulse is emitted, for negative flow not. ▪ Forward/Reverse flow option For both positive and negative flow a pulse is emitted (absolute value), whereby no distinction is made between positive and negative flow. ▪ Reverse flow option For negative flow a pulse is emitted, for positive flow not.

Switch output function
**Navigation**

Application → Pulse/switch 1 to n → Switch out funct

Description

Assign a function to the switch output.

Additional information:

- The state of the switch output (on or off) when the assigned function is triggered can be inverted in the "Invert output signal" parameter
- The "Invert output signal" parameter is not available for all devices.

Selection

- Off
- On
- Diagnostic behavior
- Limit
- Flow direction check
- Status

Additional information

Selection

- **Off** option
The switch output is permanently switched off (open, non-conductive).
- **On** option
The switch output is permanently switched on (closed, conductive).
- **Diagnostic behavior** option
Emits a pulse if there is a pending diagnostic event of the assigned behavioral category.
- **Limit** option
Emits a pulse if a limit value specified for the process variable has been reached.
- **Flow direction check** option
Emits a pulse when the flow direction changes.
- **Status** option
Emits a pulse to indicate the device status for empty pipe detection or low flow cut off, whichever option is assigned to the switch output.

Assign diagnostic behavior
**Navigation**

Application → Pulse/switch 1 to n → Assign diag. beh

Description

Select the diagnostic behavior for which the switch output should emit a pulse.







Selection

- Alarm
- Alarm or warning
- Warning


Additional information


Selection

- **Alarm** option
The switch output only emits a pulse for diagnostic events of the "Alarm" category.
- **Alarm or warning** option
The switch output emits a pulse for diagnostic events of the "Alarm" or "Warning" category.
- **Warning** option
The switch output only emits a pulse for diagnostic events of the "Warning" category.


Assign limit 	
Navigation	 Application → Pulse/switch 1 to n → Assign limit
Description	Select the process variable to monitor in case the specified limit value is exceeded. If a limit value for the selected process variable is exceeded, the output emits a pulse.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Flow velocity ■ Conductivity* ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Pressure* ■ Battery state of charge
Assign status 	
Navigation	 Application → Pulse/switch 1 to n → Assign status
Description	Select the device status to display for the switch output. Additional information: If the switch on point for empty pipe detection / low flow cut off is reached, the output is conductive. Otherwise, the switch output is non-conductive.
Selection	<ul style="list-style-type: none"> ■ Empty pipe detection ■ Low flow cut off
Value per pulse 	
Navigation	 Application → Pulse/switch 1 to n → Value per pulse
Description	Enter the measured value to which a pulse corresponds. Additional information: Weighting of the pulse output with a quantity. The lower the pulse value, the – better the resolution. – higher the frequency of the pulse response.
User entry	Signed floating-point number

* Visibility depends on order options or device settings


Pulse width	
Navigation	 Application → Pulse/switch 1 to n → Pulse width
Description	<p>Specify the duration of the output pulse.</p> <p>Additional information: The maximum pulse rate is defined by $f_{max} = 1 / (2 \times \text{pulse width})$. The interval between two pulses (P) is at least as long as the specified pulse width (B). The maximum flow is defined by $Q_{max} = f_{max} \times \text{pulse value}$. If the flow exceeds these limit values, the measuring device displays the diagnostic message "443 Pulse output faulty".</p> <p>Example: - Pulse value: 0.1 g - Pulse width: 0.1 ms - $f_{max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$ - $Q_{max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$</p>
User entry	0.1 to 500 ms
Failure mode	

Navigation	 Application → Pulse/switch 1 to n → Failure mode
Description	<p>Specify how the output should behave in the event of a device alarm.</p> <p>Additional information: For safety reasons, it is recommended that the behavior of the output in the event of a device alarm be predefined.</p>
Selection	<ul style="list-style-type: none"> ▪ Actual value ▪ No pulses
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Actual value option In the event of a device alarm, the pulse output continues based on the current flow measurement. The issue is ignored. Additional information: A device alarm indicates a serious malfunction of the measuring device that may impact the measurement quality to the point that accuracy can no longer be ensured. This option is only recommended if the necessary safeguards are in place to ensure that no alarm condition can impact the measurement quality. ▪ No pulses option In the event of a device alarm, the pulse output is switched off.


Switch-on value 

Navigation	 Application → Pulse/switch 1 to n → Switch-on value
Description	Enter limit value for the switch-on point (process variable > switch-on value = closed, conductive). Additional information: To use a hysteresis: Switch-on point > Switch-off point.
User entry	Signed floating-point number

Switch-off value 

Navigation	 Application → Pulse/switch 1 to n → Switch-off value
Description	Enter limit value for the switch-off point (process variable < switch-off value = open, non-conductive). Additional information: To use a hysteresis: Switch-on point > Switch-off point.
User entry	Signed floating-point number

Failure mode 

Navigation	 Application → Pulse/switch 1 to n → Failure mode
Description	Specify how the output should behave in the event of a device alarm. Additional information: For safety reasons, it is recommended that the behavior of the output in the event of a device alarm be predefined.
Selection	<ul style="list-style-type: none"> ▪ Actual status ▪ Open ▪ Closed
Additional information	<i>Selection</i> <ul style="list-style-type: none"> ▪ Actual status option In the event of a device alarm, the issue is ignored and the switch output adopts the behavior currently specified for the "Switch output function" parameter. ▪ Open option In the event of a device alarm, the switch output's transistor is set to "non-conductive".

Assign flow direction check



Navigation	Application → Pulse/switch 1 to n → Assign dir.check
Description	Select process variable for flow direction monitoring.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow

Switch state 1 to n

Navigation	Application → Pulse/switch 1 to n → Switch state 1 to n
Description	Indicates the current switch output status.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none"> ▪ Open option The switch output is not conductive. ▪ Closed option The switch output is conductive.

5.7 "Custody transfer" submenu



For detailed information on the parameter descriptions for "custody transfer", see the Special Documentation for the device

5.8 "Data logging" submenu

Navigation Application → Data logging

▶ Data logging

Log interval	→ 70
Reference time log interval	→ 70

Log interval



Navigation Application → Data logging → Log interval

Description Select the interval at which to log measured values.

- Selection**
- 15 seconds
 - 30 seconds
 - 1 minute
 - 5 minutes
 - 10 minutes
 - 15 minutes
 - 30 minutes
 - 1 hour
 - 2 hours
 - 4 hours
 - 6 hours
 - 12 hours
 - 24 hours

Reference time log interval



Navigation Application → Data logging → IntervalRefTime

Description Enter the reference time to which the log interval for data logging refers. Data is logged at this time. Additional information: The measured value log entry times (3) derive from the reference time specified (1) and the log interval (2).

User entry Positive integer

5.9 "Measured value supervision" submenu

Navigation Application → MeasValSupervis.

▶ **Measurement value supervision**

Maximum flow limit	→ 71
Minimum flow limit	→ 71
Maximum pressure limit	→ 71
Minimum pressure limit	→ 72
Maximum flow limit time span	→ 72

Minimum flow limit time span	→ 72
Maximum pressure limit time span	→ 72
Minimum pressure limit time span	→ 73
Start time	→ 73
End time	→ 73

Upper flow limit value



Navigation	Application → MeasValSupervis. → Upper flow limit
Description	Enter the upper flow limit value to monitor the flow. If the flow is greater than the specified limit value, the measuring device generates a diagnostic message.
User entry	Signed floating-point number

Lower flow limit value







Navigation	Application → MeasValSupervis. → Lower flow limit
Description	Enter the lower flow limit value to monitor the flow. If the flow is less than the specified limit value, the measuring device generates a diagnostic message.
User entry	Signed floating-point number

Upper pressure limit value




Navigation	Application → MeasValSupervis. → UppPressureLimit
Description	Enter the upper pressure limit value to monitor the pressure. If the pressure is higher than the specified limit value, the measuring device generates a diagnostic message.
User entry	Positive floating-point number

Lower pressure limit value	
Navigation	 Application → MeasValSupervis. → LowPressureLimit
Description	Enter the lower pressure limit value to monitor the pressure. If the pressure is lower than the specified limit value, the measuring device generates a diagnostic message.
User entry	Positive floating-point number
Time-dependent upper flow limit value	
Navigation	 Application → MeasValSupervis. → TimedepUpperFlow
Description	Enter an upper flow limit value to monitor the flow for the specified time span. If the flow within the specified time span is greater than the specified limit value, the measuring device generates a diagnostic message. Additional information: The applicable time period is specified using the "Start time time-dependent limit values" and the "End time time-dependent limit values" parameters.
User entry	Signed floating-point number
Time-dependent lower flow limit value	
Navigation	 Application → MeasValSupervis. → TimedepLowerFlow
Description	Enter a lower flow limit value to monitor the flow for the specified time span. If the flow within the specified time span is less than the specified limit value, the measuring device generates a diagnostic message. Additional information: The applicable time period is specified using the "Start time time-dependent limit values" and the "End time time-dependent limit values" parameters.
User entry	Signed floating-point number
Time-depen. upper pressure limit value	
Navigation	 Application → MeasValSupervis. → TimedepUppPress
Description	Enter an upper pressure limit value to monitor the pressure for the specified time span. If the pressure within the specified time span is higher than the specified limit value, the measuring device generates a diagnostic message. Additional information: The applicable time period is specified using the "Start time time-dependent limit values" and the "End time time-dependent limit values" parameters.

User entry Positive floating-point number

Time-depen. lower pressure limit value

Navigation  Application → MeasValSupervis. → TimedepLowPress


Description Enter the lower pressure limit value to monitor the pressure for the specified time span. If the pressure within the specified time span is lower than the specified limit value, the measuring device generates a diagnostic message.

Additional information:

The applicable time period is specified using the "Start time time-dependent limit values" and the "End time time-dependent limit values" parameters.

User entry Positive floating-point number

Start time time-dependent limit values

Navigation  Application → MeasValSupervis. → StartTime limits

Description Enter the start time for the time period that applies to the time-dependent flow and pressure limit values.

User entry Positive integer

End time time-dependent limit values

Navigation  Application → MeasValSupervis. → End time limits










Description Enter the end time for the time period that applies to the time-dependent flow and pressure limit values.

User entry Positive integer


6 "System" menu





Overall device management and security settings – management of system settings and adaption to operational requirements.




Navigation  System

System	
▶ Device management	→  74
▶ User management	→  77
▶ Connectivity	→  79
▶ Date/time	→  80
▶ Geolocation	→  82
▶ Power management	→  83
▶ Information	→  85
▶ Display	→  90
▶ Software configuration	→  93

6.1 "Device management" submenu

Navigation  System → Device manag.

▶ Device management	
Device tag	→  75
Locking status	→  75
Configuration counter	→  75
Device reset	→  76

Device tag	
Navigation	 System → Device manag. → Device tag
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
User entry	Character string comprising numbers, letters and special characters (#32)
Locking status	
Navigation	 System → Device manag. → Locking status
Description	Indicates the write protection with the highest priority that is currently active.
User interface	<ul style="list-style-type: none"> ■ Hardware locked ■ CT active - defined parameters ■ CT active - all parameters ■ Temporarily locked
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none"> ■ Hardware locked option The DIP switch for the hardware lock is enabled. As a result write access to the parameters is locked. ■ Temporarily locked option Due to internal procedures that are currently in progress (e.g. data upload/download, reset, etc.), write access to the parameters is temporarily locked. The parameters can be modified again, once the internal procedures are complete.
Configuration counter	
Navigation	 System → Device manag. → Config. counter
Description	<p>Displays the counter for changes to the device parameters.</p> <p>Additional information:</p> <ul style="list-style-type: none"> - If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions. - When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset. - Once the counter has reached the value 65535, it restarts at 0.
User interface	0 to 65 535

Device reset
**Navigation**

System → Device manag. → Device reset

Description

Reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery settings
- Restart device
- Restore S-DAT backup *
- Shut down device
- Create T-DAT backup
- Restore T-DAT backup *

Additional information

Selection





- **To delivery settings** option
Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting.
- **Restart device** option
The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
- **Delete powerfail data** option
Deletes the powerfail data segment in the T-DAT or (if applicable) the T-DAT partition of the S-DAT.
Additional information:
This function resolves the following memory content error: "283 Memory content inconsistent" with Service ID 225 and Service ID 721.
- **Delete T-DAT** option
Deletes the T-DAT or (if applicable) the T-DAT partition of the S-DAT. On performing this delete operation, all parameters on the T-DAT are reset to the default values.
Additional information:
This function can be used to resolve any memory content issue on the T-DAT.
NOTE
The powerfail data and device delivery settings will no longer be available on performing this delete operation!
- **Reset faulty parameters** option
Resets all faulty parameters to default values when the following memory content error occurs: "283 Memory content inconsistent" with Service ID 367.
Additional information:
Only faulty parameters are reset. All parameters that are reset are logged in the logbook.

* Visibility depends on order options or device settings


- **Delete delivery settings** option
 Deletes the delivery settings on the T-DAT or (if applicable) T-DAT partition of the S-DAT.
 Additional information:
 This function resolves the following memory content error: "311 Sensor electronics (ISEM) faulty" with Service ID 226.
 NOTE
 The device delivery settings will no longer be available on performing this delete operation!
- **Restore S-DAT backup** option
 Restore the data that is saved on the S-DAT. The data record is restored from the electronics memory to the S-DAT.
- **Create T-DAT backup** option
 Create T-DAT backup.

6.2 "User management" submenu

Navigation  System → User manag.

▶ User management	
User role	→  77
Enter access code	→  78
Reset Maintenance code	→  78
▶ Define Maintenance code	→  78

User role

Navigation  System → User manag. → User role

Description Displays the role the user is currently logged on in. The role determines the user's access rights for the parameters.
 Additional information:
 - Until a Maintenance code has been set in the "Define Maintenance code" parameter, all users are automatically logged on in the Maintenance role. Once the Maintenance code has been set, all users are automatically logged on in the Operator role.
 - The access rights can be changed via the "Enter access code" parameter.

User interface

- Operator
- Maintenance
- Service
- Production
- Development

Additional information

User interface

- **Operator** option
Provides only read access to parameters.
- **Maintenance** option
Provides read and write access to parameters.
Additional information:
For some parameters, the user must be logged on in the Service role to obtain write access.
- **Service** option
Provides read and write access to Service parameters.

Enter access code

Navigation

 System → User manag. → Ent. access code

Description


For users logged on in the Operator role, enter the Maintenance code to change the access status to Maintenance and disable write protection of parameters. For users logged on in the Maintenance role, enter the Service code to change the access status to Service and enable read and write access to Service parameters.

User entry

0 to 9999

Reset Maintenance code

Navigation

 System → User manag. → Reset Maint code

Description


Enter the code provided by Endress+Hauser Technical Support to reset the Maintenance code.



User entry

Character string comprising numbers, letters and special characters (#32)

6.2.1 "Define access code" wizard

Complete this wizard to specify an access code for the Maintenance role.

Navigation  System → User manag. → Def. access code

► Define Maintenance code	
Define Maintenance code	→  79
Confirm Maintenance code	→  79

Define Maintenance code



Navigation	☰ System → User manag. → Def. Maint. code → Def. Maint. code
Description	Specify an access code that is required to obtain the access rights for the Maintenance role.
User entry	0 to 9999


Confirm Maintenance code



Navigation	☰ System → User manag. → Def. Maint. code → Conf. Maint code
Description	Confirm the access code entered for the Maintenance role.
User entry	0 to 9999


6.3 "Connectivity" submenu

Navigation ☰ System → Connectivity



6.3.1 "Bluetooth configuration" submenu

Navigation ☰ System → Connectivity → Bluetooth conf.



Bluetooth






Navigation	☰ System → Connectivity → Bluetooth conf. → Bluetooth
Description	Enable or disable Bluetooth.

- Selection**
- Enable
 - On touch
 - Not available *


6.4 "Date/time" submenu

Navigation  System → Date/time

▶ **Date/time**

Set date/time	→  80
Time format	→  80
Time zone	→  81


Set date/time

Navigation  System → Date/time → Set date/time

Description Set the date and local time. Every time the date or time is changed, a logbook entry is created.

User entry Positive integer

Time format


Navigation  System → Date/time → Time format

Description Select time format.

- Selection**
- 24 h
 - 12 h AM/PM

* Visibility depends on order options or device settings

Time zone

**Navigation** System → Date/time → Time zone**Description**






Select the time zone. Every time the time zone is changed, a logbook entry is created.

Selection*Other units*


- UTC-12:00
- UTC-11:00
- UTC-10:00
- UTC-09:30
- UTC-09:00
- UTC-08:00
- UTC-07:00
- UTC-06:00
- UTC-05:00
- UTC-04:00
- UTC-03:30
- UTC-03:00
- UTC-02:00
- UTC-01:00
- UTC 00:00
- UTC+01:00
- UTC+02:00
- UTC+03:00
- UTC+03:30
- UTC+04:00
- UTC+04:30
- UTC+05:00
- UTC+05:30
- UTC+05:45
- UTC+06:00
- UTC+06:30
- UTC+07:00
- UTC+08:00
- UTC+08:45
- UTC+09:00
- UTC+09:30
- UTC+10:00
- UTC+10:30
- UTC+11:00
- UTC+12:00
- UTC+12:45
- UTC+13:00
- UTC+14:00

6.5 "Geolocation" submenu


Navigation  System → Geolocation

▶ Geolocation		
Location description	→	 82
Longitude	→	 82
Latitude	→	 82
Altitude	→	 83
Location method	→	 83


Location description

Navigation	 System → Geolocation → Location descr.
Description	Enter a description for the location
User entry	Character string comprising numbers, letters and special characters (#32)

Longitude

Navigation	 System → Geolocation → Longitude
Description	Enter the longitude.
User entry	-180 to 180 °

Latitude

Navigation	 System → Geolocation → Latitude
Description	Enter latitude
User entry	-90 to 90 °

Altitude**Navigation**

System → Geolocation → Altitude

Description

Enter altitude

User entry

Signed floating-point number

Location method**Navigation**

System → Geolocation → Location method

Description

Select the location method.

Selection

- No fix
- GPS or Standard Positioning Service fix
- Differential GPS fix
- Precise positioning service (PPS) fix
- Real Time Kinetic (RTK) fixed solution
- Real Time Kinetic (RTK) float solution
- Estimated dead reckoning
- Manual input mode
- Simulation Mode


6.6 "Power management" submenu

Navigation


System → Power management

► Power management	
Estimated battery lifetime	→ 84
Battery charge state	→ 84
Confirm battery replacement	→ 84
Low battery diagnostic message	→ 84
Capacity battery 1	→ 85
Capacity battery 2	→ 85

Estimated battery lifetime


Navigation	 System → Power management → EstBattLifetime
Description	Displays the approx. remaining life of the batteries. If the remaining life is less than 180 days, the measuring device generates a diagnostic message for diagnostic event "960 Low battery diagnostic message". Additional information: The remaining battery life until a diagnostic message is triggered can be modified for diagnostic event "890 Battery low" in the "Battery lifetime is less than 180 days" parameter.
User interface	Positive floating-point number

Battery charge state


Navigation	 System → Power management → BattChargeState
Description	Shows the charge state of the batteries.
User interface	0 to 100 %


Confirm battery replacement



Navigation	 System → Power management → Conf. replacem.
Description	Confirm battery replacement by selecting the appropriate battery.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Battery 1 ■ Battery 2 *

Low battery diagnostic message



Navigation	 System → Power management → LowBatteryDiagn
Description	Set remaining battery life for diagnostic event "890Battery low". When this lifespan is reached, the respective diagnostic message is generated.
User entry	Positive floating-point number

* Visibility depends on order options or device settings

Capacity battery 1



Navigation	System → Power management → Capacity batt. 1
Description	Enter capacity for new battery with 100 % charge state.
User entry	Positive floating-point number

Capacity battery 2



Navigation	System → Power management → Capacity batt.2
Description	Enter capacity for new battery with 100 % charge state.
User entry	Positive floating-point number

6.7 "Information" submenu

Navigation System → Information

▶ **Information**

- ▶ Device → 85
- ▶ Electronic module → 88
- ▶ Display module → 89

6.7.1 "Device" submenu

Navigation System → Information → Device

▶ **Device**

- Serial number → 86
- Order code → 86
- Firmware version → 86
- Extended order code 1 → 87
- Extended order code 2 → 87

Extended order code 3	→ ⓘ 87
Device name	→ ⓘ 88
ENP version	→ ⓘ 88
Manufacturer	→ ⓘ 88

Serial number

Navigation

📄 System → Information → Device → Serial number

Description

Displays the serial number of the measuring device. The serial number can be used to identify the measuring device and to retrieve further information on the measuring device, such as the related documentation, via the Device Viewer or Operations app.

Additional information:

The serial number can also be found on the nameplate of the sensor and transmitter.

User interface

Character string comprising numbers, letters and special characters (#11)

Order code



Navigation

📄 System → Information → Device → Order code

Description

Displays the device order code.

Additional information:

The order code can be used for instance to order a replacement or spare device or to verify that the device features specified on the order form match the shipping note.

User interface

Character string comprising numbers, letters and special characters (#20)

Firmware version

Navigation

📄 System → Information → Device → Firmware version

Description

Displays the device firmware version installed.

User interface

Character string comprising numbers, letters and special characters (#8)

Extended order code 1

**Navigation**

System → Information → Device → Ext. order cd. 1

Description

Displays the first, second and/or third part of the extended order code. Due to character length restrictions, the extended order code is split into a maximum of 3 parameters. The extended order code indicates for each feature in the product structure the selected option, thereby uniquely identifying the device model.

Additional information:

The extended order code can also be found on the nameplate.

User interface

Character string comprising numbers, letters and special characters (#20)

Extended order code 2

**Navigation**

System → Information → Device → Ext. order cd. 2

Description

Displays the first, second and/or third part of the extended order code. Due to character length restrictions, the extended order code is split into a maximum of 3 parameters. The extended order code indicates for each feature in the product structure the selected option, thereby uniquely identifying the device model.

Additional information:

The extended order code can also be found on the nameplate.

User interface

Character string comprising numbers, letters and special characters (#20)

Extended order code 3

**Navigation**

System → Information → Device → Ext. order cd. 3

Description

Displays the first, second and/or third part of the extended order code. Due to character length restrictions, the extended order code is split into a maximum of 3 parameters. The extended order code indicates for each feature in the product structure the selected option, thereby uniquely identifying the device model.


Additional information:

The extended order code can also be found on the nameplate.


User interface

Character string comprising numbers, letters and special characters (#20)


Device name

- Navigation**  System → Information → Device → Device name
- Description** Displays the name of the transmitter.
Additional information:
The name can also be found on the transmitter's nameplate.
- User interface** Character string comprising numbers, letters and special characters (#16)

ENP version


- Navigation**  System → Information → Device → ENP version
- Description** Displays the version of the electronic nameplate (ENP).
- User interface** Character string comprising numbers, letters and special characters (#16)

Manufacturer


- Navigation**  System → Information → Device → Manufacturer
- Description** Displays the manufacturer.
- User interface** Character string comprising numbers, letters and special characters (#32)

6.7.2 "Electronic module" submenu

Navigation  System → Information → Electr. module




Firmware version

- Navigation**  System → Information → Electr. module → Firmware version
- Description** Displays the firmware version of the module.

User interface Positive integer


Build no. software

Navigation  System → Information → Electr. module → Build no. softw.

Description Displays the build number of the module firmware.

User interface 0 to 65 535


Bootloader revision


Navigation  System → Information → Electr. module → Bootloader rev.

Description Displays the bootloader revision of the module firmware.

User interface Positive integer

6.7.3 "Display module" submenu

Navigation  System → Information → Display module




Firmware version

Navigation  System → Information → Display module → Firmware version


Description Displays the firmware version of the module.

User interface Positive integer

Build no. software











Navigation	 System → Information → Display module → Build no. softw.
Description	Displays the build number of the module firmware.
User interface	0 to 65 535

Bootloader revision

Navigation	 System → Information → Display module → Bootloader rev.
Description	Displays the bootloader revision of the module firmware.
User interface	Positive integer

6.8 "Display" submenu

Navigation  System → Display

► Display		
Value 1 display	→	 91
Value 2 display	→	 91
Value 3 display	→	 91
Value 4 display	→	 92
Display damping	→	 92
Brightness	→	 92
Color scheme	→	 92
Backlight	→	 93
Contrast display	→	 93
Rotation display	→	 93

Value 1 display
**Navigation**

System → Display → Value 1 display

Description

Select the measured value that is displayed first on the local display.

Additional information:

The applicable unit of measure is specified in the "System units" submenu.

Selection

- Volume flow
- Conductivity *
- Pressure *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Value 2 display
**Navigation**

System → Display → Value 2 display

Description

Select the measured value that is shown second on the local display.

Additional information:

The applicable unit of measure is specified in the "System units" submenu.

Selection

- None
- Volume flow
- Conductivity *
- Pressure *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Value 3 display
**Navigation**

System → Display → Value 3 display

Description

Select the measured value that is shown third on the local display.

Additional information:

The applicable unit of measure is specified in the "System units" submenu.


Selection

- None
- Volume flow
- Conductivity *
- Pressure *
- Totalizer 1
- Totalizer 2
- Totalizer 3

* Visibility depends on order options or device settings

Value 4 display



Navigation  System → Display → Value 4 display

Description Select the measured value that is shown fourth on the local display.
Additional information:
The applicable unit of measure is specified in the "System units" submenu.

Selection

- None
- Volume flow
- Conductivity *
- Pressure *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Display damping



Navigation  System → Display → Display damping

Description Enter time constant (PT1 element) to set reaction time of the display to fluctuations in the measured value.
Additional information:
- The smaller the time constant the faster the display reacts to fluctuations in the measured value.
- If the time constant is set to 0, damping is deactivated.

User entry 0.0 to 999.9 s

Brightness

Navigation  System → Display → Brightness

Description Adjust brightness.

User entry 0 to 100 %

Color scheme



Navigation  System → Display → Color scheme

Description Select preferred color scheme.

* Visibility depends on order options or device settings

Selection

- Light
- Dark

Backlight

Navigation  System → Display → Backlight

Description Switch the local display backlight on / off.

Selection

- Disable
- Enable

Contrast display

Navigation  System → Display → Contrast display

Description Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).

User entry 20 to 80 %

Rotation display

Navigation  System → Display → Rotation display


Description Select rotation angle of the display text to optimize local display readability.

Selection

- Auto
- 0 degree
- 90 degree
- 180 degree
- 270 degree

6.9 "Software configuration" submenu

Navigation  System → Software config.



Activate SW option
**Navigation**

System → Software config. → Activate SW opt.

Description

Enter application package code or code of the functionality ordered separately to activate it.

Additional information:

- If a measuring device was ordered with an add-on software option, the activation code is programmed into the measuring device ex factory.
- After entering the activation code: Check whether the new software option is displayed in the "Software option overview" parameter and therefore active.

NOTE

If an an invalid code is entered the software options that have already been activated are invalidated!

Before entering a new activation code: Create a record of the existing activation code.

User entry

Positive integer

Software option overview
Navigation

System → Software config. → SW option overv.

Description

Displays all software options included in the order ex factory or ordered at a later date that have been enabled via the operating interface.

Additional information:

If a new software option is not displayed after entering the activation code, the code entered was inaccurate or invalid. In this case, contact the appropriate Endress+Hauser sales organization to activate the software option.

User interface

- Extended data logger
- Heartbeat Verification
- Custody transfer
- Heartbeat Monitoring

Index

A

Activate SW option (Parameter)	94
Active diagnostics (Submenu)	21
Actual diagnostics (Parameter)	21
Alarm delay (Parameter)	28
Altitude (Parameter)	83
Application (Menu)	40
Assign behavior of diagnostic no. 376 (Parameter)	30
Assign behavior of diagnostic no. 443 (Parameter)	30
Assign behavior of diagnostic no. 832 (Parameter)	32
Assign behavior of diagnostic no. 833 (Parameter)	32
Assign behavior of diagnostic no. 842 (Parameter)	33
Assign behavior of diagnostic no. 938 (Parameter)	33
Assign behavior of diagnostic no. 955 (Parameter)	34
Assign behavior of diagnostic no. 956 (Parameter)	35
Assign behavior of diagnostic no. 957 (Parameter)	36
Assign behavior of diagnostic no. 958 (Parameter)	36
Assign behavior of diagnostic no. 959 (Parameter)	37
Assign behavior of diagnostic no. 960 (Parameter)	37
Assign behavior of diagnostic no. 961 (Parameter)	34
Assign behavior of diagnostic no. 962 (Parameter)	35
Assign diagnostic behavior (Parameter)	16, 65
Assign flow direction check (Parameter)	69
Assign limit (Parameter)	16, 66
Assign process variable (Parameter)	10, 47
Assign pulse output 1 to n (Parameter)	14, 64
Assign simulation process variable (Parameter)	26
Assign status (Parameter)	17, 66
Assign status input (Parameter)	61

B

Backlight (Parameter)	93
Battery charge state (Parameter)	84
Bluetooth (Parameter)	79
Bluetooth configuration (Submenu)	79
Bootloader revision (Parameter)	89, 90
Brightness (Parameter)	92
Build no. software (Parameter)	89, 90

C

Calibration (Submenu)	59
Calibration factor (Parameter)	59
Capacity battery 1 (Parameter)	85
Capacity battery 2 (Parameter)	85
Color scheme (Parameter)	92
Commissioning (Wizard)	6
Conductivity (Parameter)	41, 60
Conductivity calibration factor (Parameter)	60
Conductivity damping time (Parameter)	52
Conductivity measurement (Parameter)	52
Configuration (Submenu)	29, 30
Configuration counter (Parameter)	75
Confirm battery replacement (Parameter)	84
Connectivity (Submenu)	79
Contrast display (Parameter)	93
Control Totalizer 1 to n (Parameter)	48

Current measuring interval (Parameter)	57
--	----

D

Data logging (Submenu)	69
Date/time (Submenu)	80
Define access code (Wizard)	78
Device (Submenu)	85
Device alarm simulation (Parameter)	27
Device information (Menu)	20
Device management (Submenu)	74
Device name (Parameter)	8, 88
Device reset (Parameter)	76
Device tag (Parameter)	7, 75
Diagnostic event category (Parameter)	27
Diagnostic event simulation (Parameter)	28
Diagnostic list (Submenu)	23
Diagnostic settings (Submenu)	28
Diagnostics (Menu)	21
Diagnostics 1 (Parameter)	23
Diagnostics 2 (Parameter)	24
Diagnostics 3 (Parameter)	24
Diagnostics 4 (Parameter)	24
Diagnostics 5 (Parameter)	25
Display (Submenu)	90
Display damping (Parameter)	12, 92
Display module (Submenu)	89
Document	
Function	4
Target group	4
Using the document	4
Document function	4

E

Electronic module (Submenu)	88
Electronics (Submenu)	29
Electronics temperature (Submenu)	38
Empty pipe adjust value (Parameter)	55
Empty pipe detection (Parameter)	13, 54
Empty pipe detection (Submenu)	53
End time time-dependent limit values (Parameter)	73
Energy budget intelligent adaption (Parameter)	58
ENP version (Parameter)	88
Enter access code (Parameter)	78
EPD electrode existing (Parameter)	61
Estimated battery lifetime (Parameter)	84
Extended order code 1 (Parameter)	87
Extended order code 2 (Parameter)	87
Extended order code 3 (Parameter)	87

F

Factor pressure measuring interval (Parameter)	58
Failure mode (Parameter)	12, 17, 49, 67, 68
Firmware version (Parameter)	8, 86, 88, 89
Flow damping (Parameter)	51
Flow damping time (Parameter)	51
Flow override (Parameter)	51
Flow velocity (Parameter)	41

Full pipe adjust value (Parameter) 55

G

Geolocation (Submenu) 82

Guidance (Menu) 6

I

Import / Export (Submenu) 19

Information (Submenu) 85

Installation direction (Parameter) 56

Integration time (Parameter) 56

L

Latitude (Parameter) 82

Location description (Parameter) 82

Location method (Parameter) 83

Locking status (Parameter) 75

Log interval (Parameter) 70

Longitude (Parameter) 82

Low battery diagnostic message (Parameter) 84

Low flow cut off (Parameter) 12, 53

Low flow cut off (Submenu) 52

Lower flow limit value (Parameter) 71

Lower pressure limit value (Parameter) 72

M

Manufacturer (Parameter) 88

Maximum value (Parameter) 39

Measured value EPD (Parameter) 55

Measured value supervision (Submenu) 70

Measured values (Submenu) 40

Measuring interval mode (Parameter) 57

Measuring interval value (Parameter) 58

Measuring mode (Parameter) 64

Measuring period (Parameter) 57

Menu

Application 40

Device information 20

Diagnostics 21

Guidance 6

System 74

Minimum value (Parameter) 39

N

New adjustment (Parameter) 54

Nominal diameter (Parameter) 59

O

Off value low flow cutoff (Parameter) 13, 53

On value low flow cutoff (Parameter) 13, 53

Operating mode (Parameter) 13, 63

Operating time (Parameter) 22

Operating time from restart (Parameter) 22

Order code (Parameter) 86

P

Power management (Submenu) 83

Preset value 1 to n (Parameter) 49

Pressure (Parameter) 41

Pressure unit (Parameter) 10

Previous diagnostics (Parameter) 22

Process (Submenu) 31

Process parameters (Submenu) 50

Process pressure (Parameter) 60

Process variable value (Parameter) 26

Progress (Parameter) 55

Properties (Submenu) 28, 61

Pulse output simulation 1 to n (Parameter) 26

Pulse value 1 to n (Parameter) 27

Pulse width (Parameter) 14, 67

Pulse/switch output 1 to n (Submenu) 62

R

Reference time log interval (Parameter) 70

Reset all totalizers (Parameter) 46

Reset Maintenance code (Parameter) 78

Reset min/max values (Parameter) 38

Reset minimum/maximum values (Submenu) 38

Response time status input (Parameter) 62

Rotation display (Parameter) 93

S

Sensor (Submenu) 50

Sensor adjustment (Submenu) 56

Serial number (Parameter) 8, 86

Set date/time (Parameter) 80

Simulation (Submenu) 25

Software configuration (Submenu) 93

Software option overview (Parameter) 94

Start time time-dependent limit values (Parameter) 73

Status input (Submenu) 61

Status signal (Parameter) 20

Submenu

Active diagnostics 21

Bluetooth configuration 79

Calibration 59

Configuration 29, 30

Connectivity 79

Data logging 69

Date/time 80

Device 85

Device management 74

Diagnostic list 23

Diagnostic settings 28

Display 90

Display module 89

Electronic module 88

Electronics 29

Electronics temperature 38

Empty pipe detection 53

Geolocation 82

Import / Export 19

Information 85

Low flow cut off 52

Measured value supervision 70

Measured values 40

Power management 83

Process 31

Process parameters 50

Properties	28, 61
Pulse/switch output 1 to n	62
Reset minimum/maximum values	38
Sensor	50
Sensor adjustment	56
Simulation	25
Software configuration	93
Status input	61
Supervision	60
Totalizer	42
Totalizer 1 to n	47
Totalizer handling	46
Totalizers	46
Tracking pointer	38
Units	43
User management	77
Supervision (Submenu)	60
Switch output function (Parameter)	15, 65
Switch point empty pipe detection (Parameter)	54
Switch state 1 to n (Parameter)	69
Switch-off value (Parameter)	17, 68
Switch-on value (Parameter)	16, 68
System (Menu)	74
T	
Target group	4
Temperature unit (Parameter)	10
Time format (Parameter)	80
Time zone (Parameter)	81
Time-depen. lower pressure limit value (Parameter)	73
Time-depen. upper pressure limit value (Parameter)	72
Time-dependent lower flow limit value (Parameter)	72
Time-dependent upper flow limit value (Parameter)	72
Timestamp (Parameter)	22, 23, 24, 25
Totalizer (Submenu)	42
Totalizer 1 to n (Submenu)	47
Totalizer handling (Submenu)	46
Totalizer operation mode (Parameter)	11, 48
Totalizer overflow 1 to n (Parameter)	42
Totalizer value 1 to n (Parameter)	42
Totalizers (Submenu)	46
Tracking pointer (Submenu)	38
U	
Unit totalizer 1 to n (Parameter)	11, 47
Units (Submenu)	43
Upper flow limit value (Parameter)	71
Upper pressure limit value (Parameter)	71
User management (Submenu)	77
User role (Parameter)	77
V	
Value 1 display (Parameter)	18, 91
Value 2 display (Parameter)	18, 91
Value 3 display (Parameter)	18, 91
Value 4 display (Parameter)	19, 92
Value per pulse (Parameter)	15, 66
Value status input (Parameter)	62
Volume flow (Parameter)	41
Volume flow unit (Parameter)	8
Volume unit (Parameter)	9
W	
Wizard	
Commissioning	6
Define access code	78
Z	
Zero point (Parameter)	59



71510281

www.addresses.endress.com
