

Valid as of version
PROFIBUS DP:
V 3.06.XX (Device software)
PROFIBUS PA:
V 3.06.XX (Device software)

Description of device functions

Proline t-mass 65

PROFIBUS DP/PA

Thermal Mass Flowmeter






Table of contents

| | | | | |
|-----------|---|-----------|------------------------|-----------|
| 1 | The function matrix: layout and use . . . | 4 | Index | 58 |
| 2 | Illustration of the function matrix. . . . | 5 | | |
| 3 | MEASURING VALUES | 7 | | |
| 4 | SYSTEM UNITS | 8 | | |
| 5 | Quick Setup | 12 | | |
| 5.1 | Quick Setup "Commissioning" | 14 | | |
| 5.2 | Quick Setup "Communication" | 16 | | |
| 5.3 | Quick Setup "Sensor" | 17 | | |
| 5.4 | "Gas" Quick Setup menu | 18 | | |
| 5.5 | "Pressure" Quick Setup menu | 20 | | |
| 5.6 | "Heat Flow" Quick Setup menu | 21 | | |
| 5.7 | Data backup/transmission | 23 | | |
| 6 | OPERATION. | 24 | | |
| 7 | USER INTERFACE. | 26 | | |
| 8 | TOTALIZER | 29 | | |
| 9 | COMMUNICATION. | 32 | | |
| 10 | PROCESS PARAMETER | 35 | | |
| 11 | GAS. | 38 | | |
| 12 | HEAT FLOW | 43 | | |
| 13 | SYSTEM PARAMETER. | 45 | | |
| 14 | SENSOR DATA | 46 | | |
| 15 | SUPERVISION | 50 | | |
| 16 | SIMULATION SYSTEM. | 51 | | |
| 17 | SENSOR VERSION. | 52 | | |
| 18 | AMPLIFIER VERSION | 53 | | |
| 19 | Factory settings | 54 | | |
| 19.1 | Language →  24 | 54 | | |
| 19.2 | SI units (not for USA and Canada) | 54 | | |
| 19.3 | US units (only for USA and Canada) | 56 | | |

1 The function matrix: layout and use


The function matrix is a two-level construction: the groups form one level and the groups' functions the other. The groups are the highest-level grouping of the control options for the measuring device. A number of functions is assigned to each group. You select a group in order to access the individual functions for operating and configuring the measuring device. You can find an overview of all the groups available in the table of contents on page 3 and in the graphic representation of the function matrix on page 6. On page 6 you can also find an overview of all the functions available with the page references to the specific function description. A description of the individual functions is provided on page 7 and onwards.




A0001142

2 Illustration of the function matrix

| Groups/function groups | | Functions | | | |
|------------------------|------|---------------------------|---------------------------------------|----------------------------|----------------------------|
| MEASURING VALUES | → 7 | MASS FLOW | CORRECTED VOLUME FLOW | HEAT FLOW | TEMPERATURE |
| ↓ | | | | | |
| SYSTEM UNITS | → 8 | UNIT MASS FLOW | UNIT MASS | UNIT CORRECTED VOLUME FLOW | UNIT CORRECTED VOLUME |
| ↓ | | UNIT CALORIFIC VALUE MASS | UNIT CALORIFIC VALUE CORRECTED VOLUME | UNIT HEAT FLOW | UNIT HEAT |
| | | UNIT PRESSURE | UNIT TEMPERATURE | UNIT DENSITY | UNIT LENGTH |
| Quick Setup | → 12 | QUICK SETUP COMMISSIONING | QUICK SETUP SENSOR | QUICK SETUP GAS | QUICK SETUP PRESSURE |
| ↓ | | QUICK SETUP HEAT FLOW | T-DAT SAVE/LOAD | | |
| OPERATION | → 24 | LANGUAGE | ACCESS CODE | DEFINE PRIVATE CODE | STATUS ACCESS |
| ↓ | | ACCESS CODE COUNTER | | | |
| USER INTERFACE | → 26 | ASSIGN LINE 1 | ASSIGN LINE 2 | 100% VALUE LINE 1 | 100% VALUE LINE 2 |
| ↓ | | FORMAT | DISPLAY DAMPING | CONTRAST LCD | BACKLIGHT |
| | | TEST DISPLAY | | | |
| TOTALIZER | → 29 | SELECT TOTALIZER | SUM | OVERFLOW | CHANNEL |
| ↓ | | UNIT TOTALIZER | SET TOTALIZER | PRESET TOTALIZER | MODE TOTALIZER |
| | | CYCL. CALC. TOT. | | | |
| COMMUNICATION | → 32 | TAG NAME | FIELDBUS ADDRESS | WRITE PROTECTION | SELECTION GSD |
| ↓ | | UNIT TO BUS | PROFIL VERSION | ACTUAL BAUD RATE | DEVICE ID |
| | | CHECK CONFIGURATION | BLOCK SELECTION | CHANNEL | AI1 - OUT VALUE |
| | | AI2 - OUT VALUE | AI3 - OUT VALUE | AO - DISPLAY VALUE | AO - PRESSURE VALUE |
| PROCESS PARAMETER | → 35 | PROCESS PRESSURE 1 | PROCESS PRESSURE 2 | PROCESS PRESSURE | REFERENCE PRESSURE |
| ↓ | | REFERENCE TEMPERATURE | REFERENCE DENSITY | NET CALORIFIC VALUE | GROSS CALORIFIC VALUE |
| | | MOLE % GAS 1 | ASSIGN LOW FLOW CUT OFF | ON-VALUE LOW FLOW CUT OFF | OFF-VALUE LOW FLOW CUT OFF |
| | | ZERO POINT ADJUST | INSTALLATION FACTOR | | |
| GAS | → 38 | SELECT GROUP | NUMBER OF GASES | GAS TYPE 1 | MOLE % GAS 1 |
| ↓ | | DESCRIPTION | CORRECTION FACTOR | REFERENCE DENSITY | GAS TYPE 2 to 8 |
| | | MOLE % GAS 2 to 8 | CHECK VALUES | SAVE CHANGES | |
| HEAT FLOW | → 43 | CALORIFIC VALUE TYPE | MODE 1 | HEATING VALUE 1 | MODE 2 |



3 MEASURING VALUES

| Function description, MEASURING VALUES group | |
|--|--|
|  Note! The engineering unit of the measured variable displayed here is configured in the SYSTEM UNITS group (→ 8) | |
| MASS FLOW | Description The currently measured mass flow appears on the display. Display: 5-digit floating-point number, including unit e.g. 462.87 kg/h; 731.63 lb/min |
| CORRECTED VOLUME FLOW | Description The calculated corrected volume flow appears on the display. The corrected volume flow is calculated from the measured mass flow and the reference density of the gas. Display: 5-digit floating-point number, including unit e.g. 104.97 Nm ³ /h; 110.73 Sm ³ /h; etc. |
| HEAT FLOW | Description The calculated heat flow appears on the display. Display: 5-digit floating-point number, including unit, (e.g. 175.00 kJ/h; 50.000 kBtu/h; etc.) |
| TEMPERATURE | Description The currently measured temperature appears on the display. Display: 5-digit fixed-point number, incl. unit and sign e.g. -23.4 °C, 160.0 °F, 295.4 K |

4 SYSTEM UNITS






| Function description, SYSTEM UNITS group | |
|--|--|
| UNIT MASS FLOW | <p>Description For selecting the unit required and displayed for the mass flow. The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Low flow cut off <p>The following time units can be selected: s = second, m = minute, h = hour, d = day</p> <p>Options</p> <p>SI: Gram → g/time unit Kilogram → kg/time unit Metric ton → t/time unit</p> <p>US: Ounce → oz/time unit Pound → lb/time unit Ton → ton/time unit</p> <p>Factory setting kg/h or lb/h (country dependent → 54)</p> |
| UNIT MASS | <p>Description For selecting the unit required and displayed for the mass.</p> <p>Options</p> <p>SI: Gram → g Kilogram → kg Metric ton → t</p> <p>US: Ounce → oz Pound → lb Ton → ton</p> <p>Factory setting kg or lb (country dependent → 54)</p> |
| UNIT CORRECTED VOLUME FLOW | <p>Description For selecting the unit required and displayed for the corrected volume flow. The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Low flow cut off <p>The following time units can be selected: s = second, m = minute, h = hour, d = day</p> <p>Options</p> <p>SI: Norm cubic meter → Nm³/time unit Norm liter → NI/time unit</p> <p>US: Standard cubic meter → Sm³/time unit Standard cubic feet → Sft³/time unit</p> <p>Factory setting Nm³/h or Sm³/h (country dependent → 54)</p> |

| Function description, SYSTEM UNITS group | |
|--|--|
| UNIT CORRECTED VOLUME | <p>Description For selecting the unit required and displayed for the corrected volume.</p> <p>Options SI: Norm cubic meter → Nm³ Norm liter → NI US: Standard cubic meter → Sm³ Standard cubic feet → Sft³</p> <p>Factory setting Nm³ or Sm³ (country dependent → 54)</p> |
| UNIT CALORIFIC VALUE MASS | <p>Description For selecting the unit required and displayed for the gross/net calorific value.</p> <p>Options (SI units) kJ/kg MJ/kg kWh/kg MWh/kg kcal/kg Mcal/kg</p> <p>Options (US units) Btu/lb kBtu/lb</p> <p>Factory setting MJ/kg or kBtu/lb (country dependent → 54)</p> |
| UNIT CALORIFIC VALUE CORRECTED VOLUME | <p>Description For selecting the unit required and displayed for the calorific value based on the corrected volume.</p> <p>Options (SI units): kJ/Nm³ MJ/Nm³ kWh/Nm³ MWh/Nm³ kcal/Nm³ Mcal/Nm³</p> <p>Options (US units): kJ/Sm³ MJ/Sm³ kWh/Sm³ MWh/Sm³ kcal/Sm³ Mcal/Sm³ Btu/Sft³ kBtu/Sft³</p> <p>Factory setting MJ/Nm³ or kBtu/Sft³ (country dependent → 54)</p> |

| Function description, SYSTEM UNITS group | |
|--|---|
| UNIT HEAT FLOW | <p>Description For selecting the unit required and displayed for the heat flow.</p> <p>The following time units can be selected: s = second, m = minute, h = hour, d = day</p> <p>Options (SI unit)</p> <p>kW MW kJ/time unit MJ/time unit GJ/time unit kcal/time unit Mcal/time unit Gcal/time unit</p> <p>Options (US unit)</p> <p>tons kBtu/time unit MBtu/time unit GBtu/time unit</p> <p>Factory setting kW or kBtu/h (country dependent → ⓘ 54)</p> |
| UNIT HEAT | <p>Description For selecting the unit required and displayed for the heat.</p> <p>The following time units can be selected: s = second, m = minute, h = hour, d = day</p> <p>Options (SI units)</p> <p>kWh MWh kJ MJ GJ kcal Mcal Gcal</p> <p>Options (US units)</p> <p>tonh kBtu MBtu GBtu</p> <p>Factory setting kWh or kBtu (country dependent → ⓘ 54)</p> |
| UNIT PRESSURE | <p>Description Use this function to select the unit for pressure.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Process pressure (see PROCESS PARAMETER group, → ⓘ 35) ■ Reference pressure (see PROCESS PARAMETER group, → ⓘ 35) <p>Options</p> <p>bar a (bar absolute) psi a (pound per square inch absolute) kPa a (kilopascal absolute) mmHg 0°C a (millimeter mercury absolute) inHg 32°F a (inch mercury absolute) mmH2O 4°C a (millimeter water absolute) inH2O 39°F a (inch water absolute) kg/cm2 a (kilogram per centimeter squared absolute)</p> <p>Factory setting bar a or psi a (country dependent → ⓘ 54)</p> |


| Function description, SYSTEM UNITS group | |
|--|--|
| UNIT TEMPERATURE | <p>Description For selecting the unit required and displayed for the temperature.</p> <p>Options °C (CELSIUS) K (KELVIN) °F (FAHRENHEIT) R (RANKINE)</p> <p>Factory setting °C or °F (country dependent → 54)</p> |
| UNIT DENSITY | <p>Description For selecting the unit required and displayed for the calculated gas density at process conditions. The unit you select here is also valid for: <ul style="list-style-type: none"> Reference density (see PROCESS PARAMETER group, → 35) </p> <p>Options SI: g/cm³ g/cc kg/dm³ kg/l kg/m³ US: lb/ft³</p> <p>Factory setting kg/m³ or lb/ft³ (country dependent → 54)</p> |
| UNIT LENGTH | <p>Prerequisite This function is only available for the insertion sensor (t-mass 65I)</p> <p>Description For selecting the unit of length required and displayed for the pipe internal diameter or the inner dimensions of rectangular ducts (see SENSOR DATA function group → 46).</p> <p>Options MILLIMETER INCH</p> <p>Factory setting MILLIMETER or INCH (country dependent → 54)</p> |

5 Quick Setup

| Function description, Quick Setup group | |
|---|---|
| QUICK SETUP COM-MISSIONING | <p>Description Starts the Quick Setup menu for commissioning. For a flowchart of the QUICK SETUP COMMISSIONING: →  14.</p> <p>Options NO YES</p> <p>Factory setting NO</p> |
| QUICK SETUP COM-MUNICATION | <p>Description Use this function to start the setup menu for the settings of the PROFIBUS DP communication parameters. For a flowchart of the QUICK SETUP COMMUNICATION: →  16.</p> <p>Options NO YES</p> <p>Factory setting NO</p> |
| QUICK SETUP SENSOR | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I).</p> <p>Description Use this function to start the application-specific setup to calculate the insertion depth for the insertion sensor. For a flowchart of the QUICK SETUP SENSOR: →  17.</p> <p>Options NO YES</p> <p>Factory setting NO</p> |
| QUICK SETUP GAS | <p>Description Use this function to start the application-specific setup for programming the gas or gas mixture. For a flowchart of the QUICK SETUP GAS: →  18.</p> <p>Options NO YES</p> <p>Factory setting NO</p> |
| QUICK SETUP PRES-SURE | <p>Description Use this function to start the application-specific setup for programming the process pressure for each gas group. For a flowchart of the QUICK SETUP PRESSURE: →  20</p> <p>Options NO YES</p> <p>Factory setting NO</p> |

| Function description, Quick Setup group | |
|---|--|
| <p>QUICK SETUP HEAT FLOW</p> | <p>Description Use this function to start the application-specific setup for heat flow. For a flowchart of the QUICK SETUP HEAT FLOW: → 21.</p> <p>Options NO YES</p> <p>Factory setting NO</p> |
| <p>T-DAT SAVE/LOAD</p> | <p>Description Use this function to save the configuration/settings of the transmitter to a transmitter-DAT (T-DAT), or to load a configuration from the T-DAT to the EEPROM (manual backup function). For a flowchart of the T-DAT SAVE/LOAD: → 23.</p> <p>Application examples:</p> <ul style="list-style-type: none"> ▪ After commissioning, the current measuring point parameters can be saved to the T-DAT as a backup. ▪ If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). <p>Options CANCEL SAVE (from the EEPROM to the T-DAT) LOAD (from the T-DAT to the EEPROM)</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ If the target device has an older software version, the message "TRANSM. SW-DAT" is displayed during startup. Then only the "SAVE" option is available. ▪ LOAD This option is only possible: <ul style="list-style-type: none"> – if the target device has the same software version as, or a more recent software version than, the source device or – if the T-DAT contains valid data that can be called up ▪ SAVE This function is always available. <p>Factory setting CANCEL</p> |

5.1 Quick Setup "Commissioning"



A0005458-en

Fig. 1: QUICK SETUP COMMISSIONING- menu for straightforward configuration of the major device functions



Note!

The display returns to the QUICK SETUP cell if you press the ESC key combination (ESC) during programming of a parameter anywhere in the menu. The configuration settings already made remain valid, however.

QUICK SETUP - COMMISSION

Use the $\left[\begin{smallmatrix} + \\ - \end{smallmatrix} \right]$ or $\left[\begin{smallmatrix} + \\ - \end{smallmatrix} \right]$ key at the prompt "QS-COMMISSION NO" and the device access code entry appears. Enter the device access code "65" and press $\left[\begin{smallmatrix} E \\ \end{smallmatrix} \right]$; programming is enabled. The prompt "QS-COMMISSION NO" appears. Use the $\left[\begin{smallmatrix} + \\ - \end{smallmatrix} \right]$ or $\left[\begin{smallmatrix} + \\ - \end{smallmatrix} \right]$ key to change NO to YES and press $\left[\begin{smallmatrix} E \\ \end{smallmatrix} \right]$.

LANGUAGE

Use the $\left[\begin{smallmatrix} + \\ - \end{smallmatrix} \right]$ or $\left[\begin{smallmatrix} + \\ - \end{smallmatrix} \right]$ key to select the required language and continue with $\left[\begin{smallmatrix} E \\ \end{smallmatrix} \right]$.

PRE-SETTING.

- ① Select ACTUAL SETTINGS to continue programming the device and go to the next level or select DELIVERY SETTINGS to reset the device. The device restarts and returns to the Home position.

- ACTUAL SETTINGS are the actual programmed parameters in the device

- DELIVERY SETTINGS are the programmed parameters (factory settings plus customer specific settings) originally delivered with the device

SYSTEM UNITS

Select required system unit function and carry out parameterization or select QUIT to return to the QUICK SETUP function if no further programming is required.

- ② Only units not yet configured in the current setup are available for selection in each cycle.
- ③ The YES option remains visible until all the units have been configured.
NO is the only option displayed when no further units are available.

Automatic configuration of the display


- ⑧ The "automatic parameterization of the display" option contains the following basic settings/factory settings:
 - YES: main line = MASS FLOW, additional line = TOTALIZER 1
 - NO: The existing (selected) settings remain.

Carry out another Quick Setup?

- ⑨ Select additional Quick Setups to complete commissioning or select NO to exit.

5.2 Quick Setup "Communication"

To establish cyclic data transfer, various arrangements between the PROFIBUS Master (class 1) and the slave are required which have to be taken into consideration when configuring various functions. These functions can be configured quickly and easily by means of the Communication Quick Setup. The configuration options for the parameters are explained in detail in the table that follows.



A0005459-en

Fig. 2: Quick Setup Communication


| Settings for the Communication Setup menu: | | |
|---|--|-------------------------|
| Function name | Suggested settings | Description |
| Call up through the function matrix: | | |
| Quick Setup | QUICK SETUP COMMUNICATION Quick Setup | → 12 |
| QUICK SETUP COMMUNICATION | YES | → 12 |
| Basic configuration: | | Factory setting: |
| FIELDBUS ADDRESS | 126 | → 32 |
| SELECTION GSD | MANUFACT. SPEC. | → 32 |
| UNIT TO BUS | SET UNIT | → 32 |

5.3 Quick Setup "Sensor"

It is essential that the insertion sensor is setup according to the actual pipe or duct and then installed at the calculated insertion depth. This Quick Setup guides you systematically through the procedure to setup the sensor.



Note!
The QUICK SETUP SENSOR function is not available for flanged type sensors.



A0009910-en

PIPE TYPE

- ① ■ CIRCULAR
 - in case that the pipe is of a standard type, then parameterize functions PIPE STANDARD and NOMINAL DIAMETER
 - In case that the pipe is a non-standard type, then select OTHERS in the function PIPE STANDARD and parameterize the functions WALL THICKNESS and OUTER DIAMETER.
 - The function INTERNAL DIAMETER displays the calculated internal diameter and is read only.
- RECTANGULAR
 - Enter the INTERNAL HEIGHT, INTERNAL WIDTH and WALL THICKNESS of the duct
 - Select the MOUNTING orientation of the sensor: HORIZONTAL or VERTICAL

MOUNTING SET LENGTH

- ② Enter the measured length of the mounting set (including the compression fitting).

INSERTION DEPTH


- ③ This function calculates the insertion depth value for the mounting of the sensor.

Press **E** to save settings and return to QUICK SETUP SENSOR group.

5.4 "Gas" Quick Setup menu

The device can be setup with 1 or 2 individual gas groups in memory. This means that up to 2 different gas flow streams (e.g. nitrogen and argon) can be measured in a single pipe with one flowmeter.

In the case of 2 gas groups being used, a digital input can be assigned to switch between the gas groups or, alternatively, the switch can be done manually via a function in the device software. Furthermore, a programmed gas mixture can be dynamically updated, via a signal from a gas analyzer.



A0009907-en

Programming a gas group

The device allows flexible change of the gas group parameters, independent of the original factory setup and calibration



A gas group can be programmed as:

- one single gas or
- one gas mixture (of up to 8 components)

A single gas can be:

- selected from a list of standard gases or
- setup for other suitable types of gases, such as Ozone, using manual correction factors and the option called SPECIAL GAS. This requires application evaluation at the factory - consult your Endress+Hauser sales center prior to using this function.

Setting or viewing the active gas group

Go to the function SELECT GROUP (→  39) and simply select 1 or 2 and then exit using ESC ( keys simultaneously). No save function is necessary.






Note!


This Quick Setup Gas function is not available if an in-situ calibration function has been performed on the device as the in-situ calibration curve refers to the sensor power at each recorded flow point. Therefore, the programmed gas settings become redundant.

Performing the Quick Setup



1. GAS GROUP

- Use the  or  key to select the required GAS GROUP and continue with .
- Set the ANALYZER INPUT to ON if a gas compensation input is being used
- Select the NUMBER OF GASES in the group from 1 to 8.
- select the GAS TYPE from the choose list.
- enter the MOLE % for each GAS TYPE (only if NUMBER OF GASES is 2 and more).
- The error message CHECK VALUES appears if the total mixture % does not equal 100%. Go back and check the mixture settings.

2. SAVE CHANGES?


- Select YES to save the settings in GAS GROUP 1 or 2 and activate the last gas group selected. Press  to continue or
- Select CANCEL to save the entered settings in buffer memory but not activate them for measurement. If this function is selected, then it will be necessary to come back to this gas group and save it at a later stage.
- Select DISCARD to clear the last changes and return to CONFIGURE GROUP to make new settings.

3. ANOTHER GAS GROUP?

- Select YES to continue to the CONFIGURE GROUP function. Use the  or  key to select the desired GAS GROUP and proceed as per the above instructions.
- Select NO to exit to the Quick Setup.




Note!

You can find more detailed information on the GAS GROUP in chapter GAS →  38

5.5 "Pressure" Quick Setup menu

Use this Quick Setup to program the individual process pressure for each gas group. If only one gas group is being used, then only the function PROCESS PRESSURE 1 needs to be programmed, PROCESS PRESSURE 2 can remain with default settings.



A0009908-en




Note!

- The device operates with absolute pressure only. Convert any gauge pressures to absolute pressure.
- If a pressure compensating input is being used, then the input signal value overrides the manually programmed value. The pressure input value applies to both gas groups. i.e. 2 independent pressure values are no longer possible.
- This Quick Setup Gas function is not available if an in-situ calibration function has been performed on the device as the in-situ calibration curve refers to the sensor power at each recorded flow point. Therefore, the programmed pressure settings become redundant.

5.6 "Heat Flow" Quick Setup menu

The device can calculate and output the heat of combustion of common fuel gases such as methane, natural gas, propane, butane, ethane and hydrogen. Use this Quick Setup menu to program the method used to calculate the heating value or calorific value (CV). The device can be configured to give two independent heating value outputs and totalized values. For example, the pipeline has either natural gas or propane running at separate times and the heating value is required for both gases.



Calculation mode 1 and 2

- The heating value for CALCULATION MODE 1 corresponds to the settings in the function GAS GROUP 1.
- The heating value for CALCULATION MODE 2 corresponds to the settings in the function GAS GROUP 2.



Note!

- If only one gas group is used, then leave mode 2 as default settings.
- The units of measure are selected in the SYSTEM UNITS section → 8.

Auto Gross

The gross heating value (or higher heating value) is the total heat obtained by complete combustion at constant pressure of a volume of gas in air, including the heat released by the water vapor in the combustion products (gas, air and combustion products taken at reference combustion temperature and standard pressure).

Auto Net

The net heating value (or lower heating value) is determined by subtracting the heat of vaporization of the water vapor from the higher heating value. This treats any water formed as water vapor. The energy required to vaporize the water therefore is not realized as heat.

Manual

This function allows entry of a user-specific heating value if the required value is different from the value in the following table.

| Gas | Formula | Net/lower heating value | | Gross/upper heating value | |
|-------------------|--------------------------------|-------------------------|--------|---------------------------|--------|
| | | [Mj/kg] | Btu/lb | [Mj/kg] | Btu/lb |
| Hydrogen | H ₂ | 119.91 | 51.56 | 141.78 | 60.97 |
| Ammonia | NH ₃ | 18.59 | 7.99 | 22.48 | 9.67 |
| Carbon Monoxide | CO | 10.1 | 4.34 | 10.1 | 4.34 |
| Hydrogen Sulphide | H ₂ S | 15.2 | 6.54 | 19.49 | 8.38 |
| Methane | CH ₄ | 50.02 | 21.51 | 55.52 | 23.87 |
| Ethane | C ₂ H ₆ | 47.5 | 20.43 | 51.93 | 22.33 |
| Propane | C ₃ H ₈ | 46.32 | 19.92 | 50.32 | 21.64 |
| Butane | C ₄ H ₁₀ | 45.71 | 19.66 | 49.51 | 21.29 |
| Ethylene | C ₂ H ₄ | 47.16 | 20.28 | 50.31 | 21.63 |

* According to ISO 6976:1995(E) and GPA Standard 2172-96

reference combustion temperature

The following reference temperatures are used:

| Country | reference combustion temperature |
|---|----------------------------------|
| Austria, Belgium, Denmark, Germany, Italy, Luxembourg, The Netherlands, Poland, Russia, Sweden, Switzerland | 25 °C |
| Brazil, China | 20 °C |
| France, Japan | 0 °C |
| Australia, Canada, Czech Republic, Hungary, India, Ireland, Malaysia, Mexico, South Africa, Great Britain | 15 °C |
| Slovakia | 25 °C |
| USA, Venezuela | 60 °F |

5.7 Data backup/transmission

Using the T-DAT SAVE/LOAD function, you can transfer data (device parameters and settings) between the T-DAT (exchangeable memory) and the EEPROM (device storage unit).

This is required in the following instances:

- Creating a backup: current data are transferred from an EEPROM to the T-DAT.
- Replacing a transmitter: current data are copied from an EEPROM to the T-DAT and then transferred to the EEPROM of the new transmitter.
- Duplicating data: current data are copied from an EEPROM to the T-DAT and then transferred to EEPROMs of identical measuring points.



Note!

For information on installing and removing the T-DAT see Operating Instructions BA00113D/06




Fig. 3: Data backup/transmission with T-DAT SAVE/LOAD function

A0001221-en

Information on the LOAD and SAVE options available

LOAD

Data are transferred from the T-DAT to the EEPROM.







Note!

- Any settings already saved on the EEPROM are deleted.
- This option is only available, if the T-DAT contains valid data.
- This option can only be executed if the software version of the T-DAT is the same or newer than that of the EEPROM. Otherwise, the error message "TRANSM. SW-DAT" appears after restarting and the LOAD function is then no longer available.

SAVE

Data are transferred from the EEPROM to the T-DAT

6 OPERATION

| Function description, OPERATION group | |
|---------------------------------------|---|
| LANGUAGE | <p>Description For selecting the language in which all messages are shown on the local display. If you press the  keys simultaneously at startup, the language defaults to "ENGLISH".</p> <p>Options: ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS NORSK SVENSKA SUOMI PORTUGUES POLSKI CESKI</p> <p>Factory setting country dependent →  54</p> |
| ACCESS CODE | <p>Description All data of the measuring device are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered. If you press the  operating elements in any function, the measuring device automatically goes to this function and the prompt to enter the code appears on the display (programming disabled). You can enable programming by entering the private code (factory setting = 65, see DEFINE PRIVATE CODE function (→  24)).</p> <ul style="list-style-type: none"> ■ The programming levels are disabled if you do not press the operating elements within 60 seconds following a return to the HOME position. ■ Programming can also be disabled by entering any number (other than the private code). ■ Your Endress+Hauser sales center can be of assistance if you mislay your private code. <p>User input Max. 4-digit number: 0 to 9999</p> |
| DEFINE PRIVATE CODE | <p>Description Use this function to specify the private code for enabling programming.</p> <ul style="list-style-type: none"> ■ Programming is always enabled if the code defined = 0. ■ Programming has to be enabled before the code can be changed. When programming is disabled this function cannot be edited, thus preventing others from accessing your personal code. <p>User input Max. 4-digit number: 0 to 9999</p> <p>Factory setting 65</p> |
| STATUS ACCESS | <p>Description The access status for this function matrix appears on the display.</p> <p>Display: ACCESS CUSTOMER (parameters can be modified) LOCKED (parameters cannot be modified)</p> |

| Function description, OPERATION group | |
|---------------------------------------|--|
| ACCESS CODE COUNTER | <p>Description The number of times the private and service code was entered to access the device appears on the display.</p> <p>Display: Integer</p> <p>Factory setting 0</p> |


7 USER INTERFACE

| Function description, USER INTERFACE group | |
|--|---|
| <p>ASSIGN LINE 1</p> | <p>Description For assigning a display value to the main line (top line of the local display). This value is displayed during normal operation.</p> <p>Options OFF MASS FLOW MASS FLOW IN % TEMPERATURE TOTALIZER 1 TOTALIZER 2 AI1 - OUT VALUE AI2 - OUT VALUE AI3 - OUT VALUE AO - DISPLAY VALUE AO - PRESSURE VALUE CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % HEAT FLOW HEAT FLOW IN %</p> <p>Factory setting MASS FLOW</p> |
| <p>ASSIGN LINE 2</p> | <p>Description For assigning a display value to the additional line (bottom line of the local display). This value is displayed during normal operation.</p> <p>Options OFF MASS FLOW MASS FLOW IN % MASS FLOW BARGRAPH IN % TEMPERATURE TOTALIZER 1 TOTALIZER 2 TAG NAME OPERATING/SYSTEM CONDITIONS CORRECTED VOLUME FLOW CORRECTED VOLUME FLOW IN % CORRECTED VOLUME FLOW BARGRAPH IN % AI1 - OUT VALUE AI2 - OUT VALUE AI3 - OUT VALUE AO - DISPLAY VALUE AO - PRESSURE VALUE HEAT FLOW HEAT FLOW IN % HEAT FLOW BARGRAPH IN %</p> <p>Factory setting TOTALIZER 1</p> |


| Function description, USER INTERFACE group | |
|--|--|
| 100% VALUE LINE 1 | <p>Prerequisite This function is only available if one of the following options was selected in the ASSIGN LINE 1 function (→ 26):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ HEAT FLOW IN % <p>Description Use this function to enter the flow value which should be shown on the display as the 100% value.</p> <p>User input 5-digit floating-point number</p> <p>Factory setting 10 kg/h (with mass flow) 10 Nm³/h (with corrected volume flow) 10 kW (with heat flow)</p> |
| 100% VALUE LINE 2 | <p>Prerequisite This function is only available if one of the following options was selected in the ASSIGN LINE 2 function (→ 26):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ HEAT FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % ■ HEAT FLOW BARGRAPH IN % <p>Description Use this function to enter the flow value which should be shown on the display as the 100% value.</p> <p>User input 5-digit floating-point number</p> <p>Factory setting 10 kg/h (with mass flow) 10 Nm³/h (with corrected volume flow) 10 kW (with heat flow)</p> |
| FORMAT | <p>Description For selecting the number of decimal places for the display value in the main line.</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring device is computing with more decimal places than can be shown on the display. <p>Options XXXXX. - XXXX.X - XXX.XX - XX.XXX -X.XXXX</p> <p>Factory setting X.XXXX</p> |
| DISPLAY DAMPING | <p>Description For entering a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). The setting 0 seconds switches off damping.</p> <p>User input 0 to 100 seconds</p> <p>Factory setting 3 seconds</p> |

| Function description, USER INTERFACE group | |
|--|--|
| CONTRAST LCD | <p>Description For adjusting the display contrast to suit local operating conditions.</p> <p>User input 10 to 100%</p> <p>Factory setting 50%</p> |
| BACKLIGHT | <p>Description For adjusting the background lighting to suit local operating conditions. Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark.</p> <p>User input 0 to 100%</p> <p>Factory setting 50%</p> |
| TEST DISPLAY | <p>Description Use this function to test the operability of the local display and its pixels. Test sequence:</p> <ol style="list-style-type: none"> 1. Start the test by selecting ON. 2. All pixels of the main line and additional line are darkened for minimum 0.75 seconds. 3. The main line and additional line show an "8" in each field for minimum 0.75 seconds. 4. The main line and additional line show a "0" in each field for minimum 0.75 seconds. 5. The main line and additional line show nothing (blank display) for minimum 0.75 seconds. 6. When the test is completed, the local display returns to its initial state and displays the option OFF. <p>Options OFF ON</p> <p>Factory setting OFF</p> |


8 TOTALIZER


| Function description, TOTALIZER group | |
|---------------------------------------|---|
| SELECT TOTALIZER | <p>Description For selecting the totalizer.</p> <p> Note! If the GSD PROFILE option was selected in the function SELECTION GSD → 32, only the TOTALIZER 1 option is available in this function.</p> <p>Options: TOTALIZER 1 TOTALIZER 2</p> <p>Factory setting TOTALIZER 1</p> |
| SUM | <p>Description To display the current totalizer value incl. unit.</p> <p>This function is available separately for each totalizer. The selection of the current totalizer takes place in the SELECT TOTALIZER function ().</p> <p>Display: Max. 7-digit floating-point number, including unit (e.g. 15467.04 kg)</p> |
| OVERFLOW | <p>Description The total for the totalizer's overflow aggregated since measuring commenced appears on the display.</p> <p>Total flow is represented by a floating-point number consisting of max. 7 digits. Higher numerical values (>9,999,999) can be viewed as overflows. The effective quantity is thus the total of the SUM function (→ 29) plus the value displayed in the OVERFLOW function.</p> <p>This function is available separately for each totalizer. The selection of the current totalizer takes place in the SELECT TOTALIZER function ().</p> <p>Example: Reading after 2 overflows: 2 E7 kg (= 20000000 kg) The value displayed in the SUM function = 196845.7 kg Effective total quantity = 20196845.7 kg</p> <p>Display: Integer with exponent, including unit, e.g. 2 E7 kg</p> |
| CHANNEL | <p>Description For assigning the measured variable to the totalizer.</p> <p>The totalizer is reset to 0 as soon as the selection is changed.</p> <p>This function is available separately for each totalizer. The selection of the current totalizer takes place in the SELECT TOTALIZER function ().</p> <p>Options: OFF MASS FLOW CORRECTED VOLUME FLOW HEAT FLOW</p> <p>Factory setting MASS FLOW</p> |



| Function description, TOTALIZER group | |
|---------------------------------------|--|
| UNIT TOTALIZER | <p>Description For selecting the unit for the measured variable assigned to the totalizer.</p> <p>This function is available separately for each totalizer. The selection of the current totalizer takes place in the SELECT TOTALIZER function ().</p> <p>Options (ASSIGN TOTALIZER = MASS FLOW): SI → g , kg, t US → oz, lb, ton</p> <p>Factory setting kg or lb (country dependent → 54)</p> <p>Options (ASSIGN TOTALIZER = CORRECTED VOLUME FLOW): SI → NI, Nm³ US → Sm³, Sft³</p> <p>Factory setting Nm³ or Sm³ (country dependent → 54)</p> <p>Options (ASSIGN TOTALIZER = HEAT FLOW): SI → kWh, MWh, kJ, MJ, GJ, kcal, Mcal, Gcal US → kBtu, MBtu, GBtu, tonh</p> <p>Factory setting MWh or kBtu (country dependent → 54)</p> |
| SET TOTALIZER | <p>Description Control of totalizer.</p> <p>This function is available separately for each totalizer. The selection of the current totalizer takes place in the SELECT TOTALIZER function ().</p> <p>If RESET or PRESET is selected, the totalizer is set to 0 or the preset value but it does not stop totalizing. This means, it continues totalizing immediately from the new setting. To stop the totalizer, the HOLD VALUE option must be selected in the TOTALIZER MODE function.</p> <p>Options TOTALIZE Totalizes the measured variable selected in the CHANNEL function.</p> <p>RESET Reset the totalizer to 0.</p> <p>PRESET The totalizer is set to the value defined in the PRESET TOTALIZER function.</p> <p>Factory setting TOTALIZE</p> |
| PRESET TOTALIZER | <p>Prerequisite This value is not accepted by the totalizer unless the PRESET option is selected in the SET TOTALIZER function.</p> <p>Description Specifies a start value.</p> <p>This function is available separately for each totalizer. The selection of the current totalizer takes place in the SELECT TOTALIZER function ().</p> <p>User input -99999...99999</p> <p>Factory setting 0</p> |

| Function description, TOTALIZER group | |
|---------------------------------------|---|
| MODE TOTALIZER | <p>Description For selecting the totalizing mode of the totalizer. This function is available separately for each totalizer. The selection of the current totalizer takes place in the SELECT TOTALIZER function ().</p> <p> Note! The device cannot measure any negative flow.</p> <p>Options</p> <p>BALANCE This option operates the same as the POSITIVE option.</p> <p>POSITIVE (forwards) Positive flow components only.</p> <p>NEGATIVE (backwards) The functionality of this option is not supported, because the device cannot measure any negative flow.</p> <p>HOLD VALUE The totalizer stays at the last value. No more components are totalled.</p> <p>Factory setting BALANCE</p> |
| CYCL. CALC. TOT. | <p>Description This function is used to determine if the totalizers on the local display and in the operating program (e.g. operating program "FieldCare") are updated.. Particularly in the case of time-critical applications, optimization can be carried out on totalizer function blocks which are not needed. To do this, the "OFF" option must be selected in this function. It is very important when selecting the "OFF" option that the totalizers on the local display and in the operating program (e.g. Field-Care) are no longer updated.</p> <p>Options</p> <p>ON Totalizers are always updated.</p> <p>OFF Totalizers are updated only if the relevant totalizer function block (TOTAL module or function) is configured for cyclical data transfer.</p> <p>Factory setting ON</p> |

9 COMMUNICATION

| Function description, COMMUNICATION group | |
|---|---|
| TAG NAME | <p>Description For entering a tag name for the measuring device. You can edit and read this tag name via the local display or an operating program (e.g. FieldCare).</p> <p>User input Max. 16-character text, permitted characters are: A-Z, 0-9, +, -, punctuation marks</p> <p>Factory setting "-----" (no text)</p> |
| FIELD BUS ADDRESS | <p>Description For entering the device address.</p> <p>User input 1 to 126</p> <p>Factory setting 126</p> |
| WRITE PROTECTION | <p>Description Indicates whether write access to the device via PROFIBUS (acyclical data transfer, e.g. via operating program "FieldCare") is possible. Write protection is activated and deactivated by means of a jumper on the I/O module (see Operating Instructions BA00113D/06).</p> <p>Display: OFF = write access via PROFIBUS possible ON = write access via PROFIBUS disabled</p> <p>Factory setting OFF</p> |
| SELECTION GSD | <p>Description Select the operating mode (GSD file) which should be used for cyclic communication with the PROFIBUS Master (class 1). For PROFIBUS network configuration, make sure that the right device master file (GSD file) of the measuring device is used for the selected operating mode. For more information please refer to the Operating Instructions BA00113D/06/de.</p> <p>Options MANUFACT. SPEC. The measuring device is operated with complete device functionality. GSD PROFIL The measuring device is operated in the PROFIBUS Profile mode.</p> <p>Factory setting MANUFACT. SPEC.</p> |
| UNIT TO BUS | <p>Description If this function is executed, the measured variables (AI modules) transmitted cyclically are transmitted to the PROFIBUS Master (class 1) with the system units configured in the measuring device.</p> <p> Caution! Activating this function can cause the measured variables (AI modules) transmitted to the PROFIBUS Master (class 1) to change suddenly; this, in turn, can affect subsequent control routines.</p> <p>Options OFF SET UNIT</p> |




| Function description, COMMUNICATION group | |
|---|--|
| PROFIL VERSION | <p>Description To display the profile version.</p> <p>Options 3.0</p> |
| ACTUAL BAUD RATE | <p>Description The data transmission rate with which the device is communicating appear on the display.</p> |
| DEVICE ID | <p>Description The PROFIBUS device ID appears on the display. The display depends on the options selected in the SELECTION GSD function.</p> <p>Display If MANUFACTURER SPEC. is selected:</p> <ul style="list-style-type: none"> ■ PROFIBUS DP communication output = 1545 Hex ■ PROFIBUS PA communication output = 1550 Hex <p>bei der Auswahl GSD PROFIL:</p> <ul style="list-style-type: none"> ■ PROFIBUS DP communication output = 9740 Hex ■ PROFIBUS PA communication output = 9740 Hex |
| CHECK CONFIGURATION | <p>Description Indicates whether the configuration for cyclic data transmission of the PROFIBUS master (class 1) was accepted by the measuring device.</p> <p>Options ACCEPTED (configuration accepted) NOT ACCEPTED (configuration not accepted)</p> |
| BLOCK SELECTION | <p>Description Use this function to select the PROFIBUS function block for displaying the corresponding input resp. output of the selected function block in the following functions.</p> <p> Note! If the PROFILE-GSD option is selected in the SELECTION GSD function, only the AI1 - OUT VALUE option is available in this function.</p> <p>Options AI1 - OUT VALUE Display of output value in the AI1 - OUT VALUE function AI2 - OUT VALUE Display of output value in the AI2 - OUT VALUE function AI3 - OUT VALUE Display of output value in the AI3 - OUT VALUE function AO - DISPLAY VALUE Display of output value in the AO - DISPLAY VALUE function AO - PRESSURE VALUE Display of output value in the AO - PRESSURE VALUE function</p> <p>Factory setting AI1 - OUT VALUE</p> |

| Function description, COMMUNICATION group | |
|---|--|
| CHANNEL | <p>Prerequisite This function is not available unless the AI1 -, AI2 - or AI3 - OUT VALUE option was selected in the BLOCK SELECTION function</p> <p>Description Assigning a measured variable to the Analog Input function block .</p> <p> Note! If the PROFILE-GSD option is selected in the SELECTION GSD function, only the MASS FLOW option is available in this function..</p> <p>Options: MASS FLOW CORRECTED VOLUME FLOW TEMPERATURE HEAT FLOW</p> <p>Factory setting Depends on the selection in the BLOCK SELECTION function: AI1 - OUT VALUE Factory setting = MASS FLOW AI2 - OUT VALUE Factory setting = COR. VOLUME FLOW AI3 - OUT VALUE Factory setting = TEMPERATURE</p> |
| AI1 - OUT VALUE | <p>Prerequisite This function is not available unless the AI1 - OUT VALUE option was selected in the BLOCK SELECTION function.</p> <p>Description Use this function to display the measured variable which is cyclically transmitted to the PROFIBUS Master (class 1) via the Analog Input function block 1.</p> |
| AI2 - OUT VALUE | <p>Prerequisite This function is not available unless the AI2 - OUT VALUE option was selected in the BLOCK SELECTION function.</p> <p>Description Use this function to display the measured variable which is cyclically transmitted to the PROFIBUS Master (class 1) via the Analog Input function block 2.</p> |
| AI3 - OUT VALUE | <p>Prerequisite This function is not available unless the AI3 - OUT VALUE option was selected in the BLOCK SELECTION function.</p> <p>Description Use this function to display the measured variable which is cyclically transmitted to the PROFIBUS Master (class 1) via the Analog Input function block 2.</p> |
| AO - DISPLAY VALUE | <p>Prerequisite This function is not available unless the AIO - DISPLAY VALUE option was selected in the BLOCK SELECTION function.</p> <p>Description Use this function to display the measured variable (DISPLAY_VALUE module) which is cyclically transmitted from the PROFIBUS master (Class 1).</p> |
| AO - PRESSURE VALUE | <p>Prerequisite This function is not available unless the AIO - PRESSURE VALUE option was selected in the BLOCK SELECTION function.</p> <p>Description Use this function to display the process pressure, which is cyclically transmitted from the PROFIBUS Master (class 1). For more information: PROCESS PRESSURE function →  35.</p> |

10 PROCESS PARAMETER

| Function description, PROCESS PARAMETER group | |
|---|--|
| PROCESS PRESSURE 1 | <p>Prerequisite This function is not available if the IN-SITU CALIBRATION function has been enabled. Refer to your Endress+Hauser sales center for more information.</p> <p>Description Use this function to enter the process pressure for GAS GROUP 1. (Selection and composition via the functions in the GAS 1/2 group) The unit is taken from the function UNIT PRESSURE (→ 10).</p> <p>Input/display 5-digit floating-point number</p> <p>Factory setting 1.0130 [bar a] or 14.692 [psi a] (country dependent → 54)</p> |
| PROCESS PRESSURE 2 | <p>Prerequisite This function is not available if the IN-SITU CALIBRATION function has been enabled. Refer to your Endress+Hauser sales center for more information.</p> <p>Description Use this function to enter the process pressure for GAS GROUP 2. (Selection and composition via the functions in the GAS 1/2 group) The unit is taken from the function UNIT PRESSURE (→ 10).</p> <p>Input/display 5-digit floating-point number</p> <p>Factory setting 1.0130 [bar a] or 14.692 [psi a] (country dependent → 54)</p> |
| PROCESS PRESSURE | <p>Description Use this function to display the pressure value which is used for the flow calculation. The value is read from the following function: PROCESS PRESSURE 1 or 2 (depending on which gas group is active) The unit is taken from the function UNIT PRESSURE (→ 10).</p> <p>Display 5-digit floating-point number</p> <p>Factory setting 1.0130 [bar a] or 14.692 [psi a] (country dependent → 54)</p> |
| REFERENCE PRESSURE | <p>Description Use this function to enter the reference pressure for calculating the reference density (for corrected volume flow measurement). The unit is taken from the function UNIT PRESSURE (→ 10).</p> <p>User input 5-digit floating-point number</p> <p>Factory setting 1.0130 [bar a] or 14.692 [psi a] (country dependent → 54)</p> |
| REFERENCE TEMPERATURE | <p>Description Use this function to enter the reference temperature for calculating the reference density (for corrected volume flow measurement). The unit is taken from the function UNIT TEMPERATURE (→ 11).</p> <p>User input 5-digit floating-point number</p> <p>Factory setting 0.0 [°C] or +32.0 [°F] (country dependent → 54.)</p> |

| Function description, PROCESS PARAMETER group | |
|---|--|
| REFERENCE DENSITY | <p>Prerequisite This function is not available if the IN-SITU CALIBRATION function has been enabled. Refer to your Endress+Hauser sales center for more information.</p> <p>Description Use this function to display the calculated reference density (for corrected volume flow measurement). The unit is taken from the function UNIT DENSITY (→ 11).</p> <p>Display 5-digit floating-point number</p> |
| NET CALORIFIC VALUE | <p>Prerequisite This function is only available if AUTO NET or MANUAL was selected in the MODE 1 or 2 function (→ 43)</p> <p>Description Use this function to display the current net calorific value of the gas. The unit is taken from the function UNIT CALORIFIC VALUE MASS (→ 9) or UNIT CALORIFIC VALUE CORRECTED VOLUME (→ 9).</p> <p>Display 5-digit floating-point number</p> |
| GROSS CALORIFIC VALUE | <p>Prerequisite This function is only available if AUTO GROSS was selected in the MODE 1 or 2 function (→ 43).</p> <p>Description Use this function to display the current gross calorific value of the gas. The unit is taken from the function UNIT CALORIFIC VALUE MASS (→ 9) or UNIT CALORIFIC VALUE CORRECTED VOLUME (→ 9).</p> <p>Display 5-digit floating-point number</p> |
| MOLE % GAS 1 | <p>Description Use this function to display the Mole % of GAS TYPE 1. → 39</p> <p>Display 0.0 % to 100.0 %</p> |
| ASSIGN LOW FLOW CUT OFF | <p>Description For selecting the process variable on which low flow cut off should act.</p> <p>Options OFF MASS FLOW CORRECTED VOLUME FLOW</p> <p>Factory setting MASS FLOW</p> |
| ON-VALUE LOW FLOW CUT OFF | <p>Prerequisite This function is not available if OFF was selected in the ASSIGN LOW FLOW CUT OFF function (→ 36).</p> <p>Description Use this function to enter the on-value for low flow cut off. The unit is taken from the SYSTEM UNITS group (→ 8). Low flow cut off is switched on if the value entered is not equal to 0. An inverted plus sign is shown on the local display of the flow value as soon as the low flow cut off is active.</p> <p>User input 5-digit floating-point number</p> <p>Factory setting 1% of calibrated full scale value</p> |

| Function description, PROCESS PARAMETER group | |
|---|---|
| <p>OFF-VALUE LOW FLOW CUT OFF</p> | <p>Description Use this function to enter the off-value for low flow cut off. Enter the off-value as a positive hysteresis from the on-value.</p>  <p><i>Fig. 4: Example for the behavior of low flow cutoff</i></p> <p>Q Flow rate [volume/time] t Time H Hysteresis a ON VALUE LOW FLOW CUT OFF = 20 kg/h b OFF-VALUE LOW FLOW CUTOFF = 10% c Low flow cutoff active 1 Low flow cut off is switched on at 20 kg/h 2 Low flow cut off is switched off at 22 kg/h</p> <p>User input Integer 0 to 100%</p> <p>Factory setting 50%</p> |
| <p>ZERO POINT ADJUST</p> | <p>Description Use this function to start automatic zero point adjustment.</p> <p> Caution! Prior to performing zero point adjustment, observe the exact procedure for zero point adjustment as specified in Operating Instructions BA00113D/06.</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ If zero point adjustment is not possible due to unstable flow conditions, alarm #451 "ADJUST ZERO FAIL" appears on the display. ▪ RESET: reset to factory calibration. <p>Options START CANCEL RESET</p> <p>Factory setting CANCEL</p> |
| <p>INSTALLATION FACTOR</p> | <p>Description Disturbances in the flow may arise due to the design of the system, such as pipe bends, reducers, etc. The flow value measured is scaled by entering a constant factor. The flow disturbance can thus be compensated using the calculated flow signal:</p> <p>Flow output = measured flow × installation factor</p> <p>Enter a higher value: flow value output is increased. Enter a lower value: flow value output is decreased.</p> <p>User input 5-digit floating-point number 0.0000 to 99999</p> <p>Factory setting 1.0000</p> |

11 GAS


Function description, GAS group

Prerequisite

This function is **not** available if the IN-SITU CALIBRATION function is enabled. This function is available again if the in-situ calibration is reset to the factory setting. Contact your Endress+Hauser service organization for more information.


Description

Use this function to view or change the gas configuration

- The device can be configured with one or two independent gas groups.
- Switching between two groups can be performed manually (function SELECT GROUP →  39)

General programming rules:

- A gas group can be configured with 1 single gas or a gas mixture (max. 8 gas constituents).
- The sum of the gas mixture constituents entered must total 100.0 Mole %.
- A gas constituent and its corresponding Mole % can be entered in any order within the mixture.
- A gas constituent may have a value of 0.0 Mole % within the mixture.
- The option NOT USED in the GAS TYPE 1 and GAS TYPE 2 to 8 functions is a place holder where no gas is assigned. The program does not use this option for calculations.
- The option SPECIAL GAS is a substitute for other gases. The Mole % value is always 100.0%

 Note!

For a flowchart of the GAS QUICK SETUP, see Operating Instructions BA00113D/06

Programming examples

- a. 1 gas group: 1 standard gas

| | |
|-----------------|-------------|
| SELECT GROUP | GAS GROUP 1 |
| NUMBER OF GASES | 1 |
| GAS TYPE 1 | AIR |
| MOLE % GAS 1 | 100.0 % |

- b. 2 gas groups: 2 standard gases

| | | |
|-----------------|-------------|-------------|
| SELECT GROUP | GAS GROUP 1 | GAS GROUP 2 |
| NUMBER OF GASES | 1 | 1 |
| GAS TYPE 1 | ARGON | NITROGEN |
| MOLE % GAS 1 | 100.0 % | 100.0 % |

- c. 2 gas groups: 1 standard gas, 1 special gas

| | | |
|-------------------|-------------|------------------|
| SELECT GROUP | GAS GROUP 1 | GAS GROUP 2 |
| NUMBER OF GASES | 1 | 1 |
| GAS TYPE 1 | OXYGEN | SPECIAL GAS |
| MOLE % GAS 1 | 100.0 % | 100.0 % |
| DESCRIPTION | - | O2 90% OZONE 10% |
| CORRECTION FACTOR | - | 1.2009 |
| REFERENCE DENSITY | - | 1.5005 kg/m3 |

| Function description, GAS group | |
|---------------------------------|--|
| SELECT GROUP | <p>Description</p> <ul style="list-style-type: none"> ▪ select a gas group for editing ▪ set the active gas group manually <p>Setting the active gas group:</p> <ul style="list-style-type: none"> ▪ On completion of programming all the necessary functions in the gas group, select YES in the SAVE CHANGES function → 42, or ▪ If the gas group is already programmed as required, simply select the required gas group and then exit using the ESC keys (X). <p>Options GAS GROUP 1 GAS GROUP 2</p> <p>Factory setting GAS GROUP 1</p> |
| ANALYZER INPUT | <p>Description</p> <p>Use this function to activate/deactivate automatic updating of gas mixtures (via a gas analyzer signal). A gas group must contain at least 2 gas types (e.g. Methane 60%, Carbon Dioxide 40%).</p> <p>User input OFF ON</p> <p>Factory setting OFF</p> |
| NUMBER OF GASES | <p>Description</p> <p>Use this function to enter the number of gases that are used in the gas group.</p> <p>User input 1 to 8</p> <p>Factory setting 1</p> |
| GAS TYPE 1 | <p>Description</p> <p>Use this function to select gas type 1.</p> <p>Options AIR AMMONIA ARGON BUTANE CARBON DIOXIDE CARBON MONOXIDE CHLORINE ETHANE ETHYLENE HELIUM 4 HYDROGEN NORMAL HYDROGEN CHLORIDE HYDROGEN SULFIDE KRYPTON METHANE NEON NITROGEN OXYGEN PROPANE XENON NOT USED SPECIAL GAS</p> <p>Factory setting AIR</p> |

| Function description, GAS group | |
|---------------------------------|---|
| MOLE % GAS 1 | <p>Prerequisite This function is not available if the setting in NUMBER OF GASES (→ 39) is 1. (The factory setting 100% is automatically used)</p> <p>Description Use this function to enter the Mole % of the gas selected in GAS TYPE 1.</p> <p>User input 000.00 % to 100.00 %</p> <p>Factory setting 100.00 %</p> |
| DESCRIPTION | <p>Prerequisite This function is only available if the option SPECIAL GAS is selected in the function GAS TYPE 1 (→ 39).</p> <p>Description Use this function to enter a description for a special gas configuration.</p> <p>Example A special composition consisting of 93% oxygen and 7% ozone. User input: O2 93% OZONE 7%</p> <p>User input xxxx (max. 16 characters) Valid characters are A-Z, 0-9, +, -, decimal point, blank space or underscore</p> <p>Factory setting "-----" (no text)</p> |
| CORRECTION FACTOR | <p>Prerequisite This function is only available if the option SPECIAL GAS is selected in the function GAS TYPE 1 (→ 39).</p> <p>Description Use this function to enter a manual correction factor for a special gas configuration. The correction factor is normally based on air and at the specified process conditions. The correction factor is determined by the factory. If the gas or process conditions change from the initial setting, then the correction factor value will also need updating.</p> <p>User input 5-digit floating-point number</p> <p>Factory setting 1.0</p> |
| REFERENCE DENSITY | <p>Prerequisite This function is only available if the option SPECIAL GAS is selected in the function GAS TYPE 1 (→ 39).</p> <p>Description Use this function to enter a reference density for a special gas configuration when corrected volume flow is required, e.g. Nm³ (Sft³) The unit is taken from the function UNIT DENSITY (→ 11). The reference density is determined by the factory. If the gas or reference conditions change from the initial setting, then the reference density value will also need updating.</p> <p>User input 5-digit floating-point number, with unit</p> <p>Factory setting 1.2930 [kg/m³] or 0.0807 [lb/ft³] (country dependent → 54)</p> |

| Function description, GAS group | |
|---------------------------------|---|
| GAS TYPE 2 to 8 | <p>Prerequisite The number of functions available here is dependent upon the setting in the function NUMBER OF GASES (→ 39).</p> <p>Description Use this function to select the gas type.</p> <p>Options AIR AMMONIA ARGON BUTANE CARBON DIOXIDE CARBON MONOXIDE CHLORINE ETHANE ETHYLENE HELIUM 4 HYDROGEN NORMAL HYDROGEN CHLORIDE HYDROGEN SULFIDE KRYPTON METHANE NEON NITROGEN OXYGEN PROPANE XENON NOT USED</p> <p>Factory setting NOT USED</p> |
| MOLE % GAS 2 to 8 | <p>Prerequisite The number of functions available here is dependent upon the setting in the function NUMBER OF GASES (→ 39).</p> <p>Description Use this function to enter the Mole % of the gas selected in GAS TYPE 2 to 8.</p> <p>User input 000.00 % to 100.00 %</p> <p>Factory setting 100.00 %</p> |
| CHECK VALUES | <p>Prerequisite This function is only available if there is an error in the Mole % values.</p> <p>Description The error message MIXTURE NOT 100% appears if the entered values do not add up to 100%. The entries have to be checked and corrected before the gas group can be saved and used for flow measurement (see option YES[®] function SAVE CHANGES (→ 42)).</p> <p>Display MIXTURE NOT 100%</p> |

| Function description, GAS group | |
|---------------------------------|--|
| SAVE CHANGES | <p>Description Use this function to control the way entries are saved in the gas group and utilized for flow measurement.</p> <p>Options</p> <p>CANCEL The entered parameters are saved in the gas group but they are not used for flow measurement. The gas group can be activated, at a later time, by returning to the group, checking the parameters and then selecting the option YES in this function.</p> <p>YES The entered parameters are saved in the gas group and are used for flow measurement.</p> <p>DISCARD The entered parameters are not saved. The previous parameters remain valid and are used for flow measurement.</p> |

12 HEAT FLOW






| Function description, HEAT FLOW group | |
|---------------------------------------|---|
| CALORIFIC VALUE TYPE | <p>Description Use this function to select the measured variable on which the combustion value is based.</p> <p>Options</p> <ul style="list-style-type: none"> ▪ MASS ▪ CORRECTED VOLUME <p>Factory setting MASS</p> |
| MODE 1 | <p>Description Use this function to select a mode for calculating the heat flow (GAS GROUP 1).</p> <p>Options</p> <ul style="list-style-type: none"> ▪ AUTO NET ▪ AUTO GROSS ▪ MANUAL <p>Factory setting AUTO NET</p> |
| HEATING VALUE 1 | <p>Prerequisite This function is only available if MANUAL was selected in the MODE 1 function (→ 43).</p> <p>Description Use this function to enter a user-specific calorific value.</p> <p>Input/display 5-digit floating-point number</p> <p>Factory setting 0.0 The corresponding unit is taken from the UNIT CALORIFIC VALUE MASS (→ 9) or UNIT CALORIFIC VALUE CORRECTED VOLUME function (→ 9).</p> |
| MODE 2 | <p>Description Use this function to select a mode for calculating the heat flow (GAS GROUP 2).</p> <p>Options</p> <ul style="list-style-type: none"> ▪ AUTO NET ▪ AUTO GROSS ▪ MANUAL <p>Factory setting AUTO NET</p> |
| HEATING VALUE 2 | <p>Prerequisite This function is only available if MANUAL was selected in the MODE 2 function (→ 43).</p> <p>Description Use this function to enter a user-specific calorific value.</p> <p>Input/display 5-digit floating-point number</p> <p>Factory setting 0.0 The corresponding unit is taken from the UNIT CALORIFIC VALUE MASS (→ 9) or UNIT CALORIFIC VALUE CORRECTED VOLUME function (→ 9).</p> |

| Function description, HEAT FLOW group | |
|---------------------------------------|---|
| REFERENCE COMBUSTION TEMPERATURE | <p>Prerequisite This function is not available if the option MANUAL is selected in MODE 1 oder 2 (→ 43).</p> <p>Description Use this function to enter the reference combustion temperature of the gas. This function is used to calculate the calorific value of the gas. The unit is taken from the function UNIT TEMPERATURE (→ 11).</p> <p>User input 5-digit floating-point number</p> <p>Factory setting 25.0 °C or 60.0 °F (country dependent → 54)</p> |

13 SYSTEM PARAMETER


| Function description, SYSTEM PARAMETER group | |
|--|--|
| POSITIVE ZERO RETURN | <p>Description Use this function to interrupt evaluation of measured variables. For example, the output signal should be set to zero flow during operations such as pipe cleaning. The setting acts on all functions and outputs of the measuring device. If the positive zero return is active, the notice message #601 "POSITIVE ZERO-RET" is displayed.</p> <p>Options OFF ON (signal output is set to zero flow value, temperature is as normal)</p> <p>Factory setting OFF</p> |
| FLOW DAMPING | <p>Description For setting the filter depth. The sensitivity of the flow measurement signal can be reduced with respect to transient flows and interference peaks. The response time of the measuring device increases with every increase in the filter setting. The damping acts prior to other damping functions (e. g. display, time constant).</p> <p>User input 0 to 100 s</p> <p>Factory setting 1 s</p> |

14 SENSOR DATA


| Function description, SENSOR DATA group | |
|--|---|
| <p>This group of functions contains the essential data relating to the sensor geometry and calibration.</p> <p>Flange version (t-mass 65 F): The sensor data cannot be changed and is read only.</p> <p>Insertion version (t-mass 65 I): The sensor data can be changed to suit the application pipe. The pipe or duct dimensions are essential for calculating the correct insertion depth.</p> <p> Note!</p> <p>To record the sensor data for the insertion sensor (t-mass 65I), see the flowchart of the QUICK SETUP SENSOR in Operating Instructions BA00113D/06.</p> <p>Refer to your Endress+Hauser sales center for more information.</p> | |
| PIPE TYPE | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I).</p> <p>Description Use this function to select the type of pipe.</p> <p>Options CIRCULAR RECTANGULAR</p> <p>Factory setting CIRCULAR</p> |
| PIPE STANDARD | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I). This function is not available if RECTANGULAR is selected in the PIPE TYPE function (→  46).</p> <p>Description Use this function to select a pipe standard. If the option OTHERS is selected here, then values need to be entered in the functions OUTER DIAMETER/OUTER DIAMETER and WALL THICKNESS/WALL THICKNESS.</p> <p>Options DIN: PN6, PN10, PN25, PN40 ANSI: B36.10 SCHEDULE 10, 20, 30, 40, 60, 80 B36.19 SCHEDULE 10, 40, 80 OTHERS</p> <p>Factory setting PN10 or B36.10 SCHEDULE 10 (country dependent →  54)</p> |
| NOMINAL DIAMETER | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I). This function is not available if OTHER was selected in the PIPE STANDARD function (→  46) or RECTANGULAR in the PIPE TYPE function (→  46).</p> <p>Description Use this function to select the nominal diameter of the pipe.</p> <p>Options 80/3", 100/4", 150/6", 200/8", 250/10", 300/12", 350/14", 400/16", 450/18", 500/20", 600/24", 700/28", 800/32", 900/36", 1000/40"</p> <p>Factory setting 150/6"</p> |

| Function description, SENSOR DATA group | |
|---|---|
| OUTER DIAMETER | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I). This function is only available if CIRCULAR is selected in the PIPE TYPE function (→ 46) and OTHER was selected in the PIPE STANDARD function (→ 46).</p> <p>Description Use this function to enter the outer diameter of a circular pipe. The unit is taken from the function UNIT LENGTH (→ 11).</p> <p>User input 5-digit floating-point number 60 to 99999 (mm) or 2.362 to 3937 (inch) (country dependent → 54)</p> <p>Factory setting 168.3 (mm) or 6.0 (inch) (country dependent → 54)</p> |
| WALL THICKNESS | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I). This function is only available if OTHER was selected in the PIPE STANDARD function (→ 46).</p> <p>Description Use this function to enter the wall thickness of a circular or rectangular duct. The unit is taken from the function UNIT LENGTH (→ 11).</p> <p>User input 5-digit floating-point number 2.0 to 40.0 (mm) or 0.08 to 1.57 (inch) (country dependent → 54)</p> <p>Factory setting 4.5 (mm) or 0.1771 (inch) (country dependent → 54)</p> |
| INTERNAL DIAMETER | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I). This function is only available if OTHER is selected in the PIPE STANDARD function (→ 46) and CIRCULAR was selected in the PIPE TYPE function (→ 46).</p> <p>Description Use this function to view the internal diameter of a circular pipe. The unit is taken from the function UNIT LENGTH (→ 11).</p> <p>Display 5-digit floating-point number</p> <p>Factory setting Depends on the sensor size (country dependent → 54)</p> |
| INTERNAL HEIGHT | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I). This function is only available if RECTANGULAR was selected in the PIPE TYPE function (→ 46).</p> <p>Description Use this function to enter the internal height of a rectangular duct. The unit is taken from the function UNIT LENGTH (→ 11).</p> <p>User input 5-digit floating-point number 45 to 99999 (mm) or 1.771 to 3937 (inch) (country dependent → 54)</p> <p>Factory setting 150.0 (mm) or 6.0 (inch) (country dependent → 54)</p> |






| Function description, SENSOR DATA group | |
|---|---|
| INTERNAL WIDTH | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I). This function is only available if RECTANGULAR is selected in the PIPE TYPE function (→ 46).</p> <p>Description Use this function to enter the internal width of a rectangular duct. The unit is taken from the function UNIT LENGTH (→ 11).</p> <p>User input 5-digit floating-point number 45 to 99999 (mm) or 1.771 to 3937 (inch) (country dependent → 54)</p> <p>Factory setting 150.0 (mm) or 6.0 (inch) (country dependent → 54)</p> |
| MOUNTING | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I). This function is only available if RECTANGULAR was selected in the PIPE TYPE function (→ 46).</p> <p>Description Use this function to select the installation direction of the insertion sensor in the rectangular duct.</p> <ul style="list-style-type: none"> - If the VERTICAL option is selected, the value from the function INTERNAL HEIGHT (→ 47) is used to calculate the insertion depth - If the HORIZONTAL option is selected, the value from the function INTERNAL WIDTH (→ 48) is used to calculate the insertion depth <p>Options HORIZONTAL VERTICAL</p> <p>Factory setting VERTICAL</p> |
| MOUNTING SET LENGTH | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I).</p> <p>Description Use this function to enter a value for the length of the mounting set (including the sensor compression fitting). The unit is taken from the function UNIT LENGTH (→ 11).</p> <p>User input 5-digit floating-point number 75 to 900 (mm) or 2.953 to 35.433 (inch) (country dependent → 54)</p> <p>Factory setting 106.0 (mm) or 4.173 (inch) (country dependent → 54) The factory setting value is the length of the G1A compression fitting and standard Endress+Hauser mounting boss.</p> |
| INSERTION DEPTH | <p>Prerequisite This function is only available for insertion sensors (t-mass 65I).</p> <p>Description This function displays the calculated insertion depth for mounting the sensor. The unit is taken from the function UNIT LENGTH (→ 11). For more information on insertion depth calculation, please refer to the Operating Instructions BA00113D/06.</p> <p>Display 5-digit floating-point number</p> |

| Function description, SENSOR DATA group | |
|---|--|
| ZERO POINT | <p>Description This function shows the current zero point correction value for the sensor. The zero point is determined by the ZERO POINT ADJUST (→  37) function.</p> <p>User input 5-digit floating-point number -20.000 to +20.000</p> <p>Factory setting Depends on calibration.</p> |
| FLOW CONDITIONER | <p>Description Use this function to indicate if the t-mass 65F sensor has been calibrated with or without a flow conditioner.</p> <p>Display WITH WITHOUT</p> <p>Factory setting WITHOUT</p> |
| CALIBRATION DATE | <p>Description Use this function to display the date of the last factory calibration of the measuring device. This date is not updated by the IN-SITU CALIBRATION function.</p> <p>Options DD.MM.YYYY</p> |

15 SUPERVISION

| Function description, SUPERVISION group | |
|---|---|
| ACTUAL SYSTEM CONDITION | <p>Description The current system status appears on the display.</p> <p>Display SYSTEM OK or The fault/notice message with the highest priority.</p> |
| PREVIOUS SYSTEM CONDITION | <p>Description The last 16 fault and notice messages appear on the display.</p> |
| ALARM DELAY | <p>Description Use this function to enter a time delay for which the criteria for an error always has to be satisfied before a fault or notice message is generated. Depending on the setting and the type of error, this suppression acts on the display.</p> <p> Note! If this function is used, fault and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-level controller (PLC, DCS, etc.). Therefore, check in advance whether a delay of this nature could affect the safety requirements of the process. If fault and notice messages are not be suppressed, than a value of 0 seconds must be entered here.</p> <p>User input 0 to 100 s (in steps of one second)</p> <p>Factory setting 0 s</p> |
| SYSTEM RESET | <p>Description Use this function to restart (reset) the measuring device.</p> <p>Options NO The device is not restarted.</p> <p>RESTART SYSTEM Restart without disconnecting main power. In doing so, all the data (functions) are accepted unchanged.</p> <p>Factory setting NO</p> |
| OPERATION HOURS | <p>Description The hours of operation of the device appear on the display.</p> <p>Display Depends on the number of hours of operation elapsed: Hours of operation < 10 hours → display format = 0:00:00 (hr:min:sec) Hours of operation 10 to 10 000 hours → display format = 0000:00 (hr:min) Hours of operation >10 000 hours → display format = 000000 (hr)</p> |
| HOURS SINCE RESET | <p>Description The hours of operation since the last reset of the device appear on the display.</p> <p>Display Depends on the number of hours of operation elapsed: Hours of operation < 10 hours → display format = 0:00:00 (hr:min:sec) Hours of operation 10 to 10 000 hours → display format = 0000:00 (hr:min) Hours of operation >10 000 hours → display format = 000000 (hr)</p> |

16 SIMULATION SYSTEM

| Function description, SIMULATION SYSTEM group | |
|---|---|
| SIMULATION FAIL-SAFE MODE | <p>Description Use this function to set all inputs, outputs and the totalizer to their error-response modes, in order to check whether they respond correctly. During this time, the message #691 "SIMULATION FAILSAFE" appears on the display.</p> <p>Options OFF ON</p> <p>Factory setting OFF</p> |
| SIMULATION MEASURAND | <p>Description Use this function to set all the inputs, outputs and the totalizer to their flow-response modes, in order to check whether they respond correctly. During this time, the message #692 "SIMULATION MEASURAND" appears on the display.</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ The measuring device can only be used for measuring to a certain extent while the simulation is in progress. ▪ The setting is not saved if the power supply fails. <p>Options OFF MASS FLOW CORRECTED VOLUME FLOW TEMPERATURE HEAT FLOW</p> <p>Factory setting OFF</p> |
| VALUE SIMULATION MEASURAND | <p>Prerequisite Function is only available if the SIMULATION MEASURAND function (→  51) is active.</p> <p>Description Use this function to specify an arbitrary value (e.g. 12 kg/s) to check the assigned functions in the device itself and downstream signal circuits. The unit depends on the option selected in the SIMULATION MEASURAND function and is taken from the SYSTEM UNITS group (→  8).</p> <p> Note! The setting is not saved if the power supply fails.</p> <p>User input 5-digit floating-point number</p> <p>Factory setting (country dependent →  54)</p> <ul style="list-style-type: none"> ▪ 0 kg/h; 0 lb/h (MASS FLOW) ▪ 0 Nm³/h; 0 Sm³/h (CORRECTED VOLUME FLOW) ▪ 0 kW; 0 kBtu (HEAT FLOW) ▪ 0 °C; +32 °F (TEMPERATURE) |

17 SENSOR VERSION

| Function description, SENSOR VERSION group | |
|--|--|
| SENSOR TYPE | <p>Description Use this function to view the sensor type.</p> <p>Display FLOWCELL (t-mass 65F flange sensor) INSERTION (t-mass 65I insertion sensor)</p> |
| SERIAL NUMBER | <p>Description The serial number of the sensor appears on the display.</p> |
| TRANSDUCER SERIAL NUMBER | <p>Description The serial number of the transducer appears on the display.</p> |
| SOFTWARE REVISION NUMBER S-DAT | <p>Description Use this function to view the software revision number of the S-DAT.</p> |
| PRE-AMPLIFIER SOFTWARE REVISION NUMBER | <p>Description Use this function to view the software revision number of the preamplifier.</p> |
| PRE-AMPLIFIER HARDWARE REVISION NUMBER | <p>Description Use this function to view the hardware revision number of the preamplifier.</p> |

18 AMPLIFIER VERSION

| Function description, AMPLIFIER VERSION group | |
|---|--|
| DEVICE SOFTWARE | <p>Description Use this function to display the current device software version.</p> |
| HARDWARE REVISION NUMBER AMPLIFIER | <p>Description Use this function to view the hardware revision number of the amplifier board.</p> |
| SOFTWARE REVISION NUMBER AMPLIFIER | <p>Description Use this function to view the software revision number of the amplifier board.</p> |
| SOFTWARE REVISION NUMBER T-DAT | <p>Description Use this function to view the software revision number of the T-DAT.</p> |
| I/O MODULE TYPE | <p>Description Use this function to view the configuration of the I/O module.</p> |
| SOFTWARE REVISION NUMBER I/O MODULE | <p>Description Use this function to view the software revision number of the I/O module.</p> |

19 Factory settings

19.1 Language → 24

| Country | Language | Country | Language |
|-----------------|----------|-----------------|------------|
| Australia | English | Norway | Norwegian |
| Belgium | English | Austria | German |
| Denmark | English | Poland | Polish |
| Germany | German | Portugal | Portuguese |
| England | English | Sweden | Swedish |
| Finland | Finnish | Switzerland | German |
| France | French | Singapore | English |
| The Netherlands | Dutch | Spain | Spanish |
| Hong Kong | English | South Africa | English |
| India | English | Thailand | English |
| Italy | Italian | Czechia | Czech |
| Luxembourg | French | Hungary | English |
| Malaysia | English | Other countries | English |

19.2 SI units (not for USA and Canada)

19.2.1 Low flow cut off, full scale value, pulse value

t-mass F sensor

With air at ambient conditions (without a flow conditioner)

| Nominal diameter [mm] | Low flow cut off [kg/h] | Full scale value [kg/h] | Pulse value [kg/p] |
|--------------------------|----------------------------|----------------------------|-----------------------|
| 15 | 0.53 | 53 | 0.10 |
| 25 | 2.00 | 200 | 1.00 |
| 40 | 5.55 | 555 | 1.00 |
| 50 | 9.10 | 910 | 10.00 |
| 80 | 20.30 | 2030 | 10.00 |
| 100 | 37.50 | 3750 | 10.00 |

t-mass I sensor

With air at ambient conditions (without a flow conditioner)

| Nominal diameter [mm] | Low flow cut off [kg/h] | Full scale value [kg/h] | Pulse value [kg/p] |
|--------------------------|----------------------------|----------------------------|-----------------------|
| 80 | 20.30 | 2030 | 10.0 |
| 100 | 37.50 | 3750 | 10.0 |
| 150 | 75.00 | 7500 | 100.0 |
| 200 | 125.00 | 12500 | 100.0 |

| Nominal diameter | Low flow cut off | Full scale value | Pulse value |
|------------------|------------------|------------------|-------------|
| [mm] | [kg/h] | [kg/h] | [kg/p] |
| 250 | 200.00 | 20000 | 100.0 |
| 300 | 280.00 | 28000 | 100.0 |
| 400 | 500.00 | 50000 | 100.0 |
| 500 | 800.00 | 80000 | 100.0 |
| 600 | 1150.00 | 115000 | 100.0 |
| 700 | 1590.00 | 159000 | 100.0 |
| 1000 | 3200.00 | 320000 | 100.0 |
| 1500 | 7200.00 | 720000 | 100.0 |

19.2.2 System units → 8

| | Unit |
|----------------------|-------------------|
| Temperature | °C |
| Density | kg/m ³ |
| Reference density | kg/m ³ |
| Calorific Value Mass | MJ/kg |
| Heat | kWh |

| | Unit |
|----------------------------|-------------------|
| Length | mm |
| Pressure | bar a |
| Reference Pressure | bar a |
| Calorific Value Corr. Vol. | MJ/m ³ |
| Reference temperature | °C |

19.2.3 Unit totalizer 1 and 2 → 30

| | Unit |
|-----------|------|
| Mass flow | kg |
| Heat flow | MWh |

| | Unit |
|-----------------------|-----------------|
| Corrected volume flow | Nm ³ |

19.2.4 Other Units

| | Unit | |
|-----------------------|------------------|------|
| Ref. combustion temp. | °C | → 44 |
| Pipe standard | according to DIN | → 46 |

19.3 US units (only for USA and Canada)

19.3.1 Low flow cut off, full scale value, pulse value

t-mass F sensor

With air at ambient conditions; (without a flow conditioner)

| Nominal diameter [mm] | Low flow cut off [lb/hr] | Full scale value [lb/hr] | Pulse value [lb/p] |
|--------------------------|-----------------------------|-----------------------------|-----------------------|
| ½" | 1.16 | 116 | 0.20 |
| 1" | 4.40 | 440 | 2.00 |
| 1½" | 12.20 | 1220 | 2.00 |
| 2" | 20.02 | 2002 | 20.00 |
| 3" | 44.66 | 4466 | 20.00 |
| 4" | 82.50 | 8250 | 20.00 |

t-mass I sensor

With air at ambient conditions; (without a flow conditioner)

| Nominal diameter [mm] | Low flow cut off [lb/hr] | Full scale value [lb/hr] | Pulse value [lb/p] |
|--------------------------|-----------------------------|-----------------------------|-----------------------|
| 3" | 44.66 | 4466 | 20.00 |
| 4" | 82.50 | 8250 | 20.00 |
| 6" | 165.00 | 16500 | 200.00 |
| 8" | 275.00 | 27500 | 200.00 |
| 10" | 440.00 | 44000 | 200.00 |
| 12" | 610.00 | 61000 | 200.00 |
| 16" | 1100.00 | 110000 | 200.00 |
| 20" | 1760.00 | 176000 | 200.00 |
| 24" | 2530.00 | 253000 | 200.00 |
| 28" | 3498.00 | 349800 | 200.00 |
| 40" | 7040.00 | 704000 | 200.00 |
| 60" | 15840.00 | 1584000 | 200.00 |

19.3.2 System units → 8

| | Unit |
|----------------------|--------------------|
| Temperature | °F |
| Density | lb/ft ³ |
| Reference density | lb/ft ³ |
| Calorific Value Mass | kBtu/lb |
| Heat | kBtu |

| | Unit |
|----------------------------|-----------------------|
| Length | inch |
| Pressure | psi a |
| Reference Pressure | psi a |
| Calorific Value Corr. Vol. | kBtu/Sft ³ |
| Reference temperature | °F |

19.3.3 Unit totalizer 1 and 2 → 30

| | Unit |
|-----------|------|
| Mass flow | lb |
| Heat flow | kBtu |

| | Unit |
|-----------------------|-----------------|
| Corrected volume flow | Sm ³ |

19.3.4 Other Units

| | Unit | |
|-----------------------|-------------------|------|
| Ref. combustion temp. | °F | → 44 |
| Pipe standard | according to ANSI | → 46 |

Index

Numerics

| | |
|--------------------------|----|
| 100% VALUE LINE 1 (fct.) | 27 |
| 100% VALUE LINE 2 (fct.) | 27 |

A

| | |
|---|----|
| ACCESS CODE (fct.) | 24 |
| ACCESS CODE COUNTER (fct.) | 25 |
| ACTUAL BAUD RATE (fct.) | 33 |
| ACTUAL SYSTEM CONDITION (fct.) | 50 |
| AI1 - OUT VALUE (fct.) | 34 |
| AI2 - OUT VALUE (fct.) | 34 |
| AI3 - OUT VALUE (fct.) | 34 |
| ALARM DELAY (fct.) | 50 |
| AMPLIFIER HARDWARE REVISION NUMBER (fct.) | 53 |
| AMPLIFIER VERSION, function group | 53 |
| ANALYZER INPUT (fct.) | 39 |
| AO - DISPLAY VALUE (fct.) | 34 |
| ASSIGN LINE 1 (fct.) | 26 |
| ASSIGN LINE 2 (fct.) | 26 |
| ASSIGN LOW FLOW CUTOFF (fct.) | 36 |

B

| | |
|------------------------|----|
| BACKLIGHT (fct.) | 28 |
| BLOCK SELECTION (fct.) | 33 |

C

| | |
|-------------------------------|----|
| CALIBRATION DATE (fct.) | 49 |
| Calorific value | 21 |
| CALORIFIC VALUE TYPE (fct.) | 43 |
| CHANNEL (fct.) | 29 |
| CHANNEL, AI (fct.) | 34 |
| CHECK CONFIGURATION (fct.) | 33 |
| CHECK VALUES (fct.) | 41 |
| Commissioning | 14 |
| Communication | 16 |
| COMMUNICATION, function group | 32 |
| CONTRAST LCD (fct.) | 28 |
| CORRECTED VOLUME FLOW (fct.) | 7 |
| CORRECTION FACTOR (fct.) | 40 |
| CYCL. CALC. TOT. (fct.) | 31 |

D

| | |
|--|----|
| Data back-up (of device data with T-DAT) | 23 |
| DEFINE PRIVATE CODE (fct.) | 24 |
| DESCRIPTION (fct.) | 40 |
| DEVICE ID (fct.) | 33 |
| DEVICE SOFTWARE (fct.) | 53 |
| DISPLAY DAMPING (fct.) | 27 |

F

| | |
|--------------------------|----|
| FIELD BUS ADDRESS (fct.) | 32 |
| FLOW CONDITIONER (fct.) | 49 |
| FLOW DAMPING (fct.) | 45 |
| FORMAT (fct.) | 27 |

G

| | |
|--------------|----|
| Gas pressure | 20 |
|--------------|----|

| | |
|------------------------------|----|
| Gas programming | 18 |
| GAS TYPE 1 (fct.) | 39 |
| GAS TYPE 2 to 8 (fct.) | 41 |
| GAS, function group | 38 |
| GROSS CALORIFIC VALUE (fct.) | 36 |

H

| | |
|---------------------------|----|
| Heat flow | 21 |
| HEAT FLOW (fct.) | 7 |
| HEAT FLOW, function group | 43 |
| HEATING VALUE 1 (fct.) | 43 |
| HOURS SINCE RESET (fct.) | 50 |

I

| | |
|--|----|
| I/O MODULE (fct.) | 53 |
| I/O-MODULE SOFTWARE REVISION NUMBER (fct.) | 53 |
| INSERTION DEPTH (fct.) | 48 |
| INSTALLATION FACTOR (fct.) | 37 |
| INTERNAL DIAMETER (fct.) | 47 |
| INTERNAL HEIGHT (fct.) | 47 |
| INTERNAL WIDTH (fct.) | 48 |

L

| | |
|-----------------|----|
| LANGUAGE (fct.) | 24 |
|-----------------|----|

M

| | |
|---------------------------------|--------|
| MASS FLOW (fct.) | 7 |
| MEASURED VALUES, function group | 7 |
| MODE 1 (fct.) | 43 |
| MODE 2 (fct.) | 43 |
| MODE TOTALIZER (fct.) | 31 |
| MOLE % GAS 1 (GAS) (fct.) | 36, 40 |
| MOLE % GAS 2 to 8 | 41 |
| MOUNTING (fct.) | 48 |
| MOUNTING SET LENGTH (fct.) | 48 |

N

| | |
|----------------------------|----|
| NET CALORIFIC VALUE (fct.) | 36 |
| Net/gross calorific value | 21 |
| NOMINAL DIAMETER (fct.) | 46 |
| NUMBER OF GASES (fct.) | 39 |

O

| | |
|----------------------------------|----|
| OFF-VALUE LOW FLOW CUTOFF (fct.) | 37 |
| ON-VALUE LOW FLOW CUTOFF (fct.) | 36 |
| OPERATING PRESSURE (fct.) | 35 |
| OPERATION HOURS (fct.) | 50 |
| OPERATION, function group | 24 |
| OUTER DIAMETER (fct.) | 47 |
| OVERFLOW (fct.) | 29 |

P

| | |
|---|----|
| PIPE STANDARD (fct.) | 46 |
| PIPE TYPE (fct.) | 46 |
| POSITIVE ZERO RETURN (fct.) | 45 |
| PRE-AMPLIFIER HARDWARE REVISION NUMBER (fct.) | 52 |

PRE-AMPLIFIER SOFTWARE REVISION NUMBER (fct.) 52
 PRESET TOTALIZER (fct.) 30
 Pressure
 Process pressure 20
 Quick setup 20
 PREVIOUS SYSTEM CONDITION (fct.) 50
 PROCESS PARAMETER, function group 35
 PROCESS PRESSURE 1 (fct.) 35
 PROCESS PRESSURE 2 (fct.) 35
 Process pressure, programming 20
 PROFIL VERSION (fct.) 33

Q

Quick setup
 Commissioning 14
 Communication 16
 Gas programming 18
 Heat flow 21
 Pressure 20
 Sensor 17
 QUICK SETUP COMMISSIONING (fct.) 12
 QUICK SETUP COMMUNICATION (fct.) 12
 QUICK SETUP function group 12
 QUICK SETUP GAS (fct.) 12
 QUICK SETUP HEAT FLOW (fct.) 13
 QUICK SETUP PRESSURE (fct.) 12
 QUICK SETUP SENSOR (fct.) 12

R

REFERENCE COMBUSTION TEMPERATURE (fct.) 44
 REFERENCE DENSITY (fct.) 36, 40
 REFERENCE PRESSURE (fct.) 35
 REFERENCE TEMPERATURE (fct.) 35

S

SAVE CHANGES (fct.) 42
 SELECT GROUP (fct.) 39
 SELECT TOTALIZER (fct.) 29
 SELECTION GSD (fct.) 32
 SENSOR DATA, function group 46
 Sensor setup 17
 SENSOR TYPE (fct.) 52
 SENSOR VERSION, function group 52
 SERIAL NUMBER (fct.) 52
 SET TOTALIZER (fct.) 30
 SIMULATION FAILSAFE MODE (fct.) 51
 SIMULATION MEASURAND (fct.) 51
 SIMULATION SYSTEM, function group 51
 SOFTWARE REVISION NUMBER AMPLIFIER (fct.) 53
 SOFTWARE REVISION NUMBER S-DAT (fct.) 52
 SOFTWARE REVISION NUMBER T-DAT (fct.) 53
 STATUS ACCESS (fct.) 24
 SUM (fct.) 29
 SUPERVISION, function group 50
 SYSTEM PARAMETER, function group 45
 SYSTEM RESET (fct.) 50
 SYSTEM UNITS, function group 8

T

TAG NAME (fct.) 32
 T-DAT (HistoROM)
 Save/load (data back-up, e.g. for replacing devices) . 23
 T-DAT save/load 13
 T-DAT SAVE/LOAD (fct.) 13
 TEMPERATURE (fct.) 7
 TEST DISPLAY (fct.) 28
 TOTALIZER, function group 29
 TRANSDUCER SERIAL NUMBER (fct.) 52

U

UNIT CALORIFIC VALUE CORRECTED VOLUME (fct.) 9
 UNIT CALORIFIC VALUE MASS (fct.) 9
 UNIT CORRECTED VOLUME (fct.) 9
 UNIT CORRECTED VOLUME FLOW (fct.) 8
 UNIT DENSITY (fct.) 11
 UNIT HEAT (fct.) 10
 UNIT HEAT FLOW (fct.) 10
 UNIT LENGTH (fct.) 11
 UNIT MASS (fct.) 8
 UNIT MASS FLOW (fct.) 8
 UNIT PRESSURE (fct.) 10
 UNIT TEMPERATURE (fct.) 11
 UNIT TO BUS (fct.) 32
 UNIT TOTALIZER (fct.) 30
 USER INTERFACE, function group 26

V

VALUE SIMULATION MEASURAND (fct.) 51

W

WALL THICKNESS (fct.) 47
 WRITE PROTECTION (fct.) 32

Z

ZERO POINT (fct.) 49
 ZERO POINT ADJUST (fct.) 37

www.addresses.endress.com
