



## Manufacturer Information

for users regarding software updates  
(following the NAMUR recommendation 53)

### Field Xpert – Device Xpert - SFX100

Device Xpert HART –  
Device List (Rev.05) of integrated HART devices (dated 2011.02.04)

#### 1 Type of Product

- Field device / signal processing device
- Software application for device configuration / handheld terminal / device drivers etc.
- Modem / interface

Manufacturer : Endress+Hauser Process Solutions AG  
 Product : Field Xpert – Device Xpert HART  
 Type and order code : SFX100

#### 2 Software

New device driver list : For the Device Xpert HART software there exist new Device Descriptions (DDs). The actually integrated field device drivers – Device Descriptions (DDs) are listed below.

Regarding software : **Device Xpert HART software version 1.6.2**

How to get? : The actual Device Descriptions (DDs) can be downloaded via the Field Xpert, connected to the Internet via PC and the Device Xpert software function

“Device -> Synchronize Library”.

This function only works if there exists a valid DD Update contract for the specific Field Xpert.

If you need a new or renewed DD Update contract, please order it from your Endress+Hauser Sales Center with the order code:


**SFX101 and  
Endress+Hauser Field Xpert serial no.**



## Manufacturer Information

for users regarding software updates  
(following the NAMUR recommendation 53)

Field Xpert serial number : The serial number can be found on the nameplate, which is attached to the rear of the housing.



### 3 Compatibility

Is the new product software compatible with the previous version, installed device driver components and operating tools?

- Yes  
 No, reason:

Is a software update generally recommended?

- Yes, reason:  
always up-to-date device drivers

### 4 Instruction manual

Is a new instruction manual necessary due to the software modification?

- Yes  
 No

### 5 Price

Change in price in comparison with the predecessor version?

- Yes, new list price and update costs (without installation) are enclosed  
 No

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
ABB Automation	0x00001A	KSX	0x0001	5	2
ABB Automation	0x00001A	600T	0x0002	1	2
ABB Automation	0x00001A	600T	0x0002	2	3
ABB Automation	0x00001A	600T	0x0002	3	4
ABB Automation	0x00001A	2600T-268	0x0003	1	1
ABB Automation	0x00001A	2600T-268	0x0003	3	1
ABB Automation	0x00001A	2600T-262/264	0x0004	1	1
ABB Automation	0x00001A	2600T-262/264	0x0004	2	2
ABB Automation	0x000016	TEU 211	0x0005	1	2
ABB Automation	0x00001A	2600T-364	0x0005	1	2
ABB Automation	0x000016	TEU 211	0x0005	2	2
ABB Automation	0x000016	TEU 211	0x0005	3	2
ABB Automation	0x000016	TS 11	0x0006	1	2
ABB Automation	0x000016	TS 11	0x0006	2	2
ABB Automation	0x000016	TS 11	0x0006	3	2
ABB Automation	0x000016	TH 02	0x0008	1	1
ABB Automation	0x00001A	KST	0x0008	1	2
ABB Automation	0x00001A	658T	0x000A	1	2
ABB Automation	0x00001A	652/653S	0x000C	1	2
ABB Automation	0x00001A	FVS4000	0x001A	0	11
ABB Automation	0x00001A	FSM4000	0x001D	0	0
ABB Automation	0x00001A	TB82PH-Combined	0x0023	1	1
ABB Automation	0x00001A	TB82EC-Combined	0x0024	1	1
ABB Automation	0x00001A	TB82TE-Combined	0x0025	1	1
ABB Automation	0x00001A	TB82TC-Combined	0x0026	1	1
ABB Automation	0x000016	TZID	0x0040	1	1
ABB Automation	0x000016	TZIDC	0x0041	1	1
ABB Automation	0x000016	AS800	0x0085	2	2
ABB Automation	0x000016	Confrac	0x0087	1	1
ABB Automation	0x00001A	263/265, 2000T	0x0089	2	2
ABB Automation	0x00001A	263/265, 2000T	0x0089	2	3
ABB Automation	0x00001A	261	0x008C	1	1
ACCUTECH	0x00005E	VR1500XX	0x00EE	1	1
ACCUTECH	0x00005E	AI1500	0x00EF	1	1
Action Instruments	0x000089	T798	0x00EF	1	1
American Level Instruments	0x0000B2	Model 32E	0x007F	1	1
Ametek	0x000003	NEWTHERMOX	0x0004	1	1
Ametek	0x000003	NEWTHERMOX	0x0004	2	1
Ametek	0x000003	NEWTHERMOX	0x0004	3	1
Analytical Technology Inc.	0x00009F	D12	0x007F	2	0
Anderson Instrument Company	0x00005A	ANDRSN1	0x00C8	1	3
Apparatebau Hundsbach	0x000071	MT115	0x00EE	1	1
Badgermeter	0x0000BD	Primo Advanced	0x0001	1	1
BERTHOLD	0x0000A1	LB491	0x007D	1	2
BERTHOLD	0x0000A1	LB491	0x007D	2	3
BERTHOLD	0x0000A1	LB491	0x007D	2	4
BERTHOLD	0x0000A1	LB460	0x007E	1	1
BERTHOLD	0x0000A1	LB490	0x007F	1	1
BERTHOLD	0x0000A1	LB490	0x007F	2	2
BERTHOLD	0x0000A1	LB490	0x007F	3	3
BERTHOLD	0x0000A1	LB490	0x007F	3	4
BESTA	0x000066	CLS 4-20	0x00EF	1	1
Bopp & Reuther Heinrichs	0x00006C	UMC2	0x00EB	3	1
Bopp & Reuther Heinrichs	0x00006C	ES	0x00EC	2	1
Bopp & Reuther Heinrichs	0x00006C	VTX	0x00ED	7	1
Bopp & Reuther Heinrichs	0x00006C	DIMF	0x00EE	7	1
Bopp & Reuther Heinrichs	0x00006C	UST 1	0x00EF	1	2
Bopp & Reuther Heinrichs	0x00006C	UST 1	0x00EF	7	1
Brooks Instrument	0x00000A	TRI20	0x0001	1	1
Brooks Instrument	0x00000A	38XXVA	0x0002	1	1
Brooks Instrument	0x00000A	QUANTIM	0x0004	1	1
Danfoss	0x000080	MAGFLO	0x0003	1	1
Det-Tronics	0x00008F	X2200	0x0076	1	1
Det-Tronics	0x00008F	X5200	0x0077	1	1
Det-Tronics	0x00008F	X9800	0x0078	1	1
Det-Tronics	0x00008F	X3302	0x0079	1	1

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Det-Tronics	0x00008F	GT3000	0x007B	1	1
Det-Tronics	0x00008F	X3301	0x007C	1	1
Det-Tronics	0x00008F	OPECL_RX	0x007E	1	1
Det-Tronics	0x00008F	OPECL_RX	0x007E	1	2
Det-Tronics	0x00008F	Eclipse	0x007F	1	1
DeZURIK	0x000091	Positioner	0x00EF	1	4
Direct Measurement	0x000074	DMC R-1A	0x00EF	1	1
Draeger	0x000052	Polytron 7000	0x00EB	1	1
Draeger	0x000052	POLYTRON2 IR	0x00ED	0	5
Draeger	0x000052	POLYTRON2 IR	0x00ED	1	1
Draeger	0x000052	Polytron2	0x00F7	1	1
Draeger	0x000052	Polytron2	0x00F7	1	2
Draeger	0x000052	Polytron2	0x00F7	3	1
Draeger	0x000052	Polytron2	0x00F7	3	2
Drexelbrook	0x00004E	UNIVERSAL III	0x0002	5	3
Drexelbrook	0x00004E	USonic	0x00EB	2	2
Dynisco	0x000072	SPX	0x00DE	16	2
Dynisco	0x000072	IPXII	0x00DF	1	1
Dynisco	0x000072	IPX	0x00E0	1	3
Elsag Bailey	0x000012	50XM2000	0x0007	0	5
Elsag Bailey	0x000012	50XE4000	0x0008	0	6
Elsag Bailey	0x000012	50VT1000	0x000E	0	5
Elsag Bailey	0x000012	50VM1000	0x000F	0	4
Elsag Bailey	0x000012	50XM1000	0x0019	4	2
Elsag Bailey	0x000012	50SM1000	0x001A	4	1
Elsag Bailey	0x000012	PTH	0x0042	1	1
Elsag Bailey	0x000012	TB82PH pH	0x0050	1	1
Elsag Bailey	0x000012	TB82PH ORP	0x0051	1	1
Elsag Bailey	0x000012	TB82PH pION	0x0052	1	1
Elsag Bailey	0x000012	TB82PH IConc	0x0053	1	1
Elsag Bailey	0x000012	TB82EC COND	0x0054	1	1
Elsag Bailey	0x000012	TB82EC CONC	0x0055	1	1
Elsag Bailey	0x000012	TB82TE COND	0x0056	1	1
Elsag Bailey	0x000012	TB82TE CONC	0x0057	1	1
Elsag Bailey	0x000012	TB82TC COND	0x0058	1	1
Elsag Bailey	0x000012	TB82TC CONC	0x0059	1	1
Endress + Hauser	0x000011	FMU860	0x0003	1	2
Endress + Hauser	0x000011	FMU860	0x0003	2	3
Endress + Hauser	0x000011	FMU860	0x0003	3	1
Endress + Hauser	0x000011	FMU861	0x0004	1	1
Endress + Hauser	0x000011	FMU861	0x0004	2	2
Endress + Hauser	0x000011	FMU861	0x0004	3	1
Endress + Hauser	0x000011	FMU862	0x0005	1	1
Endress + Hauser	0x000011	FMU862	0x0005	2	2
Endress + Hauser	0x000011	FMU862	0x0005	3	1
Endress + Hauser	0x000011	FMR130/Micropilot	0x0006	1	1
Endress + Hauser	0x000011	FMR130/Micropilot	0x0006	2	1
Endress + Hauser	0x000011	FMR130/Micropilot	0x0006	3	1
Endress + Hauser	0x000011	FMR130/Micropilot	0x0006	4	1
Endress + Hauser	0x000011	Cerabar S	0x0007	1	1
Endress + Hauser	0x000011	Cerabar S	0x0007	2	2
Endress + Hauser	0x000011	Cerabar S	0x0007	3	2
Endress + Hauser	0x000011	Cerabar S	0x0007	4	1
Endress + Hauser	0x000011	Cerabar S	0x0007	5	1
Endress + Hauser	0x000011	Cerabar S	0x0007	6	1
Endress + Hauser	0x000011	Cerabar S	0x0007	7	1
Endress + Hauser	0x000011	Cerabar S	0x0007	7	2
Endress + Hauser	0x000011	Cerabar S	0x0007	7	3
Endress + Hauser	0x000011	FEC12	0x0008	1	2
Endress + Hauser	0x000011	Deltabar S	0x0009	1	2
Endress + Hauser	0x000011	Deltabar S	0x0009	2	2
Endress + Hauser	0x000011	Deltabar S	0x0009	3	1
Endress + Hauser	0x000011	Deltabar S	0x0009	5	1
Endress + Hauser	0x000011	Deltabar S	0x0009	6	1
Endress + Hauser	0x000011	Deltabar S	0x0009	7	1
Endress + Hauser	0x000011	Deltabar S	0x0009	7	2

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Endress + Hauser	0x000011	Deltabar S	0x0009	7	3
Endress + Hauser	0x000011	FMU231/FMU13x	0x000A	1	2
Endress + Hauser	0x000011	FMU231/FMU13x	0x000A	2	2
Endress + Hauser	0x000011	Deltapilot	0x000B	1	2
Endress + Hauser	0x000011	Deltapilot	0x000B	2	2
Endress + Hauser	0x000011	FMR23x	0x000C	1	1
Endress + Hauser	0x000011	FMR23x	0x000C	2	1
Endress + Hauser	0x000011	FMP200	0x000D	1	1
Endress + Hauser	0x000011	FMP200	0x000D	2	1
Endress + Hauser	0x000011	Cerabar M	0x000E	1	1
Endress + Hauser	0x000011	FMR2xx	0x000F	1	2
Endress + Hauser	0x000011	FMR2xx	0x000F	2	1
Endress + Hauser	0x000011	FMR2xx	0x000F	4	1
Endress + Hauser	0x000011	FMR53x	0x0010	1	2
Endress + Hauser	0x000011	FMR53x	0x0010	2	1
Endress + Hauser	0x000011	FMR53x	0x0010	3	1
Endress + Hauser	0x000011	FMU4x	0x0011	2	2
Endress + Hauser	0x000011	FMU4x	0x0011	4	1
Endress + Hauser	0x000011	FMP4x	0x0012	2	1
Endress + Hauser	0x000011	FMP4x	0x0012	4	1
Endress + Hauser	0x000011	FMG60	0x0013	1	1
Endress + Hauser	0x000011	FMG60	0x0013	2	1
Endress + Hauser	0x000011	FMG60	0x0013	2	2
Endress + Hauser	0x000011	DeltabarS	0x0017	10	1
Endress + Hauser	0x000011	DeltabarS	0x0017	20	1
Endress + Hauser	0x000011	DeltabarS	0x0017	21	1
Endress + Hauser	0x000011	DeltabarS	0x0017	21	2
Endress + Hauser	0x000011	CerabarS	0x0018	10	1
Endress + Hauser	0x000011	CerabarS	0x0018	20	1
Endress + Hauser	0x000011	CerabarS	0x0018	21	1
Endress + Hauser	0x000011	CerabarS	0x0018	21	2
Endress + Hauser	0x000011	Cerabar M 5x	0x0019	1	1
Endress + Hauser	0x000011	DeltapilotS	0x001A	21	1
Endress + Hauser	0x000011	DeltapilotS	0x001A	21	2
Endress + Hauser	0x000011	FMU9x	0x001B	1	1
Endress + Hauser	0x000011	FMU9x	0x001B	2	1
Endress + Hauser	0x000011	FMU9x	0x001B	3	1
Endress + Hauser	0x000011	FMI5x	0x001D	3	1
Endress + Hauser	0x000011	FMR25x	0x001E	1	1
Endress + Hauser	0x000011	FMR25x	0x001E	4	1
Endress + Hauser	0x000011	FMR25x	0x001E	5	1
Endress + Hauser	0x000011	FMR54x	0x001F	1	1
Endress + Hauser	0x000011	FMR54x	0x001F	1	2
Endress + Hauser	0x000011	FMP4x I	0x0020	8	1
Endress + Hauser	0x000011	Deltabar M 5x	0x0021	1	1
Endress + Hauser	0x000011	Deltapilot M 5x	0x0023	1	1
Endress + Hauser	0x000011	Waterpilot 2x	0x0024	1	1
Endress + Hauser	0x000011	PROMAG 33	0x0032	1	2
Endress + Hauser	0x000011	PROMAG 33	0x0032	2	1
Endress + Hauser	0x000011	PROWIRL 70	0x0033	1	2
Endress + Hauser	0x000011	PROMASS 63	0x0034	1	3
Endress + Hauser	0x000011	PROMASS 63	0x0034	2	1
Endress + Hauser	0x000011	PROMASS 63	0x0034	3	3
Endress + Hauser	0x000011	PROMASS 63	0x0034	4	1
Endress + Hauser	0x000011	PROMAG 39	0x0035	1	1
Endress + Hauser	0x000011	PROMAG 35S	0x0036	1	1
Endress + Hauser	0x000011	PROWIRL 77	0x0037	1	2
Endress + Hauser	0x000011	PROMASS 60	0x0039	1	1
Endress + Hauser	0x000011	PROMASS 60	0x0039	2	2
Endress + Hauser	0x000011	PROMASS 60	0x0039	3	1
Endress + Hauser	0x000011	PROSONIC FLOW	0x0040	1	1
Endress + Hauser	0x000011	PROSONIC FLOW	0x0040	2	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	1	2
Endress + Hauser	0x000011	PROMAG 50	0x0041	2	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	3	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	4	1

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Endress + Hauser	0x000011	PROMAG 50	0x0041	5	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	6	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	7	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	8	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	1	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	2	2
Endress + Hauser	0x000011	PROMAG 53	0x0042	3	2
Endress + Hauser	0x000011	PROMAG 53	0x0042	4	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	5	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	6	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	7	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	2	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	3	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	4	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	5	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	6	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	7	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	8	1
Endress + Hauser	0x000011	PROMAG 55	0x0044	1	1
Endress + Hauser	0x000011	PROMAG 55	0x0044	2	1
Endress + Hauser	0x000011	PROMAG 55	0x0044	3	1
Endress + Hauser	0x000011	PROMAG 10	0x0045	1	1
Endress + Hauser	0x000011	PROMAG 10	0x0045	2	1
Endress + Hauser	0x000011	PROMAG 10	0x0045	3	1
Endress + Hauser	0x000011	PROMAG 10	0x0045	4	1
Endress + Hauser	0x000011	PROMAG 23	0x0046	1	1
Endress + Hauser	0x000011	PROMAG 23	0x0046	2	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	1	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	2	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	3	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	4	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	5	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	6	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	7	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	8	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	9	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	1	2
Endress + Hauser	0x000011	PROMASS 83	0x0051	2	3
Endress + Hauser	0x000011	PROMASS 83	0x0051	3	2
Endress + Hauser	0x000011	PROMASS 83	0x0051	4	2
Endress + Hauser	0x000011	PROMASS 83	0x0051	5	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	6	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	7	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	8	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	9	1
Endress + Hauser	0x000011	PROMASS 84	0x0052	6	1
Endress + Hauser	0x000011	PROMASS 84	0x0052	7	1
Endress + Hauser	0x000011	PROMASS 84	0x0052	8	1
Endress + Hauser	0x000011	PROMASS 84	0x0052	9	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	1	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	2	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	3	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	4	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	5	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	6	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	7	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	8	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	9	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	1	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	2	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	3	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	4	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	5	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	6	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	1	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	2	1

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Endress + Hauser	0x000011	PROWIRL 73	0x0057	3	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	4	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	5	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	6	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	1	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	2	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	3	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	4	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	5	1
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	1	2
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	2	2
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	3	2
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	4	1
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	5	1
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	6	1
Endress + Hauser	0x000011	PROSON_F92	0x0061	1	1
Endress + Hauser	0x000011	PROSON_F91	0x0062	1	1
Endress + Hauser	0x000011	PROSON_F91	0x0062	2	1
Endress + Hauser	0x000011	AT70	0x0064	2	2
Endress + Hauser	0x000011	AT70	0x0064	3	1
Endress + Hauser	0x000011	AT70	0x0064	4	1
Endress + Hauser	0x000011	T-MASS65	0x0065	1	1
Endress + Hauser	0x000011	TMD832	0x0078	1	1
Endress + Hauser	0x000011	TMD832	0x0078	2	1
Endress + Hauser	0x000011	TMD833	0x0079	1	1
Endress + Hauser	0x000011	TMD842	0x007C	1	1
Endress + Hauser	0x000011	MyPro pH	0x008C	1	2
Endress + Hauser	0x000011	MyPro pH	0x008C	2	1
Endress + Hauser	0x000011	MyPro LFC	0x008D	1	2
Endress + Hauser	0x000011	MyPro LFC	0x008D	2	1
Endress + Hauser	0x000011	MyPro LFI	0x008E	2	1
Endress + Hauser	0x000011	CPM2x3	0x0091	1	5
Endress + Hauser	0x000011	CLi2x3	0x0092	1	3
Endress + Hauser	0x000011	CLC2x3	0x0093	1	3
Endress + Hauser	0x000011	COM2x3	0x0094	1	4
Endress + Hauser	0x000011	CUM2x3	0x0095	1	4
Endress + Hauser	0x000011	CCM2x3	0x0096	1	3
Endress + Hauser	0x000011	CLD132	0x0097	1	1
Endress + Hauser	0x000011	Mycom LFC	0x0099	1	1
Endress + Hauser	0x000011	NMT530	0x00B5	4	1
Endress + Hauser	0x000011	NMS530	0x00B6	2	1
Endress + Hauser	0x000011	TMT182	0x00C8	1	2
Endress + Hauser	0x000011	TMT182	0x00C8	2	1
Endress + Hauser	0x000011	TMT122	0x00C9	2	1
Endress + Hauser	0x000011	TMT122	0x00C9	2	2
Endress + Hauser	0x000011	TMT162	0x00CA	1	1
Endress + Hauser	0x000011	TMT162	0x00CA	2	1
Endress + Hauser	0x000011	TMT162	0x00CA	2	2
Endress + Hauser	0x000011	TMT142	0x00CB	2	2
Fieldbus International	0x0000A0	PIR 2000	0x0002	1	1
Fieldbus International	0x0000A0	OXI5000	0x00ED	1	1
Flowserve	0x000030	Logix 12xx	0x0001	1	4
Flowserve	0x000030	Logix 12xx	0x0001	1	5
Flowserve	0x000030	Logix 12xx	0x0001	2	5
Flowserve	0x000030	Logix 12xx	0x0001	2	6
Flowserve	0x000030	Logix 12xx	0x0001	3	1
Flowserve	0x000030	Logix 12xx	0x0001	3	2
Flowserve	0x000030	Logix 12xx	0x0001	3	3
Flowserve	0x000030	Kammer C2100	0x0002	1	1
Flowserve	0x000030	Logix 520	0x0003	1	1
Flowserve	0x000030	Logix 520	0x0003	1	2
Flowserve	0x000030	Logix 520	0x0003	2	1
Flowserve	0x000030	Logix 520	0x0003	2	2
Flowserve	0x000030	Logix3200-IQ	0x0004	1	2
Flowserve	0x000030	Logix3200-IQ	0x0004	2	1
Flowserve	0x000030	Logix3200-IQ	0x0004	2	2



# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Fluid Componets Intl	0x0000A6	ST98	0x0078	1	2
Foxboro	0x000014	MAG2	0x0001	2	2
Foxboro	0x000014	IASPT Premium 2	0x0002	1	1
Foxboro	0x000014	RTT30	0x0007	2	1
Foxboro	0x000014	IMV31	0x001D	2	1
Foxboro	0x000014	Vortex 84	0x001E	1	3
Foxboro	0x000014	IMT96	0x0028	1	1
Foxboro	0x000014	IMT25	0x0029	1	2
Foxboro	0x000014	I/A Pressure	0x002E	1	2
Foxboro	0x000014	I/A Pressure	0x002E	1	3
Foxboro	0x000014	I/A Pressure	0x002E	1	4
Foxboro	0x000014	I/A Pressure	0x002E	2	1
Foxboro	0x000014	I/A Pressure	0x002E	2	2
Foxboro	0x000014	I/A Pressure	0x002E	3	2
Foxboro	0x000014	IMV 25/30	0x002F	1	1
Foxboro	0x000014	IMV 25/30	0x002F	2	1
Foxboro	0x000014	IMV 25/30	0x002F	2	2
Foxboro	0x000014	875PH	0x0030	2	1
Foxboro	0x000014	875PH	0x0030	2	2
Foxboro	0x000014	875PH	0x0030	2	3
Foxboro	0x000014	875PH	0x0030	3	1
Foxboro	0x000014	ITVORTEX	0x0033	1	2
Foxboro	0x000014	ITVORTEX	0x0033	1	3
Foxboro	0x000014	CFT50	0x0034	2	1
Foxboro	0x000014	875CR	0x0035	2	2
Foxboro	0x000014	875CR	0x0035	2	3
Foxboro	0x000014	875CR	0x0035	2	4
Foxboro	0x000014	875CR	0x0035	3	1
Foxboro	0x000014	875EC	0x0036	2	2
Foxboro	0x000014	875EC	0x0036	2	3
Foxboro	0x000014	875EC	0x0036	3	1
Foxboro	0x000014	RTT15	0x0038	1	1
Foxboro	0x000014	RTT15	0x0038	1	2
Foxboro	0x000014	CFT 30 x	0x007D	3	1
Foxboro Eckardt	0x00003F	TSV175	0x0001	1	1
Foxboro Eckardt	0x00003F	DMU130	0x0002	1	2
Foxboro Eckardt	0x00003F	TI/RTT20	0x0003	1	2
Foxboro Eckardt	0x00003F	SRD991	0x0004	1	2
Foxboro Eckardt	0x00003F	DMU140	0x0005	1	2
Foxboro Eckardt	0x00003F	SRD960	0x0006	1	1
Fuji	0x000015	FCX-A/C	0x0001	1	1
Fuji	0x000015	FCX-A2/C2	0x0002	1	1
Fuji	0x000015	FCX-A2/C2	0x0002	2	2
Fuji	0x000015	FCX-A2/C2	0x0002	2	3
Fuji	0x000015	FCX-A2/C2	0x0002	3	1
Fuji	0x000015	FRC	0x0081	1	1
Hengesbach	0x0000C2	TE 52	0x0021	2	1
Honeywell	0x000017	ST3000	0x0001	1	2
Honeywell	0x000017	ST3000	0x0001	2	1
Honeywell	0x000017	ST3000	0x0001	4	1
Honeywell	0x000017	ST3000	0x0001	4	2
Honeywell	0x000017	ST3000	0x0001	5	1
Honeywell	0x000017	STT25T	0x0002	1	1
Honeywell	0x000017	HWFLOW/Mage W Plus	0x0003	1	1
Honeywell	0x000017	STT25H	0x0004	1	5
Honeywell	0x000017	STT25H	0x0004	2	6
Honeywell	0x000017	STT25H	0x0004	2	7
Honeywell	0x000017	HERCULINE	0x0005	1	2
Honeywell	0x000017	HERCULINE	0x0005	1	3
Honeywell	0x000017	HERCULINE	0x0005	3	1
Honeywell	0x000017	SmartCET	0x0006	1	1
Honeywell	0x000017	STT17H	0x0007	1	1
Honeywell	0x000017	STT25S	0x0009	1	1
Honeywell	0x000017	TWM9000	0x0050	2	2
Huakong	0x000085	HK TT01	0x007F	5	1
INOR	0x00005B	MESO	0x00EF	1	4



# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
InterCorr	0x0000A2	SMARTCET 18C	0x00EF	1	1
Invensys	0x0000A9	IA PRESSURE	0x002E	1	2
ISE-Magtech	0x00008C	LTM-100	0x0088	1	1
ISE-Magtech	0x00008C	LTM-300	0x0089	2	1
ISE-Magtech	0x00008C	LTM-300	0x0089	3	1
J Tec	0x0000AD	SERIES_0	0x0000	1	1
KAMSTRUP	0x000060	FLEXBAR 3501	0x00ED	1	3
KAMSTRUP	0x000060	FLEXBAR HRT	0x00EE	1	4
KAMSTRUP	0x000060	FLEXTOP HRT	0x00EF	1	1
KAMSTRUP	0x000060	FLEXTOP HRT	0x00EF	2	1
Kay Ray/Sensall	0x000019	3680 Dens	0x0009	1	3
Kay Ray/Sensall	0x000019	3680 Dens	0x0009	2	3
Kay Ray/Sensall	0x000019	3680 Dens	0x0009	2	4
Kay Ray/Sensall	0x000019	4790	0x000A	1	1
Kay Ray/Sensall	0x000019	4790	0x000A	2	2
Kay Ray/Sensall	0x000019	Accu-Pulse PRO	0x000B	1	1
Klay Instruments	0x000075	Klay 2000 Pressure/Level	0x00EF	1	1
Knick	0x000061	2211 Condl	0x00E8	1	1
Knick	0x000061	2211 Condl	0x00E8	2	1
Knick	0x000061	2211 Oxy	0x00E9	1	1
Knick	0x000061	2211 Cond	0x00EA	1	1
Knick	0x000061	2211 Cond	0x00EA	2	1
Knick	0x000061	2211 pH	0x00EB	1	1
Knick	0x000061	2211 pH	0x00EB	2	1
Kongsberg Maritime	0x0000C0	GT400	0x00EF	1	1
KPM	0x0000C5	KC/3	0x0080	1	1
KPM	0x0000C5	KC/5	0x0081	1	1
Krohne	0x000045	IFC 100	0x00D9	2	1
Krohne	0x000045	TT50C/R	0x00DB	1	4
Krohne	0x000045	MFC 300	0x00DD	2	1
Krohne	0x000045	ESK2A	0x00E2	1	1
Krohne	0x000045	IFC 300	0x00E3	1	2
Krohne	0x000045	IFC 300	0x00E3	2	1
Krohne	0x000045	Optiwave 7300C	0x00E5	1	2
Krohne	0x000045	M8E	0x00E6	1	1
Krohne	0x000045	UFC030	0x00E7	2	1
Krohne	0x000045	UFC030	0x00E7	2	2
Krohne	0x000045	MFC05x	0x00E8	1	1
Krohne	0x000045	IFC040	0x00E9	2	1
Krohne	0x000045	M10	0x00EA	2	1
Krohne	0x000045	BM102	0x00EC	1	1
Krohne	0x000045	VFM31	0x00ED	1	2
Krohne	0x000045	BM100	0x00EE	1	4
Krohne	0x000045	BM100	0x00EE	1	5
Krohne	0x000045	ESKII	0x00F2	1	1
Krohne	0x000045	IFC110	0x00F3	1	2
Krohne	0x000045	IFC110	0x00F3	2	1
Krohne	0x000045	IFC090	0x00F4	1	2
Krohne	0x000045	IFC090	0x00F4	2	1
Krohne	0x000045	UFC500	0x00F5	1	2
Krohne	0x000045	MFC08x	0x00F7	2	3
Krohne	0x000045	MFC08x	0x00F7	3	1
Krohne	0x000045	IFC080	0x00F8	1	1
Krohne	0x000045	IFC080	0x00F8	2	3
Krohne	0x000045	BM70	0x00F9	1	1
Krohne	0x000045	BM70	0x00F9	11	2
LABOM	0x00007F	PASCAL CI	0x003C	1	2
LABOM	0x00007F	IPX	0x00E0	1	2
Lanlian Instruments	0x0000C3	LSIII Pressure	0x0074	1	1
Magnetrik	0x000056	Model 705 3.x	0x00E5	1	1
Magnetrik	0x000056	Model 705 3.x	0x00E5	1	2
Magnetrik	0x000056	Model RX5	0x00E6	2	1
Magnetrik	0x000056	Model RX5	0x00E6	4	1
Magnetrik	0x000056	Model 704	0x00E7	1	1
Magnetrik	0x000056	Jupiter	0x00E8	2	1
Magnetrik	0x000056	Jupiter	0x00E8	3	2

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Magnetrik	0x000056	Model TA2	0x00E9	1	2
Magnetrik	0x000056	Model TA2	0x00E9	2	1
Magnetrik	0x000056	Model 707	0x00EA	2	1
Magnetrik	0x000056	Model 707	0x00EA	3	1
Magnetrik	0x000056	Model 705 2.x	0x00EB	1	1
Magnetrik	0x000056	Model 705 2.x	0x00EB	2	1
Magnetrik	0x000056	Model 705 2.x	0x00EB	3	1
Magnetrik	0x000056	Model 705 2.x	0x00EB	4	1
Magnetrik	0x000056	Model 708	0x00EC	1	1
Magnetrik	0x000056	Model 708	0x00EC	2	1
Magnetrik	0x000056	Model 708	0x00EC	3	1
Magnetrik	0x000056	Model 708	0x00EC	4	1
Magnetrik	0x000056	Model 805	0x00ED	1	2
Magnetrik	0x000056	Model 705	0x00EE	1	2
Magnetrik	0x000056	Model 705	0x00EE	3	1
Magnetrik	0x000056	Model 705	0x00EE	4	1
Magnetrik	0x000056	SMARTEZ	0x00EF	1	2
Magnetrik	0x000056	SMARTEZ	0x00EF	2	1
Masoneilan-Dresser	0x000065	HDLT	0x0064	1	2
Masoneilan-Dresser	0x000065	SVI	0x00C8	2	2
Masoneilan-Dresser	0x000065	SVI2	0x00C9	2	1
Masoneilan-Dresser	0x000065	SVI2	0x00C9	2	2
Masoneilan-Dresser	0x000065	SVI II AP	0x00CA	1	2
Meggitt Mobrey	0x00003B	4301	0x0013	3	3
Meggitt Mobrey	0x00003B	4301	0x0013	3	4
Meggitt Mobrey	0x00003B	MSP100	0x0015	2	2
Meggitt Mobrey	0x00003B	MSP100	0x0015	2	3
Meggitt Mobrey	0x00003B	GWR3300	0x0021	2	1
Meggitt Mobrey	0x00003B	MLT100	0x0029	1	1
Meggitt Mobrey	0x00003B	MLT100	0x0029	1	2
Meggitt Mobrey	0x00003B	MLT100	0x0029	1	3
Meggitt Mobrey	0x00003B	MSP900/400	0x002E	3	1
Meggitt Mobrey	0x00003B	MSP900/400	0x002E	4	1
Meggitt Mobrey	0x00003B	MSP900/400	0x002E	5	5
Meggitt Mobrey	0x00003B	MSP900/400	0x002E	5	6
Meggitt Mobrey	0x00003B	MRL700	0x002F	1	1
Meggitt Mobrey	0x00003B	MRL700	0x002F	1	2
Metso Automation	0x00002F	PSMART	0x0001	2	1
Metso Automation	0x00002F	SMARTPULP	0x003C	2	2
Metso Automation	0x00002F	SMARTPULP	0x003C	3	1
Metso Automation	0x00002F	SMARTLX	0x003D	3	1
Metso Automation	0x00002F	MCAi	0x003E	1	1
Metso Automation	0x00002F	SMARTLC	0x003F	1	1
Metso Automation	0x00002F	MCA	0x0040	1	2
Metso Automation	0x000057	ND9100HT	0x00E4	1	1
Metso Automation	0x000057	ND9100HT	0x00E4	2	1
Metso Automation	0x000057	ND9100HT	0x00E4	2	2
Metso Automation	0x000057	ND9100H	0x00E5	1	1
Metso Automation	0x000057	ND9100H	0x00E5	2	1
Metso Automation	0x000057	ND9100H	0x00E5	2	2
Metso Automation	0x000057	ND9100H	0x00E5	3	2
Metso Automation	0x000057	ValvGuard	0x00EB	2	1
Metso Automation	0x000057	ValvGuard	0x00EB	6	1
Metso Automation	0x000057	ND820/T	0x00EE	1	3
Metso Automation	0x000057	ND820/T	0x00EE	2	3
Metso Automation	0x000057	ND820/T	0x00EE	3	3
Metso Automation	0x000057	ND820/T	0x00EE	4	2
Metso Automation	0x000057	ND820/T	0x00EE	5	1
Metso Automation	0x000057	ND820/T	0x00EE	6	1
Metso Automation	0x000057	ND820/T	0x00EE	7	1
Metso Automation	0x000057	ND820	0x00EF	1	3
Metso Automation	0x000057	ND820	0x00EF	2	3
Metso Automation	0x000057	ND820	0x00EF	3	3
Metso Automation	0x000057	ND820	0x00EF	4	2
Metso Automation	0x000057	ND820	0x00EF	5	1
Metso Automation	0x000057	ND820	0x00EF	6	1

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Metso Automation	0x000057	ND820	0x00EF	7	1
Mettler Toledo	0x00008E	CondI7100	0x0078	1	1
Mettler Toledo	0x00008E	CondI7100	0x0078	2	1
Mettler Toledo	0x00008E	O2 4100e	0x0079	1	1
Mettler Toledo	0x00008E	Cond7100	0x007A	1	1
Mettler Toledo	0x00008E	Cond7100	0x007A	2	1
Mettler Toledo	0x00008E	pH 2100	0x007B	1	1
Mettler Toledo	0x00008E	pH 2100	0x007B	2	1
Micro Motion	0x00001F	9712 Mass flo	0x0007	2	6
Micro Motion	0x00001F	9739 Mass flo	0x0015	1	5
Micro Motion	0x00001F	9739 Mass flo	0x0015	2	5
Micro Motion	0x00001F	9739 Mass flo	0x0015	3	5
Micro Motion	0x00001F	9739 Mass flo	0x0015	4	1
Micro Motion	0x00001F	9739 Mass flo	0x0015	4	2
Micro Motion	0x00001F	9701	0x001E	1	3
Micro Motion	0x00001F	9701	0x001E	1	4
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	3	1
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	3	2
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	4	2
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	5	2
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	5	4
Micro Motion	0x00001F	MVD Series 1000 Config I/O	0x0025	4	1
Micro Motion	0x00001F	MVD Series 1000 Config I/O	0x0025	5	2
Micro Motion	0x00001F	MVD Series 1000 Config I/O	0x0025	5	4
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	2	1
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	2	2
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	3	1
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	3	2
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	4	1
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	5	2
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	5	4
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	2	1
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	3	1
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	3	2
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	4	1
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	5	2
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	5	4
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	2	1
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	3	1
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	3	2
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	4	1
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	5	2
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	5	4
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	1	1
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	2	1
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	2	2
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	3	1
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	3	2
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	4	1
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	5	2
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	5	4
Micro Motion	0x00001F	2400S Mass flo	0x0034	1	1
Micro Motion	0x00001F	2400S Mass flo	0x0034	1	2
Micro Motion	0x00001F	2400S Mass flo	0x0034	1	3
Micro Motion	0x00001F	2400S Mass flo	0x0034	1	4
Micro Motion	0x00001F	2400S Mass flo	0x0034	2	2
Micro Motion	0x00001F	2400S Mass flo	0x0034	2	3
Micro Motion	0x00001F	2400S Mass flo	0x0034	3	1
Micro Motion	0x00001F	2200S Analog	0x003A	1	1
Micro Motion	0x00001F	MVD Series 3000	0x0041	6	1
Micro Motion	0x00001F	MVD Series 3000	0x0041	6	2
Micro Motion	0x00001F	MVD Series 3000	0x0041	7	1
Micro Motion	0x00001F	MVD Series 3000	0x0041	7	3
Micro Motion	0x00001F	MVD Series 3000	0x0041	7	4
Milltronics	0x000058	86x PROBE	0x00C8	1	2
Milltronics	0x000058	SITTRANS LR300	0x00C9	1	1

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Milltronics	0x000058	LR 200	0x00CA	1	1
Milltronics	0x000058	LR 200	0x00CA	2	2
Milltronics	0x000058	SITRANS LR400	0x00CC	1	1
Milltronics	0x000058	Sitrans Probe LU 6m	0x00CD	1	1
Milltronics	0x000058	Sitrans Probe LU 12m	0x00CE	1	1
Milltronics	0x000058	Probe LR	0x00CF	2	2
Moore Industries	0x000020	TRZ	0x0001	1	1
Moore Industries	0x000020	TRZ	0x0001	2	1
Moore Industries	0x000020	TRZ	0x0001	3	1
Moore Industries	0x000020	THZ	0x0003	1	1
Moore Industries	0x000020	THZ2	0x0004	1	1
Moore Industries	0x000020	HTZ	0x0005	1	1
Moore Industries	0x000020	TCM	0x0006	1	1
Moore Industries	0x000020	Unknown Device (0x2007)	0x0007	1	1
M-System Co.	0x00001D	B6U	0x0001	1	1
M-System Co.	0x00001D	B3HU	0x0002	1	1
M-System Co.	0x00001D	27HU	0x0003	1	1
MTS Systems Corp.	0x000063	M-Series	0x00ED	0	1
Ohmart	0x000067	DSTH/LSTH	0x00E0	1	4
Ohmart	0x000067	DSTH/LSTH Comp	0x00E1	1	1
Open Field Communications	0x0000DD	Unknown Device (0xdd00)	0x0000	1	1
Open Field Communications	0x0000DD	FMU4x Envelope	0x0001	1	1
Open Field Communications	0x0000DD	FMR2xx Envelope	0x0002	1	1
Open Field Communications	0x0000DD	FMP4x Envelope	0x0003	1	1
Oval	0x000064	ULTRA OVAL	0x0064	2	1
Oval	0x000064	ExDelta	0x0065	1	1
Oval	0x000064	9401 Mass flo	0x006E	2	1
Oval	0x000064	9801 Mass flo	0x006F	2	1
Oval	0x000064	9201 Mass flo	0x0070	2	1
Oval	0x000064	9431 Mass flo	0x007B	2	1
Panametics	0x00009D	x868	0x0070	1	1
Paper Machine Components	0x00007E	SMT-EL	0x00E0	1	1
Peek Measurement	0x000027	900 Densitometer	0x0000	0	1
Peek Measurement	0x000027	900 Densitometer	0x0000	1	1
PEPPERL+FUCHS	0x00005D	Barcon	0x000E	1	1
PEPPERL+FUCHS	0x00005D	Unknown Device (0x5d11)	0x0011	2	2
PEPPERL+FUCHS	0x00005D	Pulscon	0x0012	2	1
Phoenix Contact	0x0000B0	MCR-TS-LP	0x0001	2	2
Phoenix Contact	0x0000B0	MCR-HT-TS	0x0002	2	2
PMV	0x00009B	D3	0x00D3	1	2
PMV	0x00009B	D3	0x00D3	1	3
PR Electronics	0x00006D	T55	0x00DF	1	1
PR Electronics	0x00006D	PRetrans 6335	0x00EE	1	1
PR Electronics	0x00006D	Pretop 5335	0x00EF	1	1
Pyromation Inc	0x0000B5	Series442	0x007F	2	1
Pyromation Inc	0x0000B5	Series642	0x0080	2	2
Pyromation Inc	0x0000B5	Series642	0x0080	2	3
ROBERTSHAW	0x00005C	Excalibur 7000	0x00C8	1	2
Rosemount	0x000026	3044 Temp	0x0002	3	3
Rosemount	0x000026	1151s	0x0003	1	1
Rosemount	0x000026	1151s	0x0003	2	1
Rosemount	0x000026	1151s	0x0003	3	1
Rosemount	0x000026	1151s	0x0003	4	2
Rosemount	0x000026	1151s	0x0003	5	4
Rosemount	0x000026	1151s	0x0003	6	1
Rosemount	0x000026	Magmeter	0x0004	3	3
Rosemount	0x000026	Magmeter	0x0004	4	3
Rosemount	0x000026	Magmeter	0x0004	5	3
Rosemount	0x000026	Magmeter	0x0004	6	1
Rosemount	0x000026	Magmeter	0x0004	7	5
Rosemount	0x000026	Magmeter	0x0004	7	6
Rosemount	0x000026	Magmeter	0x0004	8	3
Rosemount	0x000026	Magmeter	0x0004	9	3
Rosemount	0x000026	Magmeter	0x0004	10	1
Rosemount	0x000026	3051C	0x0006	1	2
Rosemount	0x000026	3051C	0x0006	2	6

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Rosemount	0x000026	3051C	0x0006	3	2
Rosemount	0x000026	3051C	0x0006	3	6
Rosemount	0x000026	3051C	0x0006	6	3
Rosemount	0x000026	3051C	0x0006	6	4
Rosemount	0x000026	3051C	0x0006	7	5
Rosemount	0x000026	3051C	0x0006	7	7
Rosemount	0x000026	Mag HS	0x000C	1	5
Rosemount	0x000026	Mag HS	0x000C	1	6
Rosemount	0x000026	3044C Temp	0x000D	1	3
Rosemount	0x000026	3044C Temp	0x000D	2	3
Rosemount	0x000026	3001C HTG	0x000E	1	2
Rosemount	0x000026	3001C HTG	0x000E	2	1
Rosemount	0x000026	3001C HTG	0x000E	3	1
Rosemount	0x000026	3051C LP	0x000F	1	1
Rosemount	0x000026	Vortex	0x0010	1	3
Rosemount	0x000026	Vortex	0x0010	2	1
Rosemount	0x000026	Vortex	0x0010	3	1
Rosemount	0x000026	3201 SAM	0x0011	1	2
Rosemount	0x000026	3201 SAM	0x0011	1	3
Rosemount	0x000026	3202 SAM	0x0013	1	3
Rosemount	0x000026	3001S HTG	0x0014	2	1
Rosemount	0x000026	3095MV	0x0016	1	8
Rosemount	0x000026	3095MV	0x0016	2	2
Rosemount	0x000026	3095MV	0x0016	2	3
Rosemount	0x000026	644 Temp	0x0018	3	1
Rosemount	0x000026	644 Temp	0x0018	4	1
Rosemount	0x000026	644 Temp	0x0018	5	4
Rosemount	0x000026	644 Temp	0x0018	6	2
Rosemount	0x000026	644 Temp	0x0018	7	1
Rosemount	0x000026	3144 Temp	0x0019	1	8
Rosemount	0x000026	3144 Temp	0x0019	2	1
Rosemount	0x000026	3144 Temp	0x0019	3	2
Rosemount	0x000026	3144 Temp	0x0019	3	3
Rosemount	0x000026	3144 Temp	0x0019	3	7
Rosemount	0x000026	3144 Temp	0x0019	4	1
Rosemount	0x000026	3244 Temp	0x001A	1	8
Rosemount	0x000026	3244 Temp	0x001A	2	1
Rosemount	0x000026	3750	0x001C	1	2
Rosemount	0x000026	3750	0x001C	2	2
Rosemount	0x000026	Tri-Loop	0x001D	1	2
Rosemount	0x000026	3095C	0x001E	5	3
Rosemount	0x000026	3300	0x0021	1	1
Rosemount	0x000026	3300	0x0021	2	1
Rosemount	0x000026	3300	0x0021	3	2
Rosemount	0x000026	2088 Smart	0x0023	3	2
Rosemount	0x000026	ProBar	0x0024	2	2
Rosemount	0x000026	ProBar	0x0024	3	1
Rosemount	0x000026	ProBar	0x0024	4	1
Rosemount	0x000026	2090 Smart	0x0027	3	1
Rosemount	0x000026	ProBar UC	0x0028	3	1
Rosemount	0x000026	ProBar UC	0x0028	4	1
Rosemount	0x000026	ProPlate UC	0x002F	3	1
Rosemount	0x000026	1810	0x0036	3	1
Rosemount	0x000026	8712D	0x0037	1	2
Rosemount	0x000026	8712D	0x0037	2	1
Rosemount	0x000026	4600	0x0038	1	2
Rosemount	0x000026	8800D	0x003A	1	1
Rosemount	0x000026	8800D	0x003A	1	2
Rosemount	0x000026	8800D	0x003A	2	1
Rosemount	0x000026	248 Temperature	0x003B	1	1
Rosemount	0x000026	248 Temperature	0x003B	2	1
Rosemount	0x000026	8732D	0x003C	1	1
Rosemount	0x000026	8732D	0x003C	2	1
Rosemount	0x000026	8732D	0x003C	3	1
Rosemount	0x000026	2088LP	0x0040	1	1
Rosemount	0x000026	951	0x0042	6	3

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Rosemount	0x000026	951	0x0042	7	5
Rosemount	0x000026	5400	0x0043	1	1
Rosemount	0x000026	3051S SIS	0x0044	1	1
Rosemount	0x000026	3051S SIS	0x0044	1	2
Rosemount	0x000026	3144P SIS	0x0045	1	1
Rosemount	0x000026	3144P SIS	0x0045	2	1
Rosemount	0x000026	4500	0x0047	7	1
Rosemount	0x000026	3051S Diag	0x004A	1	2
Rosemount	0x000026	3051S Diag	0x004A	2	1
Rosemount	0x000026	3100	0x0050	5	5
Rosemount	0x000026	3100	0x0050	5	6
Rosemount	0x000026	2051	0x0055	3	1
Rosemount	0x000026	8712E	0x0057	1	1
Rosemount	0x000026	8712E	0x0057	3	1
Rosemount	0x000026	8712E	0x0057	3	2
Rosemount	0x000026	Metran-150	0x0062	3	1
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	3	4
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	3	5
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	4	4
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	4	5
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	5	4
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	5	5
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	6	2
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	7	2
Rosemount Analytic	0x00002E	2081 pH	0x0006	1	1
Rosemount Analytic	0x00002E	2081 Cond	0x0007	1	1
Rosemount Analytic	0x00002E	Oxymitter 4000	0x000C	1	1
Rosemount Analytic	0x00002E	Oxymitter 4000	0x000C	2	1
Rosemount Analytic	0x00002E	Oxymitter 4000	0x000C	3	1
Rosemount Analytic	0x00002E	Oxymitter 4000	0x000C	4	1
Rosemount Analytic	0x00002E	WC_3000	0x000D	1	1
Rosemount Analytic	0x00002E	3081FG	0x000E	1	1
Rosemount Analytic	0x00002E	OPM-2000R	0x000F	1	1
Rosemount Analytic	0x00002E	OCX-4000	0x0010	1	1
Rosemount Analytic	0x00002E	OCX-4000	0x0010	2	1
Rosemount Analytic	0x00002E	OCX-4000	0x0010	3	1
Rosemount Analytic	0x00002E	OCX-4000	0x0010	4	1
Rosemount Analytic	0x00002E	3081pH	0x0014	1	1
Rosemount Analytic	0x00002E	3081pH	0x0014	1	2
Rosemount Analytic	0x00002E	3081C	0x0015	1	1
Rosemount Analytic	0x00002E	3081-81con	0x0016	1	1
Rosemount Analytic	0x00002E	3081-81con	0x0016	2	1
Rosemount Analytic	0x00002E	3081-81T	0x0017	1	1
Rosemount Analytic	0x00002E	5081A	0x0018	1	1
Rosemount Analytic	0x00002E	5081A	0x0018	2	1
Rosemount Analytic	0x00002E	5081C/T	0x0019	1	1
Rosemount Analytic	0x00002E	5081pH	0x001A	1	1
Rosemount Analytic	0x00002E	5081pH	0x001A	2	1
Rosemount Analytic	0x00002E	Xmt A	0x001B	1	1
Rosemount Analytic	0x00002E	Xmt C/T	0x001C	1	1
Rosemount Analytic	0x00002E	Xmt pH	0x001D	1	1
Rosemount Analytic	0x00002E	5081FG	0x001E	1	1
Rosemount Analytic	0x00002E	XS-O2	0x002B	1	1
Rosemount Analytic	0x00002E	54pH/ORP	0x0050	1	2
Rosemount Analytic	0x00002E	54eC	0x0051	1	2
Rosemount Analytic	0x00002E	54eC	0x0051	2	1
Rosemount Analytic	0x00002E	52epH/ORP	0x0052	1	1
Rosemount Analytic	0x00002E	52epH/ORP	0x0052	2	1
Rosemount Analytic	0x00002E	54eA	0x0053	1	1
Rosemount Analytic	0x00002E	54eA	0x0053	2	1
Rueger	0x00008D	S95 HRT	0x0001	1	1
Rueger	0x00008D	S95.3U_2	0x007F	1	1
Saab Tank Control	0x00004F	5600	0x00ED	6	1
Saab Tank Control	0x00004F	5600	0x00ED	7	1
Saab Tank Control	0x00004F	TankRadarPro	0x00EF	2	1
Saab Tank Control	0x00004F	TankRadarPro	0x00EF	3	1



# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Saab Tank Control	0x00004F	TankRadarPro	0x00EF	5	1
Saab Tank Control	0x00004F	TankRadarPro	0x00EF	6	1
Samson	0x000042	373X-3	0x00EF	2	1
Samson	0x000042	373X-3	0x00EF	4	2
Samson	0x000042	3780	0x00F9	1	1
Samson	0x000042	3780	0x00F9	2	1
Schlumberger	0x000028	NEXGEN	0x0001	1	1
Schlumberger	0x000028	NEXGEN	0x0001	1	2
Siemens	0x00002A	SITRANS FUS	0x0004	1	1
Siemens	0x00002A	SITRANS LR	0x0007	1	1
Siemens	0x00002A	SITRANS P HS	0x000A	1	1
Siemens	0x00002A	SITRANS P DS	0x000B	1	2
Siemens	0x00002A	SITRANS P DS	0x000B	2	1
Siemens	0x00002A	SITRANS P DS	0x000B	3	1
Siemens	0x00002A	SITRANS P DS	0x000B	3	2
Siemens	0x00002A	SITRANS P ES	0x000C	1	1
Siemens	0x00002A	SITRANS P MS	0x000D	1	1
Siemens	0x00002A	SITRANS TW	0x0010	1	1
Siemens	0x00002A	SITRANS TK H	0x0012	1	1
Siemens	0x00002A	SITRANS TK H	0x0012	2	1
Siemens	0x00002A	SITRANS TH300	0x0013	1	1
Siemens	0x00002A	SITRANS TH300	0x0013	1	2
Siemens	0x00002A	SIPART PS2	0x0015	1	1
Siemens	0x00002A	SIPART PS2	0x0015	2	1
Siemens	0x00002A	SIPART PS2	0x0015	3	1
Siemens	0x00002A	SIPART PS2	0x0015	3	2
Siemens	0x00002A	SITRANS FM	0x0016	1	1
Siemens	0x00002A	SITRANS FM MAGFLO	0x0018	1	1
Siemens	0x00002A	SITRANS FM MAGFLO	0x0018	2	1
Siemens	0x00002A	SITRANS FC MASSFLO	0x0019	2	1
Siemens	0x00002A	SITRANS FM IT2 / TM2	0x001A	1	1
Siemens	0x00002A	SITRANS P300	0x001D	1	1
Siemens	0x00002A	SITRANS P300	0x001D	2	1
Siemens	0x00002A	SITRANS P300	0x001D	3	1
Siemens	0x00002A	SITRANS P300	0x001D	3	2
Siemens	0x00002A	SITRANS TR300	0x001F	1	1
Siemens Milltronics PI	0x000054	MSP2002	0x00F8	0	1
Siemens Milltronics PI	0x000054	MSP2002	0x00F8	0	2
Siemens Milltronics PI	0x000054	MSP2002	0x00F8	1	1
Siemens Milltronics PI	0x000054	MST9500	0x00F9	0	1
Siemens Milltronics PI	0x000054	MST9500	0x00F9	1	2
Siemens Milltronics PI	0x000054	MST9500	0x00F9	2	3
Siemens Milltronics PI	0x000054	MST9500	0x00F9	3	4
Smar	0x00003E	LD301	0x0001	3	5
Smar	0x00003E	LD301	0x0001	3	6
Smar	0x00003E	LD301	0x0001	4	2
Smar	0x00003E	TT301	0x0002	2	2
Smar	0x00003E	TT301	0x0002	3	1
Smar	0x00003E	FY301	0x0003	1	2
Smar	0x00003E	FY301	0x0003	2	1
Smar	0x00003E	LD291	0x0004	3	1
Smar	0x00003E	LD291	0x0004	4	1
Smar	0x00003E	TP301	0x0005	1	1
Smar	0x00003E	DT301	0x0006	3	2
Smar	0x00003E	LD400	0x000A	1	1
SMC	0x000083	IP8101	0x007E	1	1
SMC	0x000083	F793-E701	0x00EF	1	2
Sparling Instruments	0x000043	FM6XX	0x00EE	1	1
Status Instruments	0x000084	SEM 300	0x00EF	0	0
Status Instruments	0x000084	SEM 300	0x00EF	1	1
TN Technologies	0x000090	NDMi	0x007D	1	3
TN Technologies	0x000090	Accu-Wave	0x007E	1	4
TN Technologies	0x000090	NCMi	0x007F	2	2
TN Technologies	0x000090	NCMi	0x007F	3	1
Toshiba	0x00002C	AP3100	0x0002	4	2
Toshiba	0x00002C	LF220	0x000A	5	3



# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Toshiba	0x00002C	LF220	0x000A	6	1
Toshiba	0x00002C	LF220	0x000A	8	1
Toshiba	0x00002C	LF220	0x000A	8	2
Turbo	0x000081	Intermag-Transmag	0x007F	2	3
Turbo	0x000081	Intermag-Transmag	0x007F	3	4
Turck	0x00009C	KMU-HLI	0x0001	1	1
Tyco Valve Controls	0x0000AB	SmartCal	0x0001	1	1
Tyco Valve Controls	0x0000AB	Unknown Device (0xab02)	0x0002	1	1
Unknown Manufacturer (0xef)	0x0000EF	Unknown Device (0xef83)	0x0083	1	0
Unknown Manufacturer (0xef)	0x0000EF	Unknown Device (0xef83)	0x0083	1	1
Viatran	0x000032	970	0x0001	1	2
Viatran	0x000032	970	0x0001	2	3
Viatran	0x000032	I/A Pressure	0x002E	1	3
Vortek Instruments, LLC	0x000087	Innova-Mass	0x0001	5	1
Welltech Shanghai	0x000093	WT2000	0x007C	5	1
Westlock Controls	0x00004D	ICOT	0x0001	4	1
Westlock Controls	0x00004D	ICOT	0x0001	5	2
Westlock Controls	0x00004D	SmartCal	0x0002	5	2
Westlock Controls	0x00004D	D-EPIC	0x0003	1	1
Westlock Controls	0x00004D	D-EPIC ESD	0x0004	1	1
WIKA	0x00006B	UniTrans	0x00EE	5	1
WIKA	0x00006B	T32	0x00EF	0	2
WIKA	0x00006B	T32	0x00EF	1	1
WIKA	0x00006B	T32	0x00EF	2	1
Yamatake	0x000036	MagneW	0x0001	1	2
Yamatake	0x000036	ST3000	0x0002	1	2
Yamatake	0x000036	ST3000	0x0002	2	1
Yamatake	0x000036	SVP	0x0003	1	1
Yamatake	0x000036	SVP	0x0003	2	1
Yamatake	0x000036	ThermoPlus ATT	0x0004	1	2
Yamatake	0x000036	PTG	0x0005	1	1
Yamatake	0x000036	MagneW 2W	0x0008	1	1
Yamatake	0x000036	MagneW 2W	0x0008	2	1
Yamatake	0x000036	MagneW 2W	0x0008	2	2
Yamatake	0x000036	MAGNEW4W	0x000C	1	1
Yokogawa	0x000037	YEWFLO	0x0001	1	4
Yokogawa	0x000037	YEWFLO	0x0001	2	2
Yokogawa	0x000037	YT200	0x0002	1	1
Yokogawa	0x000037	UNICOM	0x0003	1	1
Yokogawa	0x000037	EJA	0x0004	1	2
Yokogawa	0x000037	EJA	0x0004	2	1
Yokogawa	0x000037	EJA	0x0004	3	1
Yokogawa	0x000037	ADMAG AE	0x0005	1	1
Yokogawa	0x000037	ADMAG AE	0x0005	2	1
Yokogawa	0x000037	AM11	0x0006	1	1
Yokogawa	0x000037	ADMAG SE	0x0008	1	1
Yokogawa	0x000037	ADMAG SE	0x0008	2	1
Yokogawa	0x000037	YTA	0x0009	1	2
Yokogawa	0x000037	YTA	0x0009	2	1
Yokogawa	0x000037	YTA	0x0009	3	1
Yokogawa	0x000037	YTA70E	0x000A	1	1
Yokogawa	0x000037	DYF	0x000B	1	1
Yokogawa	0x000037	DYF	0x000B	2	1
Yokogawa	0x000037	DYF	0x000B	3	1
Yokogawa	0x000037	DYF	0x000B	3	2
Yokogawa	0x000037	ZR202	0x000C	1	1
Yokogawa	0x000037	ZR402	0x000D	1	1
Yokogawa	0x000037	ISC202	0x0014	1	2
Yokogawa	0x000037	PH202	0x0015	1	3
Yokogawa	0x000037	SC202	0x0016	1	2
Yokogawa	0x000037	DO202	0x0018	1	1
Yokogawa	0x000037	PH150	0x0027	1	1
Yokogawa	0x000037	PH150	0x0027	2	1
Yokogawa	0x000037	SC150	0x0028	1	1
Yokogawa	0x000037	SC150	0x0028	2	1
Yokogawa	0x000037	PH450	0x002B	1	1

# Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04 R05

DDs for Language: en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Yokogawa	0x000037	PH450	0x002B	2	1
Yokogawa	0x000037	SC450	0x002C	1	1
Yokogawa	0x000037	SC450	0x002C	2	1
Yokogawa	0x000037	ISC450	0x002D	1	1
Yokogawa	0x000037	ISC450	0x002D	2	1
Yokogawa	0x000037	ROTAMASS	0x0040	1	2
Yokogawa	0x000037	RAMC	0x0041	1	2
Yokogawa	0x000037	RCCT_F3	0x0042	1	1
Yokogawa	0x000037	RCCT_F3	0x0042	1	3
Yokogawa	0x000037	RCCT_F3	0x0042	2	1
Yokogawa	0x000037	RCCT_F3	0x0042	3	1
Yokogawa	0x000037	AXFA11	0x0050	1	1
Yokogawa	0x000037	AXFA11	0x0050	1	2
Yokogawa	0x000037	EJX	0x0051	1	1
Yokogawa	0x000037	EJX	0x0051	1	2
Yokogawa	0x000037	AXFA14	0x0052	1	1