

Compact pH electrode system sensopac CPA 320



Sensopac pH/Redox electrode systems are suitable for process measurement at high pressures and temperatures. For measurements in hazardous areas (zone 0), the Sensopac can be equipped with Ex electrodes. Self-monitoring is possible with all Sensopac types. A double reference electrode is immersed in the internal bridge electrolyte which is in contact with the medium via a large-area, dirt repelling diaphragm. The two reference systems of this electrode are connected to two measuring circuits of the pH/Redox measuring instrument Mycom CPM 152.

One of the two reference systems is specially protected so that only the second monitoring reference system is affected by penetration of electrode poisons. Any resulting difference in measured values is signaled by the Mycom CPM 152 instrument before the main measuring circuit is influenced.

Areas of application

- In-process applications for in-line measurement at pressures of up to 10 bar without counterpressure.
- For measurement in aggressive media (PP and PVDF options).
- For measurement in the food industry (stainless steel version).

Benefits at a glance


- Problem-free, direct application under high pressures (max. 10 bar) and temperatures (105 °C/130 °C) permits close matching to process conditions.
- High measuring accuracy in conjunction with the pH measuring transmitter such as Mycom CPM 152:
Self-monitoring of reference system with fault signaling; an alarm issued before the main measuring circuit is affected.
- The reference system is protected by an electrolyte bridge.
- Bridge electrolyte adaptable to the medium and easily replaceable.
- No additional protective assemblies required. Can be directly used as an immersion or flow sensor.
- Numerous mounting accessories from welding sockets to immersion assemblies.



Assembly

Assembly from
Sensopac CPA 320:

- 1 Type UBS built-in adapter for installing the Sensopac in threaded fitting G 2 1/2"
- 2 pH measuring electrode
- 3 Pt 100 temperature sensor
- 4 Shock protection
- 5 Diaphragm cartridge
- 6 Union nut (part of UBS adapter)
- 7 Sensopac body
- 8 Removable protective hood
- 9 Electrode connector
- 10 Cable, ready-made with connectors
- 11 Cap with sealed measuring cable entry



Standard material combinations:

- Polypropylene body, Hastelloy-C4 shock protection, EPDM O-rings
- Stainless steel body, stainless steel shock protection, EPDM O-rings
- PVDF body, Hastelloy-C4 shock protection, EPDM O-rings

A wide range of measuring electrodes permits close system matching. For example, the electrode type CPS 64-1 BA 2 GSA permits pH measurements up to pH 14 and temperatures up to 130 °C. Permits measurements in hazardous area zone 0 when equipped with Conducta Ex electrodes.

All electrodes built into the Sensopac system are equipped with a screw head and are easily replaced when maintenance is required.

The Sensopac compact pH electrode system can be installed and removed quickly and easily. To assist this, the system is supplied with one of the following options of built-in adapters:

- UBS – a threaded adapter for quick installation and removal.
- AMS – a dairy adapter, preferably used where cleaning or sterilization is required.

Furthermore, a wide range of accessories, such as immersion sensors, flow sensors and a spray head for electrode cleaning, is available.

Sensopac system overview

The Sensopac CPA 320 can be installed in various built-in adapters. The type of

built-in adapter is specified with the order.

Connection:

- Cable with connectors and connector sleeves, ready-made, lengths 5, 10, 15 m

Base body:

- PP
- PVDF
- stainless steel 1.4571

Electrodes:

- 1 pH electrode
- 1 double reference CPS 13-0 TD 1 GSA
- 1 temperature CTS 1-A 2 GSA



Standard built-in adapter



AMS adapter for installation in dairy fittings




UBS adapter for installation in G 2 1/2" sockets



UBS + GS (G 2 1/2" sockets)

Automatic cleaning




- Automatic cleaning during measuring operation with a spray cleaning system is possible.
- The type CPR 3 – 2 spray head can also be retrofitted when using the AMS, UBS, GS adapters.
- The spray head is suitable for water and for diluted cleaning chemicals.



➔ Sensopac with built-in spray head for electrode cleaning


◁ CPA 120 with Sensopac and built-in cleaning system

Assemblies for Sensopac CPA 320



➔ For open tanks:
immersion assembly
CPA 110-S

↻ For closed tanks:
process assembly
CPA 120-S



For installation in pipes:

➔ Flow assembly
CPA 250-S
material: PP; PVDF


➔ Flow assembly
CPA 250-S
material: stainless steel



Operating principle

Sensopac with connection to Mycom CPM 152:

- 1 pH electrode immersed directly in the measured solution
- 2 Low-impedance double reference electrode immersed in bridge electrolyte 5
- 3 Reference system for the master measuring circuit
- 4 Reference system for the monitor circuit
- 5 Bridge electrolyte in the large reference chamber
- 6 Diaphragm cartridge with a dirt-repellent, blocking-free PVF diaphragm
- 7 Master measuring circuit
- 8 Monitor circuit



The pH electrode (1) generates a half-cell voltage dependent on the pH of the medium. The dirt-repellent PVF diaphragm in the diaphragm cartridge prevents blocking and assures electrical contact between the medium and the bridge electrolyte (5) in which the double reference electrode (2) is immersed.

Reference system (3) of the double reference electrode supplies the constant reference voltage for the master measuring circuit.

Reference system (4) of the double reference electrode supplies the reference voltage for the monitor circuit.

Self-checking

Both reference systems (3) and (4) are located in the bridge electrolyte (5) behind the diaphragm cartridge (6).

Both possess an additional diaphragm system.

Reference system (3) is arranged in a long capsule behind another diaphragm at the upper opening of the capsule.

Such an arrangement ensures that if any interfering ions penetrate into the bridge electrolyte (5), only reference system (4) is contaminated, while reference system (3) is seldom affected.

Any difference in the two reference potentials is detected by the pH instrument Mycom CPM 152 and results in an error message.

The most important feature of this monitoring technique is that the alarm is produced before there is any drift on the master measuring circuit itself.



Installation and dimensions

Picture left:
Construction of
Sensopac

- 1 Measuring cable
- 2 Star knob for tightening and releasing the pressure seal
- 3 Measuring cable entry
- 4 PE connector
- 5 Protective cover
- 6 Potential matching connector (PMC)
- 7 Electrode connector
- 8 Union nut
- 9 O-ring
- 10 Sensopac body
- 11 Protective cap/calibration cup
- 12 Shock protection bolt
- 13 Electrodes
- 14 Diaphragm cartridge


Picture right:
Sensopac with
UBS adapter

- 1 Sensopac
- 2 Snap rings
- 3 Union nut
- 4 UBS adapter



Sensopac with AMS
adapter (food
applications)

- 1 Sensopac
- 2 AMS adapter
- 3 DN 80 threaded socket, to DIN 11851
- 4 Short T-piece DN 80, DIN 11852





Installation and dimensions

Picture left:
Sensopac AFS-V
adapter. Stainless steel
1.4571 version for
flange mounting

- 1 NW 80 flange,
ND 16, to DIN 2576
Material: PP
- 2 Weld-on flange
NW 80, ND 16,
to DIN 2633
- 3 AFS

Picture right:
Threaded socket
weld-on GS, GS-V for
Sensopac installation

- 1 Sensopac
- 2 Snap rings
- 3 Union nut
NW 50, to DIN 11851
Material: 1.4401
- 4 Width across flats
SW 95
- 5 UBS
- 6 Threaded socket
GS, GS-V
out of PP or 1.4571





Picture left:
Immersion assembly
CPA 110-S for
installation of Sensopac

- 1 Weather protection
cover SR
- 2 Pg 16 cable gland
- 3 Assembly head
- 4 Oval flange
- 5 Mounting plate
- 6 Immersion tube
- 7 Threaded connection
for mounting
Sensopac
- 8 Sensopac body
- 9 4 mounting holes,
Ø 18
- 10 Pg 16

Picture right:
Immersion assembly
CPA 120-S for
installation of Sensopac


- 1 Weather protection
cover SR
- 2 Pg 16 cable gland
- 3 Assembly head
- 4 Threaded fitting
- 5 Flange
- 6 Immersion tube
- 7 Threaded connection
for mounting
Sensopac
- 8 Sensopac body
- 9 4 mounting holes,
Ø 18
- 10 Pg 16



Installation and dimensions


Flow assembly
CPA 250-S for
installation of Sensopac,
Material PP, PVDF

- 1 Sensopac electrode system
- 2 Union nut NW 50, to DIN 11851
Material: 1.4401
- 3 Pipe clamp with central installation hole
- 4 Pipe DA 32 DN 25
- 5 Screwed nipple NP, G1"
- 6 O-ring
Material: EPDM
- 7 Pipe DA 32 DN 25
- 8 Plug G1"
- 9 Flow assembly CPA 250-S
out of PP or PVDF



Flow assembly CPA
250-S for installation of
Sensopac out of 1.4571


- 1 Adapter for Sensopac, included as standard
- 2 O-ring, EPDM
- 3 Union nut
- 4 Weld-on flange DN 25, PN 16, connection to DIN 2501
- 5 Drain plug G 1/2



Electrical connections


Cable configuration for Sensopac with double reference system
Cable: CPK 6

- 1 Reference signal measuring circuit 2
- 2 Reference signal measuring circuit 1
- 3 pH signal
- 4 Pt 100 3-wire connection
- 5 Potential matching PE
- 6 Potential matching pin
- 7 Pt 100
- 8 pH electrode
- 9 Double reference electrode
- 10 Coaxial line not visible
- 11 Cover screen connection
- 12 Reference system 1
- 13 Reference system 2



Cable configuration for Sensopac with two pH measuring electrodes
Cable: CPK 6

- 1 Reference signal measuring circuit 2
- 2 Reference signal measuring circuit 1
- 3 pH signal measuring circuit 2
- 4 pH signal measuring circuit 1
- 5 Potential matching PE
- 6 PE
- 7 Combination measuring cable CPK 6
- 8 Potential matching pin
- 9 pH electrode 2
- 10 pH electrode 1
- 11 Double reference electrode
- 12 Cover screen connection
- 13 Reference system 1
- 14 Reference system 2




Technical data

Base body	polypropylene PP
.	polyvinylidene fluoride PVDF
.	stainless steel 1.4571
Seals	EPDM (standard), Viton
Potential matching pin	Hastelloy C 4 (standard)
.	or stainless steel 1.4571
Electrodes	glass, special types made of plastic
.	CPS 64-1 BA2 GSA
Double reference electrode	CPS 13-0 TD1 GSA
Temperature sensor	CTS 1-A2 GSA
Internal thread for electrodes	Pg 13.5
Diaphragm cartridge	replaceable PVF diaphragm,
.	screwed into PVDF cartridge DKV-HT
Electrode seals	EPDM (standard)
Bridge electrolyte	KCl
Socket wrench for electrodes and diaphragm	size 17/special

Subject to modifications.

Pressure and temperature operating range



Working pressure for different materials and temperatures

Maximum permissible operating pressure			
Temperature [°C]	PP [bar]	PVDF [bar]	1.4571 [bar]
-5	10	10	10
20	10	10	10
70	1,5	8	10
80	0,5	7	10
90	0	10	10
105	–	6	10
130	–	5	5

Order code and Accessories

non- standard
appliance

CPA110

Version
S for use with Sensopac electrode system CPA 320

Material / Immersion depth
10 PP / 1000 mm
19 PP / 400 ... 2000 mm
30 PVDF / 1000 mm
39 PVDF / 400 ... 2000 mm
99 Special version

CPA110- ← **Order code**

non- standard
appliance

CPA120

Version
S for use with Sensopac electrode system CPA 320
T for use with Sensopac electrode system CPA 320, flange DN 125 for Chemoclean

Materials / Immersion depth
10 PP / 1000 mm
19 PP / 400 - 2000 mm
99 Special version

CPA120- ← **Order code**

CPA250

Version
S for use with Sensopac compact system CPA 320

Materials / Process connection
00 PP / G 1" BSP
13 1.4571 / flange 2 x DN 25
20 PVDF / G1" BSP
99 Special version

CPA250- ← **Order code**

Order code

Sensopac CPA 320

Assembly materials / O-rings

- P PP / EPDM
- F PVDF / EPDM
- V Stainless steel 1.4571 / EPDM
- Y Special version

Number of electrodes

- 1 For use with 1 meas. and 1 ref. electrode
- 9 Special version

Electrode type

- 2 CPS 64-1AA2 GSA
- 3 CPS 64-1BA2 GSA
- 9 Special version

Cable length / colour

- 0 5 Metre, black
- 1 10 Metre, black
- 2 15 Metre, black
- 3 5 Metre, blue (Ex)
- 4 10 Metre, blue (Ex)
- 5 15 Metre, blue (Ex)
- 9 Special version

Adaptor type

- E Adaptor for CPA 110 / CPA 120
- K Without adaptor
- U UBS out of PP
- V UBS out of stainless steel
- W UBS out of PVDF
- Y Special version

Application

- A Standard type electrode
- Z EX-type electrode
- Y Special version

CPA320-

--	--	--	--	--	--

← Order code

Endress+Hauser GmbH+Co.
- Instruments International -

P.O. Box 22 22
D-79574 Weil am Rhein
Tel. (0 76 21) 9 75 - 02
Fax (0 76 21) 97 53 45

Endress + Hauser
Nothing beats know-how

